

• 9971-MV6-4K • 9971-MV18-4K 12G/6G/3G/HD/SD UHD Multiviewers

Product Manual

	Cobalt Digital Inc.
<u>COBALT.</u>	2506 Galen Drive Champaign, IL 61821 Voice 217.344.1243 • Fax 217.344.1245 www.cobaltdigital.com

Copyright

©Copyright 2019, Cobalt Digital Inc. All Rights Reserved.

Duplication or distribution of this manual and any information contained within is strictly prohibited without the express written permission of Cobalt Digital Inc. This manual and any information contained within, may not be reproduced, distributed, or transmitted in any form, or by any means, for any purpose, without the express written permission of Cobalt Digital Inc. Reproduction or reverse engineering of software used in this device is prohibited.

Disclaimer

The information in this document has been carefully examined and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Cobalt Digital Inc. reserves the right to make changes to any products herein to improve readability, function, or design. Cobalt Digital Inc. does not assume any liability arising out of the application or use of any product or circuit described herein.

Trademark Information

Cobalt[®] is a registered trademark of Cobalt Digital Inc.

openGear[®] is a registered trademark of Ross Video Limited. DashBoard[™] is a trademark of Ross Video Limited.

TSL[™] is a trade name of TSL Professional Products Ltd.

Congratulations on choosing the Cobalt[®] 9971 12G/6G/3G/HD/SD UHD Multiviewers (9971-MV18-4K and 9971-MV6-4K). The 9971 is part of a full line of modular processing and conversion gear for broadcast TV environments. The Cobalt Digital Inc. line includes video decoders and encoders, audio embedders and deembedders, distribution amplifiers, format converters, remote control systems and much more. Should you have questions pertaining to the installation or operation of your 9971, please contact us at the contact information on the front cover.

Manual No.:	9971-MVX-OM
Document Version:	V1.0B
Release Date:	October 23, 2019
Applicable for Firmware Version (or greater):	v0.143 or newer
Description of product/manual changes:	 Manual version V1.0B has corrections that fix transposed HDMI OUT 1 and HDMI OUT 2 locations on rear module. Connector designations are now properly correlated to connector locations shown in illustrations.

Table of Contents

Chapter 1	Introduction	1-1
	Overview	1-1
	9971-MVx-4K Card Software Versions and this Manual	1-2
	Cobalt Reference Guides	1-3
	Manual Conventions	1-3
	Warnings, Cautions, and Notes	1-4
	Labeling Symbol Definitions	1-4
	Safety and Regulatory Summary	1-5
	Warnings	1-5
	Cautions	1-5
	EMC Compliance Per Market	1-5
	9971-MVx-4K Functional Description	1-6
	9971-MVx-4K Program Video Input/Output Formats	1-6
	Video Processing Description	1-8
	User Control Interface	1-10
	9971-MVx-4K Rear I/O Modules	1-12
	Technical Specifications	1-12
	Warranty and Service Information	1-14
	Cobalt Digital Inc. Limited Warranty	1-14
	Contact Cobalt Digital Inc	1-15
Chapter 2	Installation	2-1
	Overview	2-1
	Installing the 9971-MVx-4K Into a Frame Slot	2-1
	Installing a Rear I/O Module	2-3
	9971-MVx-4K Rear I/O Modules	2-4
	Setting Up 9971-MVx-4K Network Remote Control	2-6
Chapter 3	Setup Instructions.	3-1
-	Overview	3-1
	Control and Display Descriptions	3-1
	Function Menu/Parameter Menu Overview	3-2
	DashBoard [™] User Interface	3-3
	Accessing the 9971-MVx-4K Card via Remote Control	3-4
	Accessing the 9971-MVx-4K Card Using DashBoard TM	3-4
	Checking 9971-MVx-4K Card Information	3-6
	Basic Setup Overview	3-7
	9971-MVx-4K Function Menu List and Descriptions	3-8

PIP Assignment	3-9
Input Video Routing Controls	3-10
Screen Layout Controls	3-11
UMD/Tally Color/Text Source Controls	3-16
Text Layout/Insertion Controls	3-17
Audio Meter Overlay Controls	3-23
Output Video Routing Controls	3-26
Protocols (TSL Integration) Controls	3-28
Presets	3-29
Network Settings Controls	3-30
Admin	3-30
Troubleshooting	3-31
Error and Failure Indicator Overview	3-31
Basic Troubleshooting Checks	3-33
Troubleshooting Network/Remote Control Errors	3-34
In Case of Problems	3-34

Chapter 1

Introduction

Overview

Note: This manual covers all 9971 models. Model **9971-MV6-4K** and **9971-MV18-4K** vary principally in the respective six and 18 inputs/PIPs supported. Unless noted otherwise, information herein applies to either model.

This manual provides installation and setup instructions for the 9971-MVx-4K 12G/6G/3G/HD/SD UHD Multiviewer card (also referred to herein collectively referred to as the 9971-MVx-4K).

This manual consists of the following chapters:

- Chapter 1, "Introduction" Provides information about this manual and what is covered. Also provides general information regarding the 9971-MVx-4K.
- Chapter 2, "Installation" Provides instructions for installing the 9971-MVx-4K in a frame, and connecting signal and control cabling to the 9971-MVx-4K.
- Chapter 3, "Setup Instructions" Provides overviews of setup operating controls and instructions for setting up the 9971-MVx-4K to integrate within its signal flow environment.

This chapter contains the following information:

- 9971-MVx-4K Card Software Versions and this Manual (p. 1-2)
- Manual Conventions (p. 1-3)
- Safety and Regulatory Summary (p. 1-5)
- 9971-MVx-4K Functional Description (p. 1-6)
- Technical Specifications (p. 1-12)
- Warranty and Service Information (p. 1-14)
- Contact Cobalt Digital Inc. (p. 1-15)

9971-MVx-4K Card Software Versions and this Manual

When applicable, Cobalt Digital Inc. provides for continual product enhancements through software updates. As such, functions described in this manual may pertain specifically to cards loaded with a particular software build.

The Software Version of your card can be checked by viewing the **Card Info** menu in DashBoardTM. See Checking 9971-MVx-4K Card Information (p. 3-6) in Chapter 3, "Operating Instructions" for more information. You can then check our website for the latest software version currently released for the card as described below.

Note: Not all functionality described in this manual may appear on cards with initial software versions.

Check our website and proceed as follows if your card's software does not match the latest version:

Card Software earlier than latest version	Card is not loaded with the latest software. Not all functions and/or specified performance described in this manual may be available.
	You can update your card with new Update software by going to the Support>Firmware Downloads link at www.cobaltdigital.com. Download "Firmware Update Guide", which provides simple instructions for downloading the latest firmware for your card onto your computer, and then uploading it to your card through DashBoard TM .
	Software updates are field-installed without any need to remove the card from its frame.
Card Software newer than version in manual	A new manual is expediently released whenever a card's software is updated and specifications and/or functionality have changed as compared to an earlier version (a new manual is not necessarily released if specifications and/or functionality have not changed). A manual earlier than a card's software version may not completely or accurately describe all functions available for your card.
	If your card shows features not described in this

Cobalt Reference Guides

From the Cobalt[®] web home page, go to **Support>Reference Documents** for easy to use guides covering network remote control, card firmware updates, example card processing UI setups and other topics.

Manual Conventions

In this manual, display messages and connectors are shown using the exact name shown on the 9971-MVx-4K itself. Examples are provided below.

• Card-edge display messages are shown like this:

Ch01

• Connector names are shown like this: SDI IN A

In this manual, the terms below are applicable as follows:

- 9971-MVx-4K refers to the 9971-MVx-4K 12G/6G/3G/HD/SD UHD Multiviewer card (9971-MV6-4K and/or 9971-MV18-4K).
- Frame refers to the HPF-9000, oGx, OG3-FR, 8321, or similar 20-slot frame that houses Cobalt[®] or other cards.
- Device and/or Card refers to a Cobalt[®] or other card.
- System and/or Video System refers to the mix of interconnected production and terminal equipment in which the 9971-MVx-4K and other cards operate.
- Functions and/or features that are available only as an option are denoted in this manual like this:



Warnings, Cautions, and Notes

Certain items in this manual are highlighted by special messages. The definitions are provided below.

Warnings

Warning messages indicate a possible hazard which, if not avoided, could result in personal injury or death.

Cautions

Caution messages indicate a problem or incorrect practice which, if not avoided, could result in improper operation or damage to the product.

Notes

Notes provide supplemental information to the accompanying text. Notes typically precede the text to which they apply.

Labeling Symbol Definitions

\triangle	Important note regarding product usage. Failure to observe may result in unexpected or incorrect operation.
	Electronic device or assembly is susceptible to damage from an ESD event. Handle only using appropriate ESD prevention practices. If ESD wrist strap is not available, handle card only by edges and avoid contact with any connectors or components.
	 Symbol (WEEE 2002/96/EC) For product disposal, ensure the following: Do not dispose of this product as unsorted municipal waste. Collect this product separately. Use collection and return systems available to you.

Safety and Regulatory Summary

Warnings



To reduce risk of electric shock do not remove line voltage service barrier cover on frame equipment containing an AC power supply. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Cautions

CAUTION	This device is intended for environmentally controlled use only in appropriate video terminal equipment operating environments.
CAUTION	This product is intended to be a component product of an openGear® frame. Refer to the openGear® frame Owner's Manual for important safety instructions regarding the proper installation and safe operation of the frame as well as its component products.
CAUTION	Heat and power distribution requirements within a frame may dictate specific slot placement of cards. Cards with many heat-producing components should be arranged to avoid areas of excess heat build-up, particularly in frames using only convection cooling. The 9971-MVx-4K has a moderate power dissipation (>30 W). As such, avoiding placing the card adjacent to other cards with similar dissipation values if possible.
CAUTION	If required, make certain Rear I/O Module(s) is installed before installing the 9971-MVx-4K into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.
CAUTION	If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.

EMC Compliance Per Market

Market	Regulatory Standard or Code
United States of America	FCC "Code of Federal Regulations" Title 47 Part15, Subpart B, Class A
Canada	ICES-003
International	CISPR 24:2010 IEC 61000-4-2:2008 IEC 61000-4-3:2006 with A1:2007 and A2:2010 IEC 61000-4-4:2004 IEC 61000-4-6:2008
	CISPR 22:2008

9971-MVx-4K Functional Description

Figure 1-1 shows a functional block diagram of the 9971-MVx-4K. The 9971-MVx-4K includes input processing functions to accommodate SDI inputs, multi-split ARC/scaling functions, burn-in attributes and control of borders, UMD display text, audio meters, and other accessory displays. The output is available as a 2x DA 12G/6G3G/HD/SD-SDI output or HDMI/DVI. The output raster format and aspect ratio is user-configurable.

9971-MVx-4K Program Video Input/Output Formats

The 9971-MVx-4K provides the following inputs and outputs:

- Inputs:
 - SDI IN 1 thru SDI IN n coaxial video inputs per PiP (6 inputs on 9971-MV6-4K; 18 inputs on 9971-MV18-4K). On model 9971-MV18-4K, SDI IN 1 thru SDI IN 4 can be used as a single PiP input for media using quad-link SDQS/2SI.
- Outputs:
 - **12G/6G/3G/HD/SD-SDI OUT** DA 12G/6G/3G/HD/SD-SDI multi-image video outputs.
 - HDMI/DVI OUT Multi-image HDMI/DVI out (suitable for direct connection to monitor panels)

Option (Option +DUAL). Option +DUAL offers an arrangement of multiple "Screens", with each Screen being its own independent combining multiviewer. Each Screen can select from *n*-number of available SDI inputs, and in turn provide its output to be outputted on a selectable SDI or HDMI output. Option +DUAL provides independent MV processors Screen 1 and Screen 2, which provides two unique, independent multiviewer views which can be fed to separate monitor screens. Each screen output can be set for different output formats as well.

- **Note:** Total number of PiPs used for single-screen (non-option), Screen 1 and/or Screen 2 (combined or separate) cannot exceed card SDI input capacity.
 - 9971-MV6-4K has a total capacity of six PiPs.
 - 9971-MV18-4K has a total capacity of 18 PiPs.



Figure 1-1 9971-MVx-4K Functional Block Diagram

Video Processing Description

The 9971-MVx-4K features input select and validity check functions, timing alignment, and PiP ARC/scaling functions as described below.

Input Video Select Function

Input video routing correlates the card inputs to PiP descriptors as desired. An Input Status display shows video format (e.g., "1920x1080i 59.94") and duration of the valid signal presence. If invalid or no input signal is present for a given input, the status shows "Unlocked".

Note: Model 9971-MV6-4H-4K has support for four HDMI inputs in addition to the base six SDI inputs (max).

ARC Processor/PIP Assignment

This function sets the layout/quantity of PiP images per screen, ranging from 0 (none) to *n* PiPs per screen (*n* being max supported PiPs by the card; 6 for model 9971-MV6-4K; *18* for model 9971-MV18-4K). In this manner, the base screen setup is provided where only the desired PiPs are displayed in the maximized available screen area.

Multi-Split ARC Scaler/Formatting Function

This function provides conversion of each PiP input to match a common user-selected format, resulting in images that are format-matched and suitable for combining into a single PiP image. When the PiP images are sized by this function, the borders and other accessory attributes are now integrated into each PiP image. In addition to full user control of PiP image H/V sizing, accessory attributes such as border size, weight, and color can be user configured.

Multiviewer Video Combiner/Formatting Function

This function combines the multiple video images into the user-configured positions within the overall image. At this point, all PiP images are of the same raster format and fully synchronous. User templates position the images as desired by the operator using the DashBoard controls.

Identity Text Burn-In/Formatting Function

This function provides user controls for entering UMD and user ident text that is burned into each PiP image. Controls allow full control of positioning, sizing, and color/background/opacity attributes. Burn-in text can be user entry text or external text sourced via IP from an automation system.

Tally Graphics Insert/Control

This function accommodates tally inputs (received as GPI, serial, or network commands) and allows configuring the commands to provide tally indications for each PiP image. All visual attributed are configurable, including "lamp" color, size, and positioning. Tally activation can also be controlled via IP from an automation system/router. UMD text can be inserted using local user text entry or integrated with router automation to receive text from the automation system.

Router Integration

Protocols (Router Integration) provides controls for integrating TSL router IP communication with 9971-MVx-4K to provide tally attribute control and TSL display address for the PiP images. Router functions such as UMD text sourcing from/using TSL protocol is also supported.

Background/Foreground Image Insertion

The 9971-MVx-4K provides full-screen raster insertion functions that provide a background template and also provide a foreground that can mask merged screen details not desired on the overall output, or provide fixed details (such as logo bugs) that are "burned into" the final image independent of PiP video content.

A Background image insertion resides behind the opaque PiPs (PiP video content and any borders, UMDs, Tallies, etc.) Background Image insertions can be full-size raster insertions, such as logo-based background template that remains fixed regardless of PiP positioning or sizing. A Foreground image resides on top of PiPs and background. The Foreground can serve as a mask where only certain PiPs or other details are visible in the final merged output view.

Per-PiP Audio PPM Meters

Each PiP image area has setup controls to provide audio meters in several formats (channel count) as desired. Each PiP image has an audio meter display that can display from 2-bar stereo up to all four embedded audio groups for the audio associated with a PiP input. User controls allow setting meter complement, position, size, and other graphic attributes.

Note: While per-PiP audio meters are supported, currently the 9971-MVx-4K models are not intended to provide pass-thru embedded audio content on either SDI or HDMI outputs. (It has been determined through user liaison that visual indication of audio presence/content type is significantly more practical than attempting aural assessment of multiviewer merged outputs and PiPs.)

User Control Interface

Figure 1-2 shows the user control interface options for the 9971-MVx-4K. These options are individually described below.

- **Note:** All user control interfaces described here are cross-compatible and can operate together as desired. Where applicable, any control setting change made using a particular user interface is reflected on any other connected interface.
 - DashBoard[™] User Interface Using DashBoard[™], the 9971-MVx-4K and other cards installed in openGear^{®1} frames can be controlled from a computer and monitor.

DashBoardTM allows users to view all frames on a network with control and monitoring for all populated slots inside a frame. This simplifies the setup and use of numerous modules in a large installation and offers the ability to centralize monitoring. Cards define their controllable parameters to DashBoardTM, so the control interface is always up to date.

The DashBoard[™] software can be downloaded from the Cobalt Digital Inc. website: <u>www.cobaltdigital.com</u> (enter "DashBoard" in the search window). The DashBoard[™] user interface is described in Chapter 3,"Setup Instructions".

 Cobalt[®] OGCP-9000 and OGCP-9000/CC Remote Control Panels – The OGCP-9000 and OGCP-9000/CC Remote Control Panels are not intended to be used for PiP sizing and other visual abstract configuration aspects. However, the control panel can be used as a convenient "one-button" control surface for launching non-abstract functions such as a user preset that invokes setups such as PiP splits and other presets.

^{1.} openGear® is a registered trademark of Ross Video Limited. DashBoard™ is a trademark of Ross Video Limited.



Figure 1-2 9971-MVx-4K User Control Interface

Note: If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt[®] reference guide **Remote Control** User Guide (PN 9000RCS-RM) provides thorough information and step-by-step instructions for setting up network remote control of Cobalt[®] cards using DashBoard[™]. (Cobalt[®] OGCP-9000 and OGCP-9000/CC Remote Control Panel product manuals have complete instructions for setting up remote control using a Remote Control Panel.)

Download a copy of this guide by clicking on the **Support>Reference Documents** link at www.cobaltdigital.com and then select DashBoard Remote Control Setup Guide as a download, or contact Cobalt[®] as listed in Contact Cobalt Digital Inc. (p. 1-15).

9971-MVx-4K Rear I/O Modules

The 9971-MVx-4K physically interfaces to system video connections at the rear of its frame using a Rear I/O Module. All inputs and outputs shown in the 9971-MVx-4K Functional Block Diagram (Figure 1-1) enter and exit the card via the card edge backplane connector. The Rear I/O Module breaks out the 9971-MVx-4K card edge connections to BNC and other connectors that interface with other components and systems in the signal chain.

The full assortment of 9971-MVx-4K Rear I/O Modules is shown and described in 9971-MVx-4K Rear I/O Modules (p. 2-4) in Chapter 2, "Installation and Setup".

Technical Specifications

Table 1-1 lists the technical specifications for the 9971-MVx-4K 12G/6G/3G/ HD/SD UHD Multiviewer card

Item	Characteristic
Part number, nomenclature	 9971-MV6-4K 12G/6G/3G/HD/SD UHD Multiviewer with Six SDI Inputs
	 9971-MV6-4H-4K 12G/6G/3G/HD/SD UHD Multiviewer with Six SDI Inputs and Four HDMI 2.0 Inputs
	9971-MV18-4K 12G/6G/3G/HD/SD 18-Input UHD Multiviewer
Installation/usage environment	Intended for installation and usage in frame meeting openGear™ modular system definition
Power consumption	< 35 Watts maximum
Installation Density	Up to 5 cards per 20-slot frame
Environmental: Operating temperature: Relative humidity (operating or storage):	32° – 104° F (0° – 40° C) < 95%, non-condensing
Frame communication	10/100/1000 Mbps Ethernet with Auto-MDIX
Indicators	Card edge display and indicators as follows:
	 4-character alphanumeric display
	Status/Error LED indicator
	Input Format LED indicator

Table 1-1 Technical Specifications

Item	Characteristic
Program Video Input	(9971-MV6-4K) Video Inputs: (6) 75Ω inputs (max)
	(9971-MV18-4K) Video Inputs: (18) 75Ω inputs (max)
	SDI Formats Supported:
	SMPTE ST2082-1, ST2082-10, 424M, 292M, SMPTE 259M-C. All inputs/outputs 12G compliant and SDQS/2SI quad 3G compliant.
	Receive Cable Length:
	60m Belden 1694A cable at 11.88 Gbps 120m Belden 1694A cable at 2.97 Gbps 240m Belden 1694A cable at 1.485 Gbps 400m Belden 1694A cable at 270 Mbps
	Return Loss:
	>15 dB up to 1.485 GHz
	>7 dB up to 6 GHz
	>5 dB up to 12 GHz
Serial Digital PiP Video Output	Number of Outputs:
	(8) 75Ω inputs (max)
	Signal Level:
	800 mV ± 10%
	DC Offset:
	0 V ± 50 mV
	Jitter (12G/6G/3G/HD/SD):
	< 0.3/0.3/0.2/0.2 UI
HDMI PiP Video Output	(2, max) HDMI 2.0 Output; type A standard connector
HDMI Inputs (model 9971-MV6-4H-4K only)	(4) HDMI 2.0; type C-mini connector
GPIO	GPI and GPO; opto-isolated
(GPIO functionality currently reserved)	GPO Specifications:
	Max I: 120 mA
	wax v: 30 v Max P: 120 mW
	GPI Specifications:
	GPI LO @ Vin < 1.5 V
	GPI HI @ Vin > 2.3 V
	Max Vin: 9 V

Table 1-1	Technical Specifications — continued
-----------	--------------------------------------

Warranty and Service Information

Cobalt Digital Inc. Limited Warranty

This product is warranted to be free from defects in material and workmanship for a period of five (5) years from the date of shipment to the original purchaser, except that 4000, 5000, 6000, 8000 series power supplies, and Dolby[®] modules (where applicable) are warranted to be free from defects in material and workmanship for a period of one (1) year.

Cobalt Digital Inc.'s ("Cobalt") sole obligation under this warranty shall be limited to, at its option, (i) the repair or (ii) replacement of the product, and the determination of whether a defect is covered under this limited warranty shall be made at the sole discretion of Cobalt.

This limited warranty applies only to the original end-purchaser of the product, and is not assignable or transferrable therefrom. This warranty is limited to defects in material and workmanship, and shall not apply to acts of God, accidents, or negligence on behalf of the purchaser, and shall be voided upon the misuse, abuse, alteration, or modification of the product. Only Cobalt authorized factory representatives are authorized to make repairs to the product, and any unauthorized attempt to repair this product shall immediately void the warranty. Please contact Cobalt Technical Support for more information.

To facilitate the resolution of warranty related issues, Cobalt recommends registering the product by completing and returning a product registration form. In the event of a warrantable defect, the purchaser shall notify Cobalt with a description of the problem, and Cobalt shall provide the purchaser with a Return Material Authorization ("RMA"). For return, defective products should be double boxed, and sufficiently protected, in the original packaging, or equivalent, and shipped to the Cobalt Factory Service Center, postage prepaid and insured for the purchase price. The purchaser should include the RMA number, description of the problem encountered, date purchased, name of dealer purchased from, and serial number with the shipment.

Cobalt Digital Inc. Factory Service Center

2506 Galen Drive	Office: (217) 344-1243
Champaign, IL 61821 USA	Fax: (217) 344-1245
www.cobaltdigital.com	Email: info@cobaltdigital.com

THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON COBALT'S PART. ANY SOFTWARE PROVIDED WITH, OR FOR USE WITH, THE PRODUCT IS PROVIDED "AS IS." THE BUYER OF THE PRODUCT ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE OR RELIED UPON WITH RESPECT TO THE QUALITY AND FUNCTION OF THE GOODS HEREIN SOLD. COBALT PRODUCTS ARE NOT AUTHORIZED FOR USE IN LIFE SUPPORT APPLICATIONS.

COBALT'S LIABILITY, WHETHER IN CONTRACT, TORT, WARRANTY, OR OTHERWISE, IS LIMITED TO THE REPAIR OR REPLACEMENT, AT ITS OPTION, OF ANY DEFECTIVE PRODUCT, AND SHALL IN NO EVENT INCLUDE SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS), EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Contact Cobalt Digital Inc.

Feel free to contact our thorough and professional support representatives for any of the following:

- Name and address of your local dealer
- Product information and pricing
- Technical support
- Upcoming trade show information

Phone:	(217) 344-1243
Fax:	(217) 344-1245
Web:	www.cobaltdigital.com
General Information:	info@cobaltdigital.com
Technical Support:	support@cobaltdigital.com

This page intentionally blank

Chapter 2

Installation

Overview

This chapter contains the following information:

- Installing the 9971-MVx-4K Into a Frame Slot (p. 2-1)
- Installing a Rear I/O Module (p. 2-3)
- Setting Up 9971-MVx-4K Network Remote Control (p. 2-6)

Installing the 9971-MVx-4K Into a Frame Slot

CAUTION

Heat and power distribution requirements within a frame may dictate specific slot placement of cards. Cards with many heat-producing components should be arranged to avoid areas of excess heat build-up, particularly in frames using only convection cooling. The 9971-MVx-4K has a moderate power dissipation (>30 W). As such, avoiding placing the card adjacent to other cards with similar dissipation values if possible.

CAUTION



Note: If installing the 9971-MVx-4K in a slot with no rear I/O module, a Rear I/O Module is required before cabling can be connected. Refer to Installing a Rear I/O Module (p. 2-3) for rear I/O module installation procedure.

CAUTION

If required, make certain Rear I/O Module(s) is installed before installing the 9971-MVx-4K into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.

Note: Check the packaging in which the 9971-MVx-4K was shipped for any extra items such as a Rear I/O Module connection label. In some cases, this label is shipped with the card and to be installed on the Rear I/O connector bank corresponding to the slot location of the card.

Install the 9971-MVx-4K into a frame slot as follows:

- 1. Determine the slot in which the 9971-MVx-4K is to be installed.
- 2. Open the frame front access panel.
- 3. While holding the card by the card edges, align the card such that the plastic ejector tab is on the bottom.
- 4. Align the card with the top and bottom guides of the slot in which the card is being installed.
- **5.** Gradually slide the card into the slot. When resistance is noticed, gently continue pushing the card until its rear printed circuit edge terminals engage fully into the rear I/O module mating connector.

CAUTION

If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.

- **6.** Verify that the card is fully engaged in rear I/O module mating connector.
- 7. Close the frame front access panel.
- 8. Connect the input and output cables as shown in 9971-MVx-4K Rear I/O Modules (p. 2-4).
- 9. Repeat steps 1 through 8 for other 9971-MVx-4K cards.
- **Note:** The 9971-MVx-4K BNC inputs are internally 75-ohm terminated. It is not necessary to terminate unused BNC inputs or outputs.
- **Note:** To remove a card, press down on the ejector tab to unseat the card from the rear I/O module mating connector. Evenly draw the card from its slot.
 - **10.** If network remote control is to be used for the frame and the frame has not yet been set up for remote control, perform setup in accordance with Setting Up 9971-MVx-4K Network Remote Control (p. 2-6).
- Note: If installing a card in a frame already equipped for, and connected to DashBoard[™], no network setup is required for the card. The card will be discovered by DashBoard[™] and be ready for use.

Installing a Rear I/O Module

Note: This procedure is applicable **only if a Rear I/O Module is not currently installed** in the slot where the 9971-MVx-4K is to be installed.

If installing the 9971-MVx-4K in a slot already equipped with a suitable I/O module, omit this procedure.

Install a Rear I/O Module as follows:

- 1. On the frame, determine the slot in which the 9971-MVx-4K is to be installed.
- 2. In the mounting area corresponding to the slot location, install Rear I/O Module as shown in Figure 2-1.



Figure 2-1 Rear I/O Module Installation

9971-MVx-4K Rear I/O Modules

Table 2-1 shows and describes the full assortment of Rear I/O Modules specifically for use with the 9971-MVx-4K.

Table 2-1 9971-MVx-4K Rear I/O Modules

9971-MVx-4K Rear I/O Module	Description
 Note: 6-input and 18-input Rear I/O Modules bel models, respectively. However, any Rear I 6-input Rear I/O Modules will not accome 9971-MV18-4K. On 18-input Rear I/O Modules when use coaxial inputs on 18-input Rear I/O Modules 	by are intended for use in 9971-MV6-4K or 9971-MV18-4K O Module can be used on either model noting the following: nodate the maximum available PiP inputs on d with 9971-MV6-4K, only IN 1 thru IN 6 of 18 available iles can be used to pass to the actual card inputs.
Note: All coaxial connections on Rear I/O Module	es below are HD-BNC.
Note: COMM/GPIO functionality is currently rese	rved.
RM20-9971-B-HDBNC SDIN 1 - *COM A, RX2 / 422(+) 2 - *COM A, RX2 / 422(+) 3 - @COM A, RX1 / 422(-) 3 - @COM A, RX1 / 422(-) 6 - *COM A, RX1 / 422(-) 6 - *COM A, RX1 / 422(-) 9 - GPI IN5 / GPO OUT 2 10 - GPI IN4 11 - @PI IN1 12 - GPI IN3 14 - NC 15 - NC * Port can be GUI-configured as two RS-232 ports (Tx and RX), or as a full-duplex RS-422 port. * HDMI ionupta seplicable to model-MV6-4H-4K only. HDMI contectors are mounted on card assembly and project through opening on rear module.	 Provides the following connections: SIx PiP SDI Video In (SDI IN 1 thru SDI IN 6) Eight SDI Out (4x2) (SDI 1A/1B thru SDI 4A/4B) HDMI IN 1 thru HDMI IN 4 (Model 9971-MV6-4H-4K only.) These inputs (HDMI type C mini) reside on the card assembly and project through a cutout on the rear module. The connectors are not part of the rear module assembly. The connectors are shown here for reference. HDMI OUT (type A standard connector) COMM/GPIO (HD-15 connector) ETHERNET 100/1000 Control Port Note: Ethernet connector is reserved for tally, UMD control, DashBoard Output Preview, and other functions. This port is independent of card/frame network remote control.

Installation



Table 2-1 9971-MVx-4K Rear I/O Modules — continued

Setting Up 9971-MVx-4K Network Remote Control

Perform remote control setup in accordance with Cobalt[®] reference guide "Remote Control User Guide" (PN 9000RCS-RM).

Note: If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt[®] reference guide **Remote** Control User Guide (PN 9000RCS-RM) provides thorough information and step-by-step instructions for setting up network remote control of Cobalt[®] cards using DashBoard[™]. (Cobalt[®] OGCP-9000 and/or OGCP-9000/CC Remote Control Panels are not recommended for use with this product.)

Download a copy of this guide by clicking on the **Support > Reference Documents** link at www.cobaltdigital.com and then select DashBoard Remote Control Setup Guide as a download, or contact Cobalt[®] as listed in Contact Cobalt Digital Inc. (p. 1-15).

- If installing a card in a frame already equipped for, and connected to DashBoard[™], no network setup is required for the card. The card will be discovered by DashBoard[™] and be ready for use.
- Cards using current firmware versions typically require DashBoard[™] version 6.0 or greater. This is due to the added user interface controls which can only be accommodated with DashBoard version 6.0 or greater. While cards with these firmware versions will appear in the frame Basic Tree View in earlier DashBoard versions, the card controls will not be accessible. For a free download of the latest DashBoard version, please go to www.cobaltdigital.com, and select Products > Software Control > DashBoard[™], and then select the version applicable to your computer.

Chapter 3

Setup Instructions

Overview

This chapter contains the following information:

If you are already familiar with using DashBoard to control Cobalt cards, please skip to Basic Setup Overview (p. 3-7).

- Control and Display Descriptions (p. 3-1)
- Accessing the 9971-MVx-4K Card via Remote Control (p. 3-4)
- Checking 9971-MVx-4K Card Information (p. 3-6)
- 9971-MVx-4K Function Menu List and Descriptions (p. 3-8)
- Troubleshooting (p. 3-37)

Control and Display Descriptions

This section describes the user interface controls, indicators, and displays for using the 9971-MVx-4K card.

Access to the 9971-MVx-4K functions (and the controls, indicators, and displays related to a particular function) follows a general arrangement of Function Menus under which related controls can be accessed (as described in Function Menu/Parameter Menu Overview below).

Note: When a setting is changed, settings displayed on DashBoard[™] are the settings as effected by the card itself and reported back to the remote control; the value displayed at any time is the actual value as set on the card.

Function Menu/Parameter Menu Overview

The functions and related parameters available on the 9971-MVx-4K card are organized into function **menus**, which consist of parameter groups as shown below.

Figure 3-1 shows how the 9971-MVx-4K card and its menus are organized, and also provides an overview of how navigation is performed between cards, function menus, and parameters.



Figure 3-1 Function Menu/Parameter Menu Overview

DashBoard[™] User Interface

(See Figure 3-2.) The card function menus are organized in DashBoardTM using tabs. When a tab is selected, each parametric control or selection list item associated with the function is displayed. Scalar (numeric) parametric values can then be adjusted as desired using the GUI slider controls. Items in a list can then be selected using GUI drop-down lists.



Figure 3-2 Typical DashBoard Tabs and Controls

Accessing the 9971-MVx-4K Card via Remote Control

Access the 9971-MVx-4K card using DashBoard[™] or Cobalt[®] Remote Control Panel as described below.

Accessing the 9971-MVx-4K Card Using DashBoard™

- 1. On the computer connected to the frame LAN, open DashBoardTM.
- **2.** As shown below, in the left side Basic View Tree locate the Network Controller Card associated with the frame containing the 9971-MVx-4K card to be accessed (in this example, "MFC-8320-N SN: 00108053").



3. As shown below, expand the tree to access the cards within the frame. Click on the card to be accessed (in this example, "Slot 6: 9971-MV18-4K").



As shown on the next page, when the card is accessed in DashBoardTM its function menu screen showing tabs for each function is displayed. (The particular menu screen displayed is the previously displayed screen from the last time the card was accessed by DashBoardTM).

Setup Instructions



Checking 9971-MVx-4K Card Information

The operating status and software version the 9971-MVx-4K card can be checked using DashBoardTM. Figure 3-3 shows and describes the 9971-MVx-4K card information screen using DashBoardTM.

Note: Proper operating status in DashBoard[™] is denoted by green icons for the status indicators shown in Figure 3-3. Yellow or red icons respectively indicate an alert or failure condition. Refer to Troubleshooting (p. 3-37) for corrective action.



Figure 3-3 9971-MVx-4K Card Info/Status Utility

Basic Setup Overview

Figure 3-4 describes the primary steps in setting up the card to have a desired multiviewer layout, accommodate the number of input channels (PiPs) needed, and route the merged Screen output(s) to the physical card SDI and/or HDMI outputs. Basically, these steps set the card to accommodate the desired number of input channel PiPs, and then provide an output multiviewer matrix with the desired layout; these steps will produce the desired PiP layout on the card output.

When the input PiP and layout aspects are set as desired, then other attributes such as tallies and audio bars can be added to the PiPs as described in detailed section 9971-MVx-4K Function Menu List and Descriptions (p. 3-8).



Figure 3-4 Basic Setup Overview

9971-MVx-4K Function Menu List and Descriptions

Table 3-1 individually lists and describes each 9971-MVx-4K function menu and its related list selections, controls, and parameters. Where helpful, examples showing usage of a function are also provided. Table 3-1 is primarily based upon using DashBoard[™] to access each function and its corresponding menus and parameters.

- Note: All numeric (scalar) parameters displayed on DashBoard[™] can be changed using the slider controls, () arrows, or by numeric keypad entry in the corresponding numeric field. (When using numeric keypad entry, add a return after the entry to commit the entry.)
- **Note:** Examples in this section use 9971-MV18-4K and may cite up to 18 available PiPs. The same controls appear on 9971-MV6-4K, but with support of a maximum of six PiPs on the card itself and related UI depictions. However, both models use the same tabs/pages as shown here.

On DashBoardTM itself and in Table 3-1, the function menu items are organized using tabs as shown below.



The table below provides a quick-reference to the page numbers where each function menu item can be found.

Function Menu Item	Page	Function Menu Item	Page
PIP Assignment	3-9	Output Video Routing Controls	3-32
Input Video Routing Controls	3-10	Protocols (TSL Integration) Controls	3-34
Screen Layout Controls	3-11	Presets	3-35
UMD/Tally Color/Text Source Controls	3-20	Network Settings Controls	3-36
Text Layout/Insertion Controls	3-21	Admin	3-37
Audio Meter Overlay Controls	3-29		

Table 3-1 9971-MVx-4K Function Menu List







Screen Layout	Provides controls for selecting PiP layout presets templates and output format of the merged screen output(s). Also provides controls for per-PiP manipulation such as PiP sizing and positioning.
Screen/PiP Ganging Controls	
Note: In this tab and others where applicable, a gase selected screen (or PiP) or to all screens (o	anging control and info message allows actions to be applied to only the r PiPs) as described below.
Modifying Selected Screen Only Modifying All Ena	bled Screens Clicking on the info message changes the action from Only Screen or Only PIP to ganged action of All Enabled Screens or All Enabled PIPs.
Modifying Selected PIP Only Modifying All E	This is convenient when attributes (such as tally setup or output format) is desired to be applied in a wholesale manner. In addition to changing the ganging rules, the info display also shows, at any time, whether changes are being applied on per-item or all items basis.
If not carefully considered, All settings can ap changes are desired before selecting All sett	oply attributes not desired for screens and/or PiPs. Make certain wholesale ings and applying changes.
Screen Select	(Option +DUAL only) Selects the Screen to be set up using the controls
Screen Select Screen 1 Screen 1 Screen 2 Screen 2	Note: This control can be set to gang both screens using the Screen/PiP Ganging Controls described above.
• PiP Select	Selects the PiP to be set up using the controls on this tab.
PIP Select PIP 1	Note: This control can be set to gang all PiPs using the Screen/PiP Ganging Controls described above.

Screen	Layout		(continued	3)	
Output Format S Output Format 1 1 3 3 1	elect 920×1080p 50 A 920×1080p 50 A 920×1080p 59.94 A 920×1080p 60 A 840×2160p 50 12G 840×2160p 60 12G 280×720p 50 280×720p 50 280×720p 60 920×1080i 50 920×1080i 59.94 920×1080i 60	Select up usi Note:	s the output fo ng the controls (Option +DUA using the Scre	ormat (from choices shown) for the Screen t ls on this tab. AL only) This control can be set to gang both een/PIP Ganging Controls described above.	o be set
• Template Preset Template 2x2 3x3 4x4 5x4 Appl	Select	Select applie are ex When image below Note:	s from the pre: d to the screer cample template e area within a (Option +DU , using the Sci • Make certain assigns enou • Although sor PiPs support graphic inser	eset symmetrical template grid choices show n(s). Click Apply Template when done. Sho ite layouts and example (default) PiP assign is applied, PiP positioning, sizing, and video PiP can be manipulated using controls desc JAL only) This control can be set to gang both creen/PiP Ganging Controls (p. 3-11). n PiP settings performed in PIP Assignment rugh PiPs to fill template grid selected. me layout choices exceed the number of pro- ted, these are reserved for support of clock a ertion support.	n to be wn below ments. program ribed n screens (p. 3-9) ggram and static
2 :	x 2		3 x 3		
PIP 1	PIP 2	PIP 1 PIP 4	PIP 2 PIP 5	PIP 3 PIP 6	
PIP 3	PIP 4	PIP 7	PIP 8	PIP 9	
4 x	x 4				
PIP 1 PIP 2	PIP 3 PIP 4				
PIP 5 PIP 6	PIP 7 PIP 8				
PIP 9 PIP 10	PIP 11 PIP 12				
PIP 13 PIP 14	PIP 15 PIP 16				

T	
i able 3-1	99/1-MVX-4K Function Menu List — continued















Screen Layout	(continued)
Video Position Controls	 Horizontal and Vertical Center controls shift the content video image within the individual PiP area left/right or up/down. Width and Height controls adjust the size of the content video image from its default size to a H/V size less than 100%. Note: Video position/size controls have no effect on the respective PiP size or position. Only the image within the selected PiP is modified.
Video Position	
Horizontal Center	50.00 50.00 50.00
Vertical Center	0.00 ÷
Width	50.00 100.00 82.50 C
Height 0.00	50.00 100.00
Border Width/Enable Controls	The Show Border Controls checkbox opens the Border width and other attributes controls.
	Border Width sets the border width (in pixels).
Show Border Controls	
PIP Border Enable	
PIP Border Width	

Screen Layout	(continued)
• Border User Color/Opacity Select	User Color select, when enabled, allows a border color to be asserted manually (versus asserted by tally automation). Color choices are shown here.
Transparent 90% Opaque	 Opacity selects border opacity from full opaque to transparent in various gradients.
PiP Border Color Source Select	Selects the PiP board color from choices of User Color (as manually set up using Border User Color/Opacity Select controls above), or using Tally automated border color as directed by Tally 1 thru Tally 4 direction.
Pip Border User Color Pip Border Color Source	Tally 1 Tally 2 Tally 3 Tally 4





UMD/Taliy	Provides controls to set UMD text and color sources from TSL protocol/tally, or to obtain from User Entry (Text Layout page).
Note: Unless changes here are to be applied to a and make certain Screen/PiP Ganging Cor 3-11) for info on setting controls for screen	III PiPs or screens, make certain the desired PiP is selected in PIP Select, ntrols is set to desired screen/PiP . See Screen/PiP Ganging Controls (p. /PiP only or wholesale ALL settings.
Screen Select	(Option +DUAL only) Selects the Screen to be set up using the controls on this tab.
Screen Select Screen 1 Screen 1 Screen 2	Note: This control can be set to gang both screens using the Screen/PiP Ganging Controls (p. 3-11).
PiP Select	Selects the PiP to be set up using the controls on this tab.
PIP Select PIP 1	Note: This control can be set to gang all PiPs using the Screen/PiP Ganging Controls (p. 3-11).
Enable Tally Icons	Enables insertion/use of standard tally "lamp" icon (rounded-corner
	square "lamp" icon).
Enable Tally Icons	other attributes. Enabling icons here is specifically tied to icon graphic insertion.
UMD Text Source Select UMD Text Source User Entry (see Text Layout Tab) TSL Protocol	Selects UMD text source from TSL Protocol automation, or sets UMD to use static user-entered text in conjunction with Text Layout tab/page (p. 3-21).
• UMD Color Source Select	For text, outlines, and background colors, individually allows color source to be selected from Tally sources, or use static user-entered color choices in conjunction with Text Layout tab/page (p. 3-21). The Tally 1 thru Tally 4 choices allow prioritization of TSL tally number items to assert over lower numbers (example: If Tally 1 is active over Tally 2, attributes/actions associated with Tally 1 are asserted).
UMD Color Sources Text Layout Tab	Tally 1 Tally 1 Tally 2 Tally 3 Tally 4
UMD Text Color Source	
UMD Background Color Source	

Text Layout Screen Text Pip Text	Provides controls and dialog for screen text entry and positioning.	
 Note: This tab has sub-tabs for Screen Text and PiP Text. Screen Text is user text which is "burned" across the entire multiviewer merged screen, with no regard for underlaying PiP. PiP Text is user text which is "burned" into specified PiP(s) and is entirely contained within a PiP. 		
• Screen Select Screen Select Screen 1 Screen 2	(Option +DUAL only) Selects the Screen to be set up using the controls on this tab. Note: This control can be set to gang both screens using the Screen/PiP Ganging Controls (p. 3-11).	
Screen Text Entry Field User Text This is some test text. ABCDEFG	 Dialog entry box that allows entry of desired ident text string. Note: • All normal keyboard alphanumeric characters are supported. Not all ASCII special characters (Windows ALT+<i>nnnn</i>) are supported. • Up to 126 characters can be entered. 	
Font Selection Font Load Status Font selection is disabled in Admin tab. Fonts loaded. An error occurred while loading fonts. All text is	Depending on whether or not Load User Fonts is selected in the Admin tab, a corresponding message in Font Load Status is displayed.	

Text Layout Screen Text Pip Text	(continued)
Position Mode Select	Sets the base location and anchoring of screen text insertions.
	Automatic is default basic positioning.
Position Mode Automatic ~	 Fixed allows full custom positioning using Fixed Text Position and Size controls (see below).
Anchor Fixed	• Anchor allows text positioning anchored to a starting position. The Text Box Anchor Point controls are exposed when Anchor is selected.
Text Box Anchor Point	
Horizontal Center Left Center Right	
Vertical Middle Top Middle Bottom	

Text Layout Screen Text Pip Text	(continued)		
Fixed Text Position/Size Controls	 When Fixed mode is selected above, these controls allow positioning and sizing as described. Left and Top controls move the PiP from its default origin position. Width and Height controls adjust the size of the overall text insertion. 		
Fixed Text Position and Size Left U U U U U U U U U U U U U U U U U U U	50.00 100.00		
Width U U U U U U U U U U U U U U U U U U U	50.00 100.00 50.00 100.00 20.00		
0.00	Preight 20.00 0.00 50.00 Origin (0,0) x= 100%		
Border Width/Enable Controls The Show Border Controls checkbox opens the Border width and other attributes controls			
Show Border Controls	Outline Width sets the border width (in pixels).		
Outline Width	4 7 10 2 C		

Text Layout Screen Text Pip Text	(continued)
• Border User Color/Opacity Select Text Blue Cyan Gray 25% Gray 50% Gray 75% Green Lime Color Black V	Color/Opacity controls for Text , Outline , and Background are as follows: • Color select provides choices as shown here.
Text Transparent 90% Opaque Opacity Opaque	 Opacity select provides opacity from full opaque to transparent in various gradients.
Text Justification/Alignment Select Show Text Controls Text Justification	The Show Text Controls checkbox opens the Text controls, which sets the positioning and justification of screen text as follows:
Horizontal Center Left Center Right	• Horizontal choices Left, Center, and Right align the text either with left, center, or right margin and justification.
Vertical Middle Top Middle Bottom Vertical Middle Midd	 Vertical choices Top, Middle, and Bottom align the text either positioned near top, middle, or bottom of image area.

Table 3-1	9971-MVx-4K Function Menu List — continued

Text Layout Screen Text Pip Text	Provides controls for selecting text source to be applied in selected PiPs and applying PiP text.
Screen Select Screen 1 Screen 1 Screen 2	(Option +DUAL only) Selects the Screen to be set up using the controls on this tab. Note: This control can be set to gang both screens using the Screen/PiP Ganging Controls (p. 3-11).
• PiP Select PIP Select PIP 1 PIP 2 • • • • • • •	Selects the PiP to be set up using the controls on this tab. Note: This control can be set to gang all PiPs using the Screen/PiP Ganging Controls (p. 3-11).
• PiP Text Box Enable/Select Enable Text Box Ident 1 UMD Ident 1 Ident 2	Enable opens PiP text tool dialog and controls. For selected PiP(s), Text Box sets PiP to use and display the selected text source from choices shown.
PiP Text Entry Field User Text This is some test text. ABCDEFG	 Dialog entry box that allows entry of desired ident text string. Note: • All normal keyboard alphanumeric characters are supported. Not all ASCII special characters (Windows ALT+<i>nnnn</i>) are supported. • Up to 126 characters can be entered. • If UMD Text Source in UMD/Tally Color/Text Source Controls (p. 3-20) is set to TSL Protocol, Text Entry field is not available, and Text Source "See UMD/Tally Tab" message appears. To enter user text here, text source must be set to User Entry.

Text Layout Screen Text Pip Text	(continued)
Position Mode Select Position Mode Automatic Automatic Anchor Fixed	 Sets the base location and anchoring of screen text insertions. Automatic is default basic positioning. Fixed allows full custom positioning using Fixed Text Position and Size controls (see below). Anchor allows text positioning anchored to a starting position. The Text Box Anchor Point controls are exposed when Anchor is selected.
Text Box Anchor Point Horizontal Left Center Right Vertical Middle Bottom	
Fixed Text Position/Size Controls	 When Fixed mode is selected above, these controls allow positioning and sizing as described. Left and Top controls move the PiP from its default origin position. Width and Height controls adjust the size of the overall text insertion.
Fixed Text Position and Size	
0.00	50.00 100.00 C
Top	50.00 100.00 C
Width	50.00 100.00 20.00 C
Height	50.00 100.00 20.00 C
	Origin (0,0)

Text Layout Screen Text Pip Text	(continued)
Border Width/Enable Controls	The Show Border Controls checkbox opens the Border width and other attributes controls. • Outline Width sets the border width (in pixels).
Show Border Controls Outline Width I I I I 4	1 1 2 2 7 10
• Border User Color/Opacity Select Text Blue Cyan Gray 25% Gray 50% Gray 75% Green Lime Color Black V	Color/Opacity controls for Text , Outline , and Background are as follows: • Color select provides choices as shown here.
Text - Transparent 90% Opaque Opacity Opaque	• Opacity select provides opacity from full opaque to transparent in various gradients.

Text Layout Screen Text Pip Text	(continued)	
Text Justification/Alignment Select Show Text Controls Text Justification	The Show Text Controls checkbox opens the Text controls, which sets the positioning and justification of screen text as follows:	
Horizontal Center Left Center Right	• Horizontal choices Left, Center, and Right align the text either with left, center, or right margin and justification.	
Vertical Middle Vertical Top Air Middle Bottom Vertical V	• Vertical choices Top , Middle , and Bottom align the text either positioned near top, middle, or bottom of image area.	
Font Selection Font Load Status Fonts loaded. An error occurred while loading fonts. All text is	Depending on whether or not Load User Fonts is selected in the Admin tab, a corresponding message in Font Load Status is displayed.	

 Table 3-1
 9971-MVx-4K Function Menu List — continued





Table 3-1 9971-MVx-4K Function Menu List — continued



Output Video Routing		Provides co output(s) to Outputs su to the four s desired.	ontrols to route r SDI and HDMI ub-tab routes mu SDI output ports	output ports. Itiviewer merged output(s) and two HDMI ports as
➤ tions below may sh DUAL, which allow nly Screen 1 selec	now Screen 1 a /s the card to si tions.	ind Screen 2 controls. Support two independent	Screen 2 controls ap screen outputs. If n	pear only when licensed with ot optioned with +DUAL, the UI
Status Controls				_
Source		Status	Output Enabled	
Screen 1		1920x1080p 59.94 A	\checkmark	
Screen 1		1920x1080p 59.94 A	\checkmark	
	v	Output Disabled		
Screen 1				
Screen 1 Screen 1	· •	Output Disabled		
Screen 1 Screen 1 Source		Output Disabled	Output Enabled	
Screen 1 Screen 1 Source Screen 1		Output Disabled Status Output Disabled	Output Enabled	
	HDMI OUT 1 Setu Tions below may sh DUAL, which allow inly Screen 1 select Status Controls Source Screen 1 Screen 1	HDMI OUT 1 Setup HDMI	HDMI OUT 1 Setup HDMI desired. desired. desired. ions below may show Screen 1 and Screen 2 controls. S DUAL, which allows the card to support two independent inly Screen 1 selections. Status Controls Screen 1 1920x1080p 59.94 A Screen 1 1920x1080p 59.94 A	HDMI OUT 1 Setup HDMI desired. ions below may show Screen 1 and Screen 2 controls. Screen 2 controls ap DUAL, which allows the card to support two independent screen outputs. If no nly Screen 1 selections. Status Controls Screen 1 1920x1080p 59.94 A Screen 1 1920x1080p 59.94 A



Output Video Routing HDMI OUT 1 Setup HD	HDMI OUT 1 Setup and HDMI OUT 2 sub-tabs independently route multiviewer merged output(s) provide individual setup parameters to the two (m HDMI output ports as desired.	
Note: HDMI OUT subtabs have identical independ sub-tabs. Therefore, only the HDMI OUT 1	dent controls for both HDMI O controls are shown here.	UT 1 and HDMI OUT 2 using the respective
HDMI Setup Controls		
	Color Space	YCbCr 4:2:2
Basic HDMI package setup controls	Colorimetry	BT.709 ¥
	Bit Depth	10 ~
	Range	Legal
	Audio Channel Count	2 ~
	HDR InfoFrame Insertion	Auto (HDR Only) Enabled Disabled
HDR coding setup controls	HDR InfoFrame OETF	Auto
	HDR InfoFrame Gamut	BT.2020
	Red x[2]	0.70800
	Red y[2]	0.29200
	Green x[0]	0.17000
Colorimetry/Luminanance setup controls	Green y[0]	0.79700
	Blue x[1]	0.13100
	Display Mastering	0.00050
	Luminance Min Display Mastering	1000
	Luminance Max Content Light	1000
	Level Max (MaxCLL) Frame Average Light	400
	Level Max (MaxFALL)	
	Note: Although Audio Cl this card is not specified Control may not be func	nannei Count select control may be present, for embedded audio processing/pass-thru. stional.

Protocols	Pro co att im	ovides controls mmunication w ribute control a ages.	o for integrating TSI vith 9971-MVx-4K t and TSL display ad	L router IP o provide tally dress for the PiP
Option ⊡ Note: UI depictions below may show Screen 1 ar only when licensed with option +DUAL, wh optioned with +DUAL, the Screen 2 control	nd Screen iich allows is/selection	2 (Screen 1 and 5 the card to suppo ns are not ackowle	Screen 2) controls Scr rt two independent scre dged and therefore car	een 2 controls appear en outputs. If not i be ignored.
 Note: • Router address must be accessible to net Network Settings Controls (p. 3-36)). • When router access (fetch) is enabled, co manual control locked out. 	work used	for 9971-MVx-4K ertain burn-in aspe	rear module Ethernet p cts is asserted by route	ort (as set using the card r control, with user
Tally Setup Controls				
TSL setup controls. Sets the card to communicate with TSL	Γ	TSL Protocol	Disabled O Enable	ed
Tally attribute setup controls. Sets non-tally appearance and choices of color/ opacity when Tally-ON condition occurs. Tally-to-PiP addressing setup. Sets addressing for tally for each of the individual available PiPs.		Status Port Number Tally Off Color Tally 1 On Color Tally 2 On Color Tally 3 On Color Tally 4 On Color Tally 0pacity Output 1 PIP 1 Output 1 PIP 2 Output 1 PIP 3	Gray 50% Red Green Yellow Blue 75% TSL Display	5005
		Output 2 PIP 17		34 🗇

Table 3-1 9971-MVx-4K Function Menu List — continued Allows user control settings to be saved in a one-button Preset and then loaded (recalled) as desired, and ^Dresets provides a one-button restore of factory default settings. Preset Save / Select / Load Controls Input Routing Output Routing Pip Assignment Protocols Screen 1 Screen 2 Screen 2 Preset Lavers allows selecting a Save Preset Layers functional layer (or "area of concern") 1 \checkmark \checkmark \checkmark that the preset is concerned with. Limiting presets to a layer or area of concern allows for highly specific presets, and masks changing card settings in areas outside of the layer or area of concern. **Restore Factory Defaults** • Pressing Save Preset opens field for entering user-defined Preset Name for the preset being saved (in this example, "Profile 1A"). Up to 128 individual presets can be saved. Preset Name Profile 1A Preset 1:Profile 1A • Load Selected Preset button allows loading (recalling) the Load Preset selected preset. When this button is pressed, the changes called out in the preset are immediately applied. Modify Preset · Clear Preset button deletes the currently selected preset. · Modify Preset button allows currently-selected preset to take in current changed settings and nest the changes in the Save Preset selected preset. Restore Factory Defaults button allows loading (recalling) Clear Preset the factory default preset. When this button is pressed, the changes called out in the preset are immediately applied. Cancel • **Download** saves all individual presets to a .bin file to be downloaded to a connected computer. Save Download presets.bin • Preset: drop-down allows a preset saved above to be Preset selected to be loaded, modified or cleared. Profile 1A (In this example, custom preset "1: Profile 1A" can be selected and then loaded, modified, or cleared by pressing the respective button.) 128 : (Empty) Upload (open) card Download (save) card presets to a network presets from a computer by clicking Download Presets network Save at the bottom of the Presets page. Refresh Upload Reboot computer by clicking Download Presets StoredPresets.bin Sa Upload at the bottom of DashBoard. Browse to a desired Save In: 🔁 My Document V 🝺 🌦 💷 🖽 save location (in .ook in: 📁 Cobalt Preset 🝺 📩 📮 🔚 😫 this example, My Browse to the 📁 Cobalt Preset: Documents\Cobalt location Presets). where the file was RCVR 21 Presets.bi RCVR21 Presets.b File Name File Name saved The file can then be Files of Type: BIN Files (*.bin) BIN Files (*.bin) renamed if desired on the computer or drive (in this (RCVR21 Presets Save Cancel Open Cancel example, Mv in this example) Documents\Cobalt Presets). Select the desired file and before committing the save. click Open to load the file to the card. Note: • Preset transfer between card download and file upload is on a group basis (i.e., individual presets cannot be downloaded or uploaded separately).

• After uploading a presets file, engagement of a desired preset is only assured by selecting and loading a desired preset as described above.

Network Settings	The Network Settings tab provides a dedicated Ethernet connection to card control and monitoring via a rear module Ethernet port. (This IP interface is entirely independent and separate from the card's DashBoard frame-based remote control/monitoring interface.)
Opening Fields for Editing Modify Network Settings Apply Cancel	 Modify Network Settings button opens dialog field for setting network parameters. Apply button commits and applies the settings. Cancel button exits dialog with no changes committed.
Card IP Physical Port Select Control Ethernet Connection Rear IO Module Frame	 Allows card dedicated IP interface (as set below) to use frame communications or dedicated rear I/O module Ethernet RJ-45 port. Note: • Frame net connection allows cards with per-card Ethernet connection to connect with network via a shared frame Ethernet port instead of per-card dedicated Ethernet connectors on the card's rear module. Frame net connection is available only on certain frame models. • Card slot must be fitted with a rear I/O module equipped with an Ethernet connector in order to use Rear I/O selection.
Card IP Setup Controls Address Mode DHCP Static IP Address 192.168.2.10 Subnet Mask 255.255.255.0 Default Gateway 192.168.2.1 DNS Server 192.168.2.12	 Provides controls for setting up card dedicated IP interface. Addressing Mode selsects either DHCP or static. Where Static is selected, standard IP fields allow entry of Address, Subnet Mask, and Default Gateway. Where DHCP is selected, DNS Server address field is provided.
NTP Clock Setup NTP Source Frame Network Card pool.rtp.org Specify IP Address NTP Server 192.168.2.16	 Allows device NTP clock IP source and localization. This is the clock/time device will use for logs and other recorded actions. NTP Source buttons allow selecting the network source that will provide NTP time. NTP Server sets the IP address where NTP is to be obtained when "Specify IP Address" is checked.
Card Active IP Address Display Active IP Address 10.99.11.142	Shows the connected (active) IP address the card is using (as set up using the controls described above).

 Table 3-1
 9971-MVx-4K Function Menu List — continued

Admin	Shows card serial number and enables user font download.
Admin User Character (Font) Load Serial Number 446968	Load User Fonts allows the download of characters specifically tailored to a particular user language of the user's choice (this functionality is incrementally being introduced and may not be functional of earlier card firmware releases).
Load User Fonts 🔽	Note: User characters (font), when loaded and enabled, only appear in user-accessible custom text such as user screen/PiP text, UMD text, and other user-entered text. The DashBoard UI labeling of controls uses the standard Latin-Roman character set as shown in this manual.

Troubleshooting

This section provides general troubleshooting information and specific symptom/corrective action for the 9971-MVx-4K card and its remote control interface. The 9971-MVx-4K card requires no periodic maintenance in its normal operation; if any error indication (as described in this section) occurs, use this section to correct the condition.

Error and Failure Indicator Overview

The 9971-MVx-4K card itself and its remote control systems all (to varying degrees) provide error and failure indications. Depending on how the 9971-MVx-4K card is being used (i.e, standalone or network controlled through DashBoardTM or a Remote Control Panel), check all available indications in the event of an error or failure condition.

The various 9971-MVx-4K card and remote control error and failure indicators are individually described below.

- **Note:** The descriptions below provide general information for the various status and error indicators. For specific failures, also use the appropriate subsection listed below.
 - Basic Troubleshooting Checks (p. 3-39)
 - Troubleshooting Network/Remote Control Errors (p. 3-40)
 - In Case of Problems (p. 3-40)

DashBoard[™] Status/Error Indicators and Displays

Figure 3-5 shows and describes the DashBoard[™] status indicators and displays. These indicator icons and displays show status and error conditions relating to the 9971-MVx-4K card itself and remote (network) communications.



Figure 3-5 DashBoard™ Status Indicator Icons and Displays

Basic Troubleshooting Checks

Failures of a general nature (affecting many cards and/or functions simultaneously), or gross inoperability errors are best addressed first by performing basic checks before proceeding further. Table 3-2 provides basic system checks that typically locate the source of most general problems. If required and applicable, perform further troubleshooting in accordance with the other troubleshooting tables in this section.

ltem	Checks
Verify power presence and characteristics	• On both the frame Network Controller Card and the 9971-MVx-4K, in all cases when power is being properly supplied there is always at least one indicator illuminated. Any card showing no illuminated indicators should be cause for concern.
	 Check the Power Consumed indication for the 9971-MVx-4K card. This can be observed using the DashBoard[™] Card Info pane.
	 If display shows no power being consumed, either the frame power supply, connections, or the 9971-MVx-4K card itself is defective.
	 If display shows excessive power being consumed (see Technical Specifications (p. 1-15) in Chapter 1, "Introduction"), the 9971-MVx-4K card may be defective.
Check Cable connection secureness and connecting points	Make certain all cable connections are fully secure (including coaxial cable attachment to cable ferrules on coaxial connectors). Also, make certain all connecting points are as intended. Make certain the selected connecting points correlate to the intended card inputs and/or outputs. Cabling mistakes are especially easy to make when working with large I/O modules.
Card seating within slots	Make certain all cards are properly seated within its frame slot. (It is best to assure proper seating by ejecting the card and reseating it again.)
Check status indicators and displays	On both DashBoard [™] and the 9971-MVx-4K card edge indicators, red indications signify an error condition. If a status indicator signifies an error, proceed to the following tables in this section for further action.
Troubleshoot by substitution	All cards within the frame can be hot-swapped, replacing a suspect card or module with a known-good item.

Table 3-2 Basic Troubleshooting Checks

Troubleshooting Network/Remote Control Errors

Refer to Cobalt[®] reference guide "Remote Control User Guide" (PN 9000RCS-RM) for network/remote control troubleshooting information.

In Case of Problems

Contact and Return Authorization

Should any problem arise with this product that was not solved by the information in this section, please contact the Cobalt Digital Inc. Technical Support Department.

If required, a Return Material Authorization number (RMA) will be issued to you, as well as specific shipping instructions. If required, a temporary replacement item will be made available at a nominal charge. Any shipping costs incurred are the customer's responsibility. All products shipped to you from Cobalt Digital Inc. will be shipped collect.

The Cobalt Digital Inc. Technical Support Department will continue to provide advice on any product manufactured by Cobalt Digital Inc., beyond the warranty period without charge, for the life of the product.

See Contact Cobalt Digital Inc. (p. 1-21) in Chapter 1, "Introduction" for contact information.

Cobalt Digital Inc.



2506 Galen Drive Champaign, IL 61821 Voice 217.344.1243 • Fax 217.344.1245 www.cobaltdigital.com