COBALT®

Engineering
Release
Notes

You can update your device by downloading the new Update software by going to the **Support>Firmware** link at www.cobaltdigital.com. Download "Firmware Update Guide", which provides simple instructions for downloading the latest firmware for your device onto your computer, and then uploading it to your device through DashBoard™.

Software updates are field-installed without any need to remove card from its frame.

The table below lists released software versions and describes the corresponding functions additions, improvements and/or corrections.

Software Version (Date)	Description
Rev 2.22 (5/27/2021 – present)	**Corrections:** • Corrects condition where, when fitted with any 9904-UDX model card, the hosted card could fall out of DashBoard, thereby corrupting remote control/monitoring for the hosted card. **Note:** This error did not affect power to the hosted card or any card signal processing in effect
Rev 2.21 and earlier	• Initial release