



Cobalt Digital Inc.

2406 E. University Ave.
Urbana, IL 61802
Voice 217.344.1243 • Fax 217.344.1245
www.cobaltdigital.com

Engineering Release Notes

You can update your card by downloading the new Update software by going to the **Support>Firmware** link at www.cobaltdigital.com. Download "Firmware Update Guide", which provides simple instructions for downloading the latest firmware for your card onto your computer, and then uploading it to your card through Dashboard™.

Software updates are field-installed without any need to remove the card from its frame.

The table below lists released software versions and describes the corresponding functions additions, improvements and/or corrections.

Software Version (Date)	Description
Rev 1.0.5 (6/2/2014 – present)	Corrections: <ul style="list-style-type: none">• Fixes inconsistency in Dashboard nomenclature for inputs to change from "In 1" thru "In 4" to "In A" thru "In D" to match rear module labeling. Fixes other minor Dashboard text issues.• Fixes rear module model detection to detect and display all currently available rear modules. Note: Rear module PN displayed in the Cobalt mfg PN and not the PN listed in marketing and manual materials.
Rev 1.0.3 (4/2014 – 6/2/2014)	<ul style="list-style-type: none">• Initial releases