

You can update your card by downloading the new Update software by going to the **Support>Firmware** link at [www.cobaltdigital.com](http://www.cobaltdigital.com). Download "Firmware Update Guide", which provides simple instructions for downloading the latest firmware for your card onto your computer, and then uploading it to your card through Dashboard™.

**Software updates are field-installed without any need to remove the card from its frame.**

The table below lists released software versions and describes the corresponding functions additions, improvements and/or corrections.

<b>Software Version (Date)</b>	<b>Description</b>
Rev 2.067 (8/14/2018 – present) All 9978-ANC-MON models All BBG-1078-ANC-MON models	<b>Improvements:</b> <ul style="list-style-type: none"><li>• Reduces internal messages written to device system logs. This improves log access in the case engineering support using and viewing logs is ever required.</li></ul>
Rev 2.065 (8/7/2018 – 8/14/2018) All 9978-ANC-MON models All BBG-1078-ANC-MON models	<ul style="list-style-type: none"><li>• Initial general release</li></ul>