


---

COBALT<sup>®</sup>

**9932-EMDE**



**3G/HD/SD-SDI 16-Channel Embedder/De-Embedder  
with Audio/Video Processing and CVBS I/O**

# ***Product Manual***

---

COBALT<sup>®</sup>

**Cobalt Digital Inc.**

2506 Galen Drive  
Champaign, IL 61821  
Voice 217.344.1243 • Fax 217.344.1245  
[www.cobaltdigital.com](http://www.cobaltdigital.com)

---

## Copyright

©Copyright 2017, Cobalt Digital Inc. All Rights Reserved.

Duplication or distribution of this manual and any information contained within is strictly prohibited without the express written permission of Cobalt Digital Inc. This manual and any information contained within, may not be reproduced, distributed, or transmitted in any form, or by any means, for any purpose, without the express written permission of Cobalt Digital Inc. Reproduction or reverse engineering of software used in this device is prohibited.

## Disclaimer

The information in this document has been carefully examined and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Cobalt Digital Inc. reserves the right to make changes to any products herein to improve readability, function, or design. Cobalt Digital Inc. does not assume any liability arising out of the application or use of any product or circuit described herein.

## Trademark Information

**Cobalt**<sup>®</sup> is a registered trademark of Cobalt Digital Inc.

**openGear**<sup>®</sup> is a registered trademark of Ross Video Limited. **DashBoard**<sup>™</sup> is a trademark of Ross Video Limited.

**Dolby**<sup>®</sup> is a registered trademark of Dolby Laboratories, Inc. Other product names or trademarks appearing in this manual are the property of their respective owners.

Congratulations on choosing the Cobalt<sup>®</sup> 9932-EMDE 3G/HD/SD-SDI 16- Channel Embedder / De-Embedder with Audio/Video Processing and CVBS I/O. The 9932-EMDE is part of a full line of modular processing and conversion gear for broadcast TV environments. The Cobalt Digital Inc. line includes video decoders and encoders, audio embedders and de-embedders, distribution amplifiers, format converters, remote control systems and much more. Should you have questions pertaining to the installation or operation of your 9932-EMDE, please contact us at the contact information on the front cover.

<b>Manual No.:</b>	9932EMDE-OM
<b>Document Version:</b>	V1.6
<b>Release Date:</b>	March 27, 2017
<b>Applicable for Firmware Version (or greater):</b>	V1.235 or greater
<b>Description of product/manual changes:</b>	- Previous manual showed Closed Captioning, Video Proc, and COM Routing tabs, which are not present on this product (Video Proc/Color Corrector is available only as an option). These tab/control descriptions are removed from this manual.

# Table of Contents

---

<b>Chapter 1</b>	<b>Introduction .....</b>	<b>1-1</b>
	Overview .....	1-1
	9932-EMDE Card Software Versions and this Manual .....	1-2
	Cobalt Reference Guides .....	1-2
	Manual Conventions.....	1-3
	Warnings, Cautions, and Notes .....	1-4
	Labeling Symbol Definitions.....	1-4
	Safety and Regulatory Summary .....	1-5
	Warnings.....	1-5
	Cautions .....	1-5
	EMC Compliance Per Market .....	1-5
	9932-EMDE Functional Description.....	1-6
	9932-EMDE Input/Output Formats.....	1-6
	Video Processor Description .....	1-8
	Audio Processor Description .....	1-13
	Control and Data Input/Output Interfaces .....	1-17
	Alarm Function.....	1-18
	User Control Interface .....	1-19
	9932-EMDE Rear I/O Modules.....	1-21
	Technical Specifications.....	1-21
	Warranty and Service Information .....	1-24
	Cobalt Digital Inc. Limited Warranty.....	1-24
	Contact Cobalt Digital Inc.....	1-25
<b>Chapter 2</b>	<b>Installation and Setup .....</b>	<b>2-1</b>
	Overview .....	2-1
	Installing the 9932-EMDE Into a Frame Slot.....	2-1
	Installing a Rear I/O Module .....	2-3
	9932-EMDE Rear I/O Modules.....	2-4
	GPIO and Analog Audio Connections .....	2-9
	Setting Up 9932-EMDE Network Remote Control.....	2-9
<b>Chapter 3</b>	<b>Operating Instructions.....</b>	<b>3-1</b>
	Overview .....	3-1

---

Control and Display Descriptions .....	3-1
Function Menu/Parameter Overview .....	3-2
DashBoard™ User Interface .....	3-3
Cobalt® Remote Control Panel User Interfaces .....	3-4
Web HTML5 User Interface .....	3-5
Accessing the 9932-EMDE Card via Remote Control.....	3-6
Accessing the 9932-EMDE Card Using DashBoard™.....	3-6
Accessing the 9932-EMDE Card Using a Cobalt® Remote Control Panel.....	3-7
Checking 9932-EMDE Card Information .....	3-8
Ancillary Data Line Number Locations and Ranges .....	3-9
9932-EMDE Function Menu List and Descriptions .....	3-10
Input Video Controls .....	3-11
Output Video Mode Controls .....	3-12
Framesync .....	3-13
Input Audio Status .....	3-16
Input Audio Routing/Controls .....	3-17
Video Quality Events .....	3-22
Audio Detect Events Setup Controls .....	3-23
Video Proc/Color Correction .....	3-24
Output Audio Routing/Controls .....	3-27
Text-To-Speech Setup Controls .....	3-31
Timecode .....	3-32
Wings Insertion .....	3-37
Keyer .....	3-38
Ancillary Data Proc Controls .....	3-41
Presets .....	3-43
GPO Setup Controls .....	3-44
Event Setup Controls .....	3-45
Admin (Log Status/Firmware Update - Card IP Address) .....	3-49
User Log .....	3-51
Alarms Setup Controls .....	3-52
Troubleshooting .....	3-56
Error and Failure Indicator Overview .....	3-56
Basic Troubleshooting Checks.....	3-60
9932-EMDE Processing Error Troubleshooting.....	3-61
Troubleshooting Network/Remote Control Errors.....	3-62
In Case of Problems .....	3-62

---

# Introduction

## Overview

This manual provides installation and operating instructions for the 9932-EMDE 3G/HD/SD-SDI 16- Channel Embedder / De-Embedder with Audio/Video Processing and CVBS I/O card (also referred to herein as the 9932-EMDE).

**This manual** consists of the following chapters:

- **Chapter 1, “Introduction”** – Provides information about this manual and what is covered. Also provides general information regarding the 9932-EMDE.
- **Chapter 2, “Installation and Setup”** – Provides instructions for installing the 9932-EMDE in a frame, and optionally installing a 9932-EMDE Rear I/O Module.
- **Chapter 3, “Operating Instructions”** – Provides overviews of operating controls and instructions for using the 9932-EMDE.

**This chapter** contains the following information:

- **9932-EMDE Card Software Versions and this Manual (p. 1-2)**
- **Manual Conventions (p. 1-3)**
- **Safety and Regulatory Summary (p. 1-5)**
- **9932-EMDE Functional Description (p. 1-6)**
- **Technical Specifications (p. 1-21)**
- **Warranty and Service Information (p. 1-24)**
- **Contact Cobalt Digital Inc. (p. 1-25)**

## 9932-EMDE Card Software Versions and this Manual

When applicable, Cobalt Digital Inc. provides for continual product enhancements through software updates. As such, functions described in this manual may pertain specifically to cards loaded with a particular software build.

The Software Version of your card can be checked by viewing the **Card Info** menu in DashBoard™. See Checking 9932-EMDE Card Information (p. 3-8) in Chapter 3, “Operating Instructions” for more information. You can then check our website for the latest software version currently released for the card as described below.

**Note:** Not all functionality described in this manual may appear on cards with initial software versions.

Check our website and proceed as follows if your card’s software does not match the latest version:

Card Software <b>earlier</b> than latest version	<p>Card is not loaded with the latest software. Not all functions and/or specified performance described in this manual may be available.</p> <p>You can update your card with new Update software by going to the <b>Support&gt;Firmware Downloads</b> link at <a href="http://www.cobaltdigital.com">www.cobaltdigital.com</a>. Download “Firmware Update Guide”, which provides simple instructions for downloading the latest firmware for your card onto your computer, and then uploading it to your card through DashBoard™.</p> <p><b>Software updates are field-installed without any need to remove the card from its frame.</b></p>
Card Software <b>newer</b> than version in manual	<p>A new manual is expediently released whenever a card’s software is updated <b>and specifications and/or functionality have changed</b> as compared to an earlier version (a new manual is not necessarily released if specifications and/or functionality have not changed). A manual earlier than a card’s software version may not completely or accurately describe all functions available for your card.</p> <p>If your card shows features not described in this manual, you can check for the latest manual (if applicable) and download it by going to the card’s web page on <a href="http://www.cobaltdigital.com">www.cobaltdigital.com</a>.</p>

## Cobalt Reference Guides

From the Cobalt® web home page, go to **Support>Reference Documents** for easy to use guides covering network remote control, card firmware updates, example card processing UI setups and other topics.

---

## Manual Conventions

In this manual, display messages and connectors are shown using the exact name shown on the 9932-EMDE itself. Examples are provided below.

- Card-edge display messages are shown like this:



- Connector names are shown like this: **SDI IN A**

In this manual, the terms below are applicable as follows:

- **9932-EMDE** refers to the 9932-EMDE 3G/HD/SD-SDI 16- Channel Embedder / De-Embedder with Audio/Video Processing and CVBS I/O card.
- **Frame** refers to the HPF-9000, OG3-FR, 8321, or similar 20-slot frame that houses Cobalt® or other cards.
- **Device** and/or **Card** refers to a Cobalt® or other card.
- **System** and/or **Video System** refers to the mix of interconnected production and terminal equipment in which the 9932-EMDE and other cards operate.
- Functions and/or features that are available only as an option are denoted in this manual like this:



Most options are covered in this manual. However, if your card has DashBoard tabs that are not described in this manual it indicates that the optional function/feature is covered in a separate Manual Supplement.

If you have not received a Manual Supplement for options on your card, you can download a pdf for the option by going to the card's web page and clicking on **Product Downloads**, where you can select from any available option Manual Supplements for the card.

## Warnings, Cautions, and Notes

Certain items in this manual are highlighted by special messages. The definitions are provided below.

### Warnings

Warning messages indicate a possible hazard which, if not avoided, could result in personal injury or death.




### Cautions

Caution messages indicate a problem or incorrect practice which, if not avoided, could result in improper operation or damage to the product.

### Notes

Notes provide supplemental information to the accompanying text. Notes typically precede the text to which they apply.

## Labeling Symbol Definitions

	<p>Important note regarding product usage. Failure to observe may result in unexpected or incorrect operation.</p>
	<p>Electronic device or assembly is susceptible to damage from an ESD event. Handle only using appropriate ESD prevention practices.</p> <p>If ESD wrist strap is not available, handle card only by edges and avoid contact with any connectors or components.</p>
	<p>Symbol (WEEE 2002/96/EC)</p> <p>For product disposal, ensure the following:</p> <ul style="list-style-type: none"> <li>• Do not dispose of this product as unsorted municipal waste.</li> <li>• Collect this product separately.</li> <li>• Use collection and return systems available to you.</li> </ul>



## Safety and Regulatory Summary

### Warnings

#### ! WARNING !

To reduce risk of electric shock do not remove line voltage service barrier cover on frame equipment containing an AC power supply. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

### Cautions

#### CAUTION

This device is intended for environmentally controlled use only in appropriate video terminal equipment operating environments.

#### CAUTION

This product is intended to be a component product of an openGear® frame. Refer to the openGear® frame Owner's Manual for important safety instructions regarding the proper installation and safe operation of the frame as well as its component products.

#### CAUTION

If required, make certain Rear I/O Module(s) is installed before installing the 9932-EMDE into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.

#### CAUTION

If required, make certain Rear I/O Module(s) is installed before installing the 9932-EMDE into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.

#### CAUTION

If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.

#### CAUTION

The 9932-EMDE FPGA is designed for a normal-range operating temperature around 85° C core temperature. Operation in severe conditions exceeding this limit for non-sustained usage are within device operating safe parameters, and can be allowed by setting this control to Disable. However, the disable (override) setting should be avoided under normal conditions to ensure maximum card protection.

### EMC Compliance Per Market

Market	Regulatory Standard or Code
United States of America	FCC "Code of Federal Regulations" Title 47 Part15, Subpart B, Class A
Canada	ICES-003
International	CISPR 24:2010 IEC 61000-4-2:2008 IEC 61000-4-3:2006 with A1:2007 and A2:2010 IEC 61000-4-4:2004 IEC 61000-4-6:2008 IEC 61000-6-3:2006 with A1:2010 CISPR 22:2008

---

## 9932-EMDE Functional Description

Figure 1-1 shows a functional block diagram of the 9932-EMDE. The 9932-EMDE includes AES/analog audio support and CVBS video I/O. In addition to a basic signal presence input failover function, a Quality Check option allows failover to alternate inputs based on user-configurable subjective criteria such as black or frozen frame. With option +ANC, the 9932-EMDE offers full VANC/HANC ancillary data packet de-embedding and embedding for 3G/HD/SD-SDI streams, with direct access to DID and SDID locations to extract or insert user data such as camera PTZ, SCTE 104, closed-captioning read/insert, GPI/GPO via ANC, or other specialized user payloads.

### 9932-EMDE Input/Output Formats


The 9932-EMDE provides the following inputs and outputs:

- **Inputs:**

- **3G/HD/SD SDI IN A** thru **SDI IN D** – four 3G/HD/SD-SDI inputs. **SDI IN A** or **SDI IN B** can be set to failover to **A** or **B** in absence of opposite channel of this pair.
- **CVBS IN** – CVBS coaxial analog video input.
- **AES IN** – BNC (AES-3id, 75Ω) ports as AES input (number of ports dependent on rear I/O module used).
- **AN-AUD IN** – Four balanced analog audio embed inputs.

- **Outputs:**

- **3G/HD/SD-SDI OUT (1-4)** – four 3G/HD/SD-SDI buffered video outputs. Each output can be independently set as processed output video or selected input video reclocked.
- **RLY BYP B** – 3G/HD/SD-SDI which outputs a copy of **SDI OUT 1** under normal conditions, or passive outputs the SDI input on **SDI IN B** as a relay failover if card power is lost.
- **AES OUT** – BNC (AES-3id, 75Ω) ports as AES outputs (number of ports dependent on rear I/O module used).
- **AN-AUD OUT** – Four balanced analog audio de-embed outputs.
- **CVBS OUT** – CVBS coaxial analog video usable with SD video streams.



9932BD V1.3L106

Figure 1-1 9932-EMDE Functional Block Diagram

- Notes:**
1. Signal connections shown depicts full input/output capability. Practical input/output signal availability is determined by rear I/O module used. Refer to text for more information.
  2. Some functions shown here are available only with corresponding card option(s).
  3. Asterisk (\*) denotes optional function/feature.

---


## Video Processor Description

The 9932-EMDE video subsystem provides the functions described below.

### Input Video Select/Quality Check Functions

A GUI-based control allows the card to select from up to four 3G/HD/SD-SDI inputs, and a SD CVBS analog video input. For analog inputs, waveform-based ancillary data is preserved for extraction and usage later in the card processing chain.

The input can be selected using DashBoard manual control, set to failover to an alternate input upon loss of the target input, and can be externally selected via a GPIO interface. Reclocked copies of any SDI input can be outputted by the card when selected as a choice on the output crosspoint.

**Option**  (Option +QC). Quality Check allows criteria such as black/frozen frame events to propagate an event alert. This alert can be used by the card Presets function to invoke video routing changes, GPO, and other actions.

### Auto-Changeover Function

(See Figure 1-2.) This function allows the card logic assert of input select and routing to the **RLY BYP B** card processed output under normal conditions, while providing latching relays at both the input and output nodes to provide input failover to select an alternate input, and also provides output failover which can passively relay-route the currently selected input directly to the output if the card loses power or is removed from the frame. (Both relays are located on the card rear module.)

The **RLY BYP B** SDI output retains selected routing regardless of whether a selection was manually invoked or by a unit-detected failover (such as loss of power). For example, prior to a power loss event if a changeover from **SDI IN A** to **SDI IN B** was active at the time, this selection is retained by the latching relays. In a power-loss event, **SDI IN B** would be directly routed to output **RLY BYP B**, and the card automatically removed from the signal path until normal operation again commences. In normal operation, the output relay always maintains routing from the card processed output to output **RLY BYP B**.

- Note:**
- The card also provides active (DA-driven) outputs **RCK/PROC 1** thru **RCK/PROC 4**. These outputs are independent of the relay failover function and will lose signal in the event of a power loss.
  - The above failover uses basic signal presence as failover criteria and is limited to inputs **A** and **B**. Failover using active assessments (Quality Check) can be set to provide failovers using frozen/black frame and other criteria. See Video Quality Events Detect Function (p. 1-12) for more information.





Figure 1-2 Auto-Changeover Function and Signal Flow

## Timecode Processor

(See Figure 1-3.) This function provides for extraction of timecode data from input video source, and in turn allow individual timecode strings to be embedded on the output video. The function can monitor any of the video inputs of the card for supported timecode formats such as ATC\_LTC or ATC\_VITC for down-conversions to HD, and ATC\_VITC or VITC waveform (with selectable odd/even field line number control) for SD SDI or CVBS inputs. Waveform VITC timecode can also be extracted from a reference input and used as the output timecode value. If the preferred format is detected, the preferred format is used by the card; if the preferred format is not detected, the card uses other formats (where available) as desired. An internally-generated free-run timecode can be also be embedded on output video if desired.

The function also provides conversion between various timecode formats and provides independent insertion and line number controls for each SDI timecode output format.

**Option**  When licensed with option **+LTC**, this function also can receive, send and translate between audio/RS-485 LTC timecode formats and the VBI formats described above.




Figure 1-3 Timecode Processor

### Frame Sync Function **Option**

This function provides for frame sync control using either one of two external **FRAME REF IN (1,2)** reference signals distributed with the card frame, or the input video as a frame sync reference.

This function also allows horizontal and/or vertical offset to be added between the output video and the frame sync reference.

Frame sync can select from either of two card frame reference sources, or free-run input video sync. Selectable failover allows alternate reference selection should the initial reference source become unavailable or invalid. In the event of input video loss of signal, the output can be set to disable video, go to black, go to an internal test signal generator pattern, or freeze to the last intact frame (last frame having valid SAV and EAV codes).

An internal test signal generator provides a selection of several standard patterns such as color bars, sweep patterns, and other technical patterns. The test patterns can be applied to the output video upon loss of input or manually inserted at any time.

## Wings Insertion


Wings insertion allows a symmetrical L-R wings insertion to be integrated into the card program video output. Wings video is accommodated using a separate wings SDI input. The wings user interface displays wings timing relative to the card output video, allowing wings timing offset to be adjusted such that wings can be properly framed. (This function does not provide timing offset control of the wings video; offset must be provided by an external frame sync card or device controlling the wings video feed.)

The wings L/R insertion width can be manually configured using a wings width control.

## Key/Fill Insertion **Option**

Option **+KEYER** provides for three of the card SDI video inputs to be used as respective program video, key, and fill inputs. This function provides chroma keying using the **KEY VID IN** signal. The **FILL VID IN** signal provides the fill video that is inserted in the area “cleared out” by the key. The keying user interface displays key and fill timing relative to the card output video, allowing timing offset to be adjusted such that key and fill can be properly framed. (The option and its host card does not provide timing offset control of the key/fill video; offset must be provided by external frame sync cards or devices controlling the key and fill video feed.) The program video input when using keying accommodates either an SDI or an analog video input; key and fill inputs are SDI only.

Alpha threshold keyer modes allow full-color key/fill from cost-effective generic sources such as a standard PC (with appropriate HDMI-to-SDI output conversion) hosting simple .bmp, .jpeg, or .png graphic files. In these modes, a common key/fill SDI input provides both the key and fill input.

**EAS Text Crawl Generation** **Option**  Option **+EAS** provides for automated keying Emergency Alert System (EAS) text crawls in the active program video output. The function receives its text stream via a card serial data input. The EAS crawl start can be set to trigger upon receiving the serial data message, or be set to use a GPI to trigger start of the EAS crawl.

Embedded in the received serial data are commands which set the message severity to be shown by the keyed crawl (severity is correlated to user-specified text color and background color for the crawl). User controls allow control of the crawl speed and repeat of the crawl burn-in (if desired). Refer to +TTS Manual Supplement OPT-SW-PHXEAS-MS for detailed information and installation/setup instructions. This supplement is furnished with the option.

## Color Corrector **Option**

Option **+COLOR** converts the YCbCr SDI input video to the 4:4:4 RGB color space (where the color correction is applied), and then back to YCbCr SDI on the output. Controls are available to adjust each RGB level independently for both white levels (gain) and black levels (offset). Gamma can also be independently adjusted for each RGB channels. Various controls can be ganged to provide adjustment for all three color channels simultaneously.

## Video Quality Events Detect Function **Option**

Option **+QC** provides a **Video Quality Events** user interface and an **Event Triggers** user interface for setting an area of concern across the program raster which can be monitored for frozen or black video events. Threshold controls allow setting the sensitivity of the function, while engage and disengage threshold timing controls allow setting how fast the event detection engages and releases when triggered. The **Event Triggers** user interface allows instructing the card as to the action to take upon an event (such as go to a changed signal routing, activate a GPO, send an automated email, or go to a user-defined preset).

An **Event Triggers** user interface can detect Closed Caption Presence and Closed Caption Absence events. The **Event Triggers** user interface in turn allows instructing the card as to the action to take upon an event (such as go to a changed signal routing, activate a GPO, send an automated email, or go to a user-defined preset).

## Ancillary Data Processor **Option**

This function provides full VANC/HANC ancillary data de-embedding and embedding for 3G/HD/SD-SDI streams. Direct access to DID and SDID locations allows extraction or insertion of user data such as camera PTZ, SCTE 104, closed-captioning read/insert, GPI/GPO via ANC, or other specialized user payloads. Data can be extracted and inserted within the card (Bridge mode), or inserted and/or extracted to and from the card via serial or IP interfaces connecting to external devices/systems. A rear I/O module with a dedicated IP port can be used with the ancillary data processor function for data insertion or extraction via IP.

This option also provides SMPTE 337 embed/de-embed, which allows serial user data to be embedded and de-embedded over unused embedded audio pairs.

## Video Output Crosspoint

A four-output video matrix crosspoint allows independently applying the card processed video output, relocked input, or wings/key-fill previews to any of the four card discrete coaxial outputs (**SDI OUT 1** thru **SDI OUT 4**). For an SD output, a CVBS coaxial output is available as a processed video output.



An additional output (**RLY BYP B**) provides a relay-protected output that outputs a copy of **SDI OUT 1** crosspoint selection in normal operation. In power loss failover **RLY BYP B** passive outputs the signal connected to **SDI IN B**.

## Audio Processor Description

The audio processor operates as an internal audio router. This function chooses from the following inputs:

- 16 channels of embedded audio from the SDI video input (default 1-to-1 routing to SDI output)
- Up to 16 channels (8 pairs) of discrete AES input<sup>1</sup>
- Up to 4 channels of balanced analog audio input

(See Figure 1-4.) The audio processing subsection is built around a card internal 16-channel audio bus. This 16-channel bus receives inputs from an input routing crosspoint that routes de-embedded, and discrete AES and analog audio inputs, over the 16-channel card bus. Correspondingly, at the output end of the 16-channel bus is an output routing crosspoint that in turn distributes the 16-channel bus signals to embedded, and discrete AES and analog audio outputs.

An Input Audio Status display shows the presence and peak level of each input audio channel received by the card. In addition to SDI embedded audio channel sources, analog and coaxial AES inputs are available as input audio choices. For AES audio inputs, payload is identified (PCM or data such as Dolby® Digital or E). Each AES input pair has independent sample rate converters to align each input pair with video timing to accommodate cases where AES audio is not synchronous with input video (SRC automatically bypassed for non-PCM payloads). As such, the audio subsection provides a full crosspoint between all supported audio inputs and output types.

1. Discrete audio I/O channel count is dependent on rear I/O module used. Not all rear I/O modules may not support maximum number of available discrete channels.




Figure 1-4 Basic Audio Processing Block Diagram

### Audio Down Mix Function

(See Figure 1-5.) The Audio Down Mixer function provides for the selection of any five embedded channels serving as Left (L), Right (R), Center (C), Left Surround (Ls), and Right Surround (Rs) individual signals to be multiplexed into stereo pair Down Mix Left (DM-L) and Down Mix Right (DM-R). The resulting stereo pair DM-L and DM-R can in turn be routed to any embedded audio pair as desired (or de-embedded to an AES or analog audio output).





Figure 1-5 Audio Down Mix Functional Block Diagram with Example Sources


**Flex Buses.** For both input and output nodes before and after the card internal buses, flex buses provide flexible-structure mixer in which any of 16 summing nodes (**Flex Mix Bus A** thru **Flex Mix Bus P**) can receive any card audio input, thereby allowing several customizable mixing schemes. Similarly, any of the 16 card internal bus signals can be applied to an output flex bus mixer. The output flex bus allows cross-sourcing from both **Path 1** and **Path 2** embedded internal Audio Bus sources to the Path 1 and Path 2 discrete output audio crosspoints.

**Text-To-Speech.** **Option**  (Option **+TTS**) Cobalt Digital **+TTS** is a complete 21CVAA digital text-to-speech generation / audio insertion solution for embedded and discrete audio systems. **+TTS** is available as a software option for 9932-EMDE cards.

**+TTS** interfaces with industry standard Windows Share folder systems to receive non-proprietary text, XML, or similar plain text files, and converts and inserts realistic human-voice audio into user-configured audio channels (typically an SAP channel pair intended for this playout). **+TTS** allows for prioritization based on the organization's discretion (for example, severe weather alerts out-prioritizing school closings). Alert tones are inserted over the main program channels to alert the visually impaired that emergency content is to occur on the SAP channel. Alerts can be played a configurable number of times, and alerts with higher priority can interrupt current lists for breaking news. Once the interrupt message is broadcast, **+TTS** automatically reverts to normal audio programming. Refer to **+TTS Manual Supplement OPT-TTS-MS** for detailed information and installation/setup instructions. This supplement is furnished with the option.

### Audio Events Detect Function **Option**

Option **+QC** provides a **Audio Detect Events** user interface and an **Event Triggers** user interface for checking user-selected channels to detect audio silence conditions. The **Event Triggers** user interface in turn allows instructing the card as to the action to take upon an event (such as go to a changed signal routing, activate a GPO, send an automated email, or go to a user-defined preset).

**2.0-to-5.1 Upmixer.** **Option**  (Option **+UM**) The 2.0-to-5.1 upmixer function receives a normal PCM stereo pair from any internal audio bus channel pair. The stereo pair is upmixed to provide 5.1 channels (Left (**L**), Right (**R**), Center (**C**), Low Frequency Effects (**LFE**), Left Surround (**Ls**), and Right Surround (**Rs**)). Whenever the upmixer is active, it overwrites the six selected 5.1 output channels with the new 5.1 upmix signals (including replacing the original source stereo **L** and **R** inputs with new **L** and **R** signals).

The 2.0-to-5.1 upmixer can be set to upmix in any of three modes: Always upmix, Bypass upmix, or Auto enable/bypass upmixing. The Auto upmixing mode looks at the signal levels on the selected channels and compares them to a selectable level threshold. It then determines whether or not to generate 5.1 upmixing from the stereo pair as follows:

- If the upmixer detects signal level **below** a selected threshold on **all three** of the selected channels designated as **C**, **Ls**, and **Rs**, this indicates to the upmixer that these channels are not carrying 5.1. In this case, the upmixer produces new 5.1 content generated by the upmixer.
- If the upmixer detects signal level **above** a selected threshold on **any** of the three selected channels designated as **C**, **Ls**, and **Rs**, this indicates to the upmixer that the channel(s) are already carrying viable 5.1 content. In this case, the upmixer is bypassed and the channels fed to the upmixer pass unaffected to the upmixer outputs.

The examples in Figure 1-6 show the automatic enable/disable upmixing function applied to example selected channels **Bus Ch 1** thru **Bus Ch 6**. As shown and described, the processing is contingent upon the signal levels of the channels selected to carry the new 5.1 upmix relative to the selected threshold (in this example, -60 dBFS).





Figure 1-6 Upmixing Auto Enable/Bypass with Example Sources

**Loudness Processor.** **Option**  (See Figure 1-7.) The loudness processor (option +LP) function receives up to six selected channels from the internal bus and performs loudness processing on the selected channels. A loudness processing profile best suited for the program material can be selected from several loudness processing presets.

**Note:** Discussion and example here describes 5.1-channel loudness processor. Stereo and dual-stereo processors operate similar to described here.

The example in Figure 1-7 shows routing of embedded output channels Emb Out Ch 1 thru Ch 6 fed through the loudness processor. A master output gain control is provided which allows fine adjustment of the overall output level.




Figure 1-7 5.1-Channel Loudness Processor with Example Sources

## Control and Data Input/Output Interfaces

### GPI Interface

Two independent ground-closure sensing GPI inputs (**GPI 1** and **GPI 2**; each sharing common ground connection as chassis potential) are available. Associated with each GPI user control is a selection of one of 32 user-defined card presets in which GPI activation invokes a card control preset. Because the GPI closure invokes a user-defined preset, the resulting setup is highly flexible and totally user-defined. Invoking a user preset to effect a change involves card setup communication limited **only** to the items being changed.

GPI triggering can be user selected to consider the activity on discrete GPI ports, or combinations of logic states considering both GPI inputs, as well as be set for level or edge triggering. This flexibility allows multistage, progressive actions to be invoked if desired. Indication is provided showing whenever a GPI input has been invoked.

## GPO Interface

Two independent phototransistor non-referenced (floating) contact pairs (**GPO 1/1** and **GPO 2/2**) are available. A GPO can be invoked by setting a GPO to be enabled when a card preset is in turn applied (i.e., when a preset is invoked (either manually or via event-based loading), the GPO is correspondingly also activated.

## +SCTE104 Insertion **Option**

Option +SCTE104 provides generation and insertion of SCTE 104 messages into baseband SDI. Message send can be triggered from automation GPI or other event action modes. The option can also execute card actions based on SCTE 104 messages received by the card, as well as send triggered SCTE 104 packets to other downstream systems.

The user interface is based on common SCTE 104 operations: Splice Start Normal, Splice Start Intermediate, Splice End Normal, Splice End Intermediate, and Splice Cancel (splice\_request\_data variants), offering full control of splice start, end, and cancel as well as pre-roll and break duration offsets. (A Manual Supplement is planned for this option. Please check product web page.)

## Alarm Function

The card can be set to monitor input video/audio for input errors such as input LOS, frozen or black frame, loss of reference, closed captioning ancillary data loss, and/or per-channel audio absences. These alarms can be propagated as a card general error or warning message, and can be downloaded as basic .txt logs or via a Syslog function.

User setup tables configure the alarm severity escalation as well as trigger holdoff/release and other thresholds as applicable.

---

## User Control Interface

Figure 1-8 shows the user control interface options for the 9932-EMDE. These options are individually described below.

**Note:** All user control interfaces described here are cross-compatible and can operate together as desired. Where applicable, any control setting change made using a particular user interface is reflected on any other connected interface.

- **DashBoard™ User Interface** – Using DashBoard™, the 9932-EMDE and other cards installed in openGear®<sup>1</sup> frames can be controlled from a computer and monitor.

DashBoard™ allows users to view all frames on a network with control and monitoring for all populated slots inside a frame. This simplifies the setup and use of numerous modules in a large installation and offers the ability to centralize monitoring. Cards define their controllable parameters to DashBoard™, so the control interface is always up to date.


The DashBoard™ software can be downloaded from the Cobalt Digital Inc. website: [www.cobaltdigital.com](http://www.cobaltdigital.com) (enter “DashBoard” in the search window). The DashBoard™ user interface is described in Chapter 3, “Operating Instructions”.

- **Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panels** – The OGCP-9000 and OGCP-9000/CC Remote Control Panels conveniently and intuitively provide parameter monitor and control of the 9932-EMDE and other video and audio processing terminal equipment meeting the open-architecture Cobalt® cards for openGear™ standard.

In addition to circumventing the need for a computer to monitor and control signal processing cards, the Control Panels allow quick and intuitive access to hundreds of cards in a facility, and can monitor and allow adjustment of multiple parameters at one time.

The Remote Control Panels are totally compatible with the openGear™ control software DashBoard™; any changes made with either system are reflected on the other. The Remote Control Panel user interface is described in Chapter 3, “Operating Instructions”.

1. openGear® is a registered trademark of Ross Video Limited. DashBoard™ is a trademark of Ross Video Limited.



**Figure 1-8 9932-EMDE User Control Interface**

**Note:** If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt® reference guide **Remote Control User Guide (PN 9000RCS-RM)** provides thorough information and step-by-step instructions for setting up network remote control of Cobalt® cards using Dashboard™. (Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panel product manuals have complete instructions for setting up remote control using a Remote Control Panel.)

Download a copy of this guide by clicking on the **Support>Reference Documents** link at [www.cobaltdigital.com](http://www.cobaltdigital.com) and then select Dashboard Remote Control Setup Guide as a download, or contact Cobalt® as listed in Contact Cobalt Digital Inc. (p. 1-25).



## 9932-EMDE Rear I/O Modules

The 9932-EMDE physically interfaces to system video connections at the rear of its frame using a Rear I/O Module.

All inputs and outputs shown in the 9932-EMDE Functional Block Diagram (Figure 1-1) enter and exit the card via the card edge backplane connector. The Rear I/O Module breaks out the 9932-EMDE card edge connections to BNC and other connectors that interface with other components and systems in the signal chain.

The full assortment of 9932-EMDE Rear I/O Modules is shown and described in 9932-EMDE Rear I/O Modules (p. 2-4) in Chapter 2, “Installation and Setup”.

## Technical Specifications

Table 1-1 lists the technical specifications for the 9932-EMDE 3G/HD/SD-SDI 16-Channel Embedder / De-Embedder with Audio/Video Processing and CVBS I/O card.

**Table 1-1 Technical Specifications**

Item	Characteristic
Part number, nomenclature	9932-EMDE 3G/HD/SD-SDI 16-Channel Embedder / De-Embedder with Audio/Video Processing and CVBS I/O
Installation/usage environment	Intended for installation and usage in frame meeting openGear™ modular system definition
Power consumption	< 18 Watts maximum
Installation Density	Up to 20 cards per 20-slot frame
Environmental: Operating temperature: Relative humidity (operating or storage):	32° – 104° F (0° – 40° C) < 95%, non-condensing
Frame communication	10/100 Mbps Ethernet with Auto-MDIX
Indicators	Card edge display and indicators as follows: <ul style="list-style-type: none"> <li>• 4-character alphanumeric display</li> <li>• Status/Error LED indicator</li> <li>• Input Presence LED indicators</li> </ul>
Serial Digital Video Input	Number of Inputs: Up to (4), with manual select or failover to alternate input. Data Rates Supported: SMPTE 424M, 292M, SMPTE 259M-C

Table 1-1 Technical Specifications — continued

Item	Characteristic
Serial Digital Video Input (cont.)	Impedance: 75 $\Omega$ terminating Return Loss: > 15 dB up to 1.485 GHz > 10 dB up to 2.970 GHz
Analog Video Input	Number of Inputs: One SD analog CVBS Impedance: 75 $\Omega$
AES Audio Inputs	Standard: SMPTE 276M Number of Inputs: Up to 16 unbalanced; AES-3id Impedance: 75 $\Omega$
Analog Audio Inputs	Number of Inputs: Up to four balanced using 3-wire removable Phoenix connectors; 0 dBFS => +24 dBu
Input Select/Auto-Changeover Failover (option +QC)	Failover to alternate input on loss of target input. Failover invoked upon LOS and/or (with option +QC) user configurable parametric criteria such as black/frozen frame or audio silence. - Black frame trigger configurable for black intensity threshold and persistence time. - Frozen frame trigger configurable for frozen percentage difference and persistence time.
Post-Processor Serial Digital Video Outputs	Number of Outputs: Up to four 3G/HD/SD-SDI BNC Impedance: 75 $\Omega$ Return Loss: > 15 dB at 5 MHz – 270 MHz Signal Level: 800 mV $\pm$ 10% DC Offset: 0 V $\pm$ 50 mV Jitter (3G/HD/SD): < 0.3/0.2/0.2 UI

Table 1-1 Technical Specifications — continued

Item	Characteristic
Post-Processor Serial Digital Video Outputs (cont.)	Minimum Latency: SD: 127 pixels; 9.4 us 720p: 330 pixels; 4.45 us 1080i: 271 pixels; 3.65 us 1080p: 361 pixels; 2.43 us
Analog Video Output	Number of Outputs: One SD analog CVBS Impedance: 75 Ω
Embedded Audio Output	16-ch embedded. User crosspoint allows routing of any embedded channel to any embedded channel output. Multi-frequency tone generator for each audio output. Master delay control; range of -33 msec to +3000 msec.
AES Audio Outputs	Standard: SMPTE 276M Number of Outputs: Up to 16 unbalanced; AES-3id Impedance: 75 Ω
Analog Audio Outputs	Number of Outputs: Up to four balanced using 3-wire removable Phoenix connectors; 0 dBFS => +24 dBu
Frame Reference Input (option +FS)	Number of Inputs: Two, REF 1 and REF 2 from frame with selectable failover Standards Supported: SMPTE 170M/318M ("black burst") SMPTE 274M/296M ("tri-level") Return Loss: > 35 dB up to 5.75 MHz
GPIO	(2) GPI; (2) GPO; opto-isolated GPO Specifications: Max I: 120 mA Max V: 30 V Max P: 120 mW GPI Specifications: GPI LO @ Vin < 1.5 V GPI HI @ Vin > 2.3 V Max Vin: 9 V

---

## Warranty and Service Information

### Cobalt Digital Inc. Limited Warranty

This product is warranted to be free from defects in material and workmanship for a period of five (5) years from the date of shipment to the original purchaser, except that 4000, 5000, 6000, 8000 series power supplies, and Dolby® modules (where applicable) are warranted to be free from defects in material and workmanship for a period of one (1) year.

Cobalt Digital Inc.'s ("Cobalt") sole obligation under this warranty shall be limited to, at its option, (i) the repair or (ii) replacement of the product, and the determination of whether a defect is covered under this limited warranty shall be made at the sole discretion of Cobalt.

This limited warranty applies only to the original end-purchaser of the product, and is not assignable or transferrable therefrom. This warranty is limited to defects in material and workmanship, and shall not apply to acts of God, accidents, or negligence on behalf of the purchaser, and shall be voided upon the misuse, abuse, alteration, or modification of the product. Only Cobalt authorized factory representatives are authorized to make repairs to the product, and any unauthorized attempt to repair this product shall immediately void the warranty. Please contact Cobalt Technical Support for more information.

To facilitate the resolution of warranty related issues, Cobalt recommends registering the product by completing and returning a product registration form. In the event of a warrantable defect, the purchaser shall notify Cobalt with a description of the problem, and Cobalt shall provide the purchaser with a Return Material Authorization ("RMA"). For return, defective products should be double boxed, and sufficiently protected, in the original packaging, or equivalent, and shipped to the Cobalt Factory Service Center, postage prepaid and insured for the purchase price. The purchaser should include the RMA number, description of the problem encountered, date purchased, name of dealer purchased from, and serial number with the shipment.

#### **Cobalt Digital Inc. Factory Service Center**

2506 Galen Drive

Champaign, IL 61821 USA

www.cobaltdigital.com

Office: (217) 344-1243

Fax: (217) 344-1245

Email: info@cobaltdigital.com

THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON COBALT'S PART. ANY SOFTWARE PROVIDED WITH, OR FOR USE WITH, THE PRODUCT IS PROVIDED "AS IS." THE BUYER OF THE PRODUCT ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE OR RELIED UPON WITH RESPECT TO THE QUALITY AND FUNCTION OF THE GOODS HEREIN SOLD. COBALT PRODUCTS ARE NOT AUTHORIZED FOR USE IN LIFE SUPPORT APPLICATIONS.

COBALT'S LIABILITY, WHETHER IN CONTRACT, TORT, WARRANTY, OR OTHERWISE, IS LIMITED TO THE REPAIR OR REPLACEMENT, AT ITS OPTION, OF ANY DEFECTIVE PRODUCT, AND SHALL IN NO EVENT INCLUDE SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS), EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

---

## Contact Cobalt Digital Inc.

Feel free to contact our thorough and professional support representatives for any of the following:

- Name and address of your local dealer
- Product information and pricing
- Technical support
- Upcoming trade show information

<b>Phone:</b>	(217) 344-1243
<b>Fax:</b>	(217) 344-1245
<b>Web:</b>	<a href="http://www.cobaltdigital.com">www.cobaltdigital.com</a>
<b>General Information:</b>	info@cobaltdigital.com
<b>Technical Support:</b>	support@cobaltdigital.com

---

**This page intentionally blank**

# Installation and Setup

## Overview

This chapter contains the following information:

- Installing the 9932-EMDE Into a Frame Slot (p. 2-1)
- Installing a Rear I/O Module (p. 2-3)
- Setting Up 9932-EMDE Network Remote Control (p. 2-9)

## Installing the 9932-EMDE Into a Frame Slot

### CAUTION

Heat and power distribution requirements within a frame may dictate specific slot placement of cards. Cards with many heat-producing components should be arranged to avoid areas of excess heat build-up, particularly in frames using only convection cooling. The 9932-EMDE has a moderate power dissipation (<18 W). As such, avoiding placing the card adjacent to other cards with similar dissipation values if possible.

### CAUTION



This device contains semiconductor devices which are susceptible to serious damage from Electrostatic Discharge (ESD). ESD damage may not be immediately apparent and can affect the long-term reliability of the device.

Avoid handling circuit boards in high static environments such as carpeted areas, and when wearing synthetic fiber clothing. Always use proper ESD handling precautions and equipment when working on circuit boards and related equipment.

**Note:** If installing the 9932-EMDE in a slot with no rear I/O module, a **Rear I/O Module is required** before cabling can be connected. Refer to Installing a Rear I/O Module (p. 2-3) for rear I/O module installation procedure.

### CAUTION

If required, make certain Rear I/O Module(s) is installed before installing the 9932-EMDE into the frame slot. Damage to card and/or Rear I/O Module can occur if module installation is attempted with card already installed in slot.

**Note:** Check the packaging in which the 9932-EMDE was shipped for any extra items such as a Rear I/O Module connection label. In some cases, this label is shipped with the card and to be installed on the Rear I/O connector bank corresponding to the slot location of the card.

Install the 9932-EMDE into a frame slot as follows:

1. Determine the slot in which the 9932-EMDE is to be installed.
2. Open the frame front access panel.
3. While holding the card by the card edges, align the card such that the plastic ejector tab is on the bottom.
4. Align the card with the top and bottom guides of the slot in which the card is being installed.
5. Gradually slide the card into the slot. When resistance is noticed, gently continue pushing the card until its rear printed circuit edge terminals engage fully into the rear I/O module mating connector.

#### **CAUTION**

**If card resists fully engaging in rear I/O module mating connector, check for alignment and proper insertion in slot tracks. Damage to card and/or rear I/O module may occur if improper card insertion is attempted.**

6. Verify that the card is fully engaged in rear I/O module mating connector.
7. Close the frame front access panel.
8. Connect the input and output cables as shown in 9932-EMDE Rear I/O Modules (p. 2-4).
9. Repeat steps 1 through 8 for other 9932-EMDE cards.

**Note:**

- The 9932-EMDE BNC inputs are internally 75-ohm terminated. It is not necessary to terminate unused BNC inputs or outputs.
- To remove a card, press down on the ejector tab to unseat the card from the rear I/O module mating connector. Evenly draw the card from its slot.

10. If network remote control is to be used for the frame and the frame has not yet been set up for remote control, perform setup in accordance with Setting Up 9932-EMDE Network Remote Control (p. 2-9).

**Note:** If installing a card in a frame already equipped for, and connected to DashBoard™, no network setup is required for the card. The card will be discovered by DashBoard™ and be ready for use.




### Installing a Rear I/O Module

**Note:** This procedure is applicable **only if a Rear I/O Module is not currently installed** in the slot where the 9932-EMDE is to be installed.

If installing the 9932-EMDE in a slot already equipped with a suitable I/O module, omit this procedure.

Install a Rear I/O Module as follows:

1. On the frame, determine the slot in which the 9932-EMDE is to be installed.
2. In the mounting area corresponding to the slot location, install Rear I/O Module as shown in Figure 2-1.



**Figure 2-1 Rear I/O Module Installation**

9932-EMDE Rear I/O Modules

Table 2-1 shows and describes the full assortment of Rear I/O Modules specifically for use with the 9932-EMDE.

**Notes:** Rear I/O Modules equipped with 3-wire Phoenix connectors are supplied with removable screw terminal block adapters. For clarity, the adapters are omitted in the drawings below.

Table 2-1 9932-EMDE Rear I/O Modules



9932-EMDE Rear I/O Module	Description
<p><b>RM20-9932-B</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• One 3G/HD/SD-SDI coaxial input BNC (<b>SDI IN A</b>)</li> <li>• One analog video CVBS coaxial input BNC (<b>CVBS IN</b>)</li> <li>• Two analog balanced audio inputs (<b>AN-AUD IN 1</b> and <b>AN-AUD IN 2</b>)</li> <li>• One AES input BNC (<b>AES IN</b>)</li> <li>• One processed SDI output BNC (<b>SDI OUT</b>)</li> <li>• One analog video CVBS coaxial output BNC (<b>CVBS OUT</b>)</li> <li>• Two analog balanced audio outputs (<b>AN-AUD OUT 1</b> and <b>AN-AUD OUT 2</b>)</li> <li>• One AES output BNC (<b>AES OUT</b>)</li> </ul>
<p><b>RM20-9932-C</b></p>  <p>Switches S1 thru S4 set AES BNC pairs (4-ch groups) as Input (embed) or Output (de-embed).</p> <p>S1 - AES BNC 1-2 S2 - AES BNC 3-4 S3 - AES BNC 5-6 S4 - AES BNC 7-8</p>	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• One 3G/HD/SD-SDI coaxial input BNC (<b>SDI IN</b>)</li> <li>• Eight AES input or output BNCs (<b>AES I/O 1</b> thru <b>AES I/O 8</b>)</li> <li>• One processed SDI output BNC (<b>SDI OUT</b>)</li> </ul> <p><b>Note:</b> See illustration. PCB-mounted switches set BNC pairs for either input or output.</p>

Table 2-1 9932-EMDE Rear I/O Modules — continued



9932-EMDE Rear I/O Module	Description
<p><b>RM20-9932-D</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• Two 3G/HD/SD-SDI video inputs (<b>SDI IN A</b> and <b>SDI IN B</b>)</li> <li>• One CVBS video input (<b>CVBS IN</b>)</li> <li>• Two analog balanced audio inputs (<b>AN-AUD IN 1</b> and <b>AN-AUD IN 2</b>)</li> <li>• Eight AES audio inputs (<b>AES IN 1</b> thru <b>AES IN 8</b>)</li> <li>• Two 3G/HD/SD-SDI video outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> <li>• One CVBS video output (<b>CVBS OUT</b>)</li> <li>• Two analog balanced audio outputs (<b>AN-AUD OUT 1</b> and <b>AN-AUD OUT 2</b>)</li> <li>• Eight AES audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 8</b>)</li> </ul> <p><b>Note:</b> Available equipped with High-Density BNC (HDBNC) or DIN1.0/2.3 connectors as: RM20-9932-D-HDBNC or RM20-9932-D-DIN, respectively.</p>
<p><b>RM20-9932-E</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• Four 3G/HD/SD-SDI video inputs (<b>SDI IN A</b> thru <b>SDI IN D</b>)</li> <li>• Eight AES audio inputs (<b>AES IN 1</b> thru <b>AES IN 8</b>)</li> <li>• Four 3G/HD/SD-SDI video outputs; selectable as processed or input reclocked out (<b>SDI OUT 1</b> thru <b>SDI OUT 4</b>)</li> <li>• Eight AES audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 8</b>)</li> </ul> <p><b>Note:</b> Available equipped with High-Density BNC (HDBNC) or DIN1.0/2.3 connectors as: RM20-9932-E-HDBNC or RM20-9932-E-DIN, respectively.</p>

Table 2-1 9932-EMDE Rear I/O Modules — continued



9932-EMDE Rear I/O Module	Description
<p><b>RM20-9932-G</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• Two 3G/HD/SD-SDI video inputs (<b>SDI IN A</b> and <b>SDI IN B</b>)</li> <li>• One CVBS video input (<b>CVBS IN</b>)</li> <li>• Four analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 4</b>)</li> <li>• Four AES audio inputs (<b>AES IN 1</b> thru <b>AES IN 4</b>)</li> <li>• Two 3G/HD/SD-SDI video outputs (<b>SDI OUT 1</b> and <b>SDI OUT 2</b>)</li> <li>• One CVBS video output (<b>CVBS OUT</b>)</li> <li>• Four analog balanced audio outputs (<b>AN-AUD OUT 1</b> thru <b>AN-AUD OUT 4</b>)</li> <li>• Four AES audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 4</b>)</li> </ul> <p><b>Note:</b> Available equipped with High-Density BNC (HDBNC) or DIN1.0/2.3 connectors as: RM20-9932-G-HDBNC or RM20-9932-G-DIN, respectively.</p>
<p><b>RM20-9932-H</b></p>  <p><b>Note:</b> Refer to GPIO, Serial (COMM), and Analog Audio Connections (p. 2-9) for connector pinouts and important information regarding GPO electrical limits.</p>	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• Two 3G/HD/SD-SDI video input BNCs (<b>SDI IN A</b> and <b>SDI IN B</b>)</li> <li>• One SDI/CVBS video input; selectable as 3G/HD/SD-SDI or CVBS (<b>D/CVBS IN</b>)</li> <li>• Four analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 4</b>)</li> <li>• Two AES audio inputs (<b>AES IN 1</b> and <b>AES IN 2</b>)</li> <li>• Three 3G/HD/SD-SDI video outputs, selectable as processed or reclocked input (<b>SDI OUT 1</b> thru <b>SDI OUT 3</b>)</li> <li>• 3G/HD/SD-SDI video output pair, selectable as processed or reclocked input as a pair (<b>SDI OUT 4a</b> and <b>SDI OUT 4b</b>)</li> <li>• Four analog balanced audio outputs (<b>AN-AUD OUT 1</b> thru <b>AN-AUD OUT 4</b>)</li> <li>• Two AES audio outputs (<b>AES OUT 1</b> and <b>AES OUT 2</b>)</li> <li>• One GPI / 6Hz coaxial input (<b>GPI 1</b>)</li> <li>• One coaxial GPO with isolated return (<b>GPO 1</b>)</li> </ul> <p><b>Note:</b> Available equipped with High-Density BNC (HDBNC) or DIN1.0/2.3 connectors as: RM20-9932-H-HDBNC or RM20-9932-H-DIN, respectively.</p>

Table 2-1 9932-EMDE Rear I/O Modules — continued





9932-EMDE Rear I/O Module	Description
<p><b>RM20-9932-J</b></p>  <p><b>Note:</b> Refer to GPIO, Serial (COMM), and Analog Audio Connections (p. 2-9) for connector pinouts and important information regarding GPO electrical limits.</p>	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• Two 3G/HD/SD-SDI video input BNCs (<b>SDI IN A</b> and <b>SDI IN B</b>)</li> <li>• One SDI/CVBS video input; selectable as 3G/HD/SD-SDI or CVBS (<b>D/CVBS IN</b>)</li> <li>• Four analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 4</b>)</li> <li>• Two AES audio inputs (<b>AES IN 1</b> and <b>AES IN 2</b>)</li> <li>• Four 3G/HD/SD-SDI video outputs, selectable as processed or reclocked input (<b>SDI OUT 1</b> thru <b>SDI OUT 4</b>)</li> <li>• One CVBS video output (<b>CVBS OUT</b>)</li> <li>• Four analog balanced audio outputs (<b>AN-AUD OUT 1</b> thru <b>AN-AUD OUT 4</b>)</li> <li>• Two AES audio outputs (<b>AES OUT 1</b> and <b>AES OUT 2</b>)</li> <li>• One GPI / 6Hz coaxial input (<b>GPI 1</b>)</li> <li>• One coaxial GPO with isolated return (<b>GPO 1</b>)</li> </ul> <p><b>Note:</b> Available equipped with High-Density BNC (HDBNC) or DIN1.0/2.3 connectors as: RM20-9932-J-HDBNC or RM20-9932-J-DIN, respectively.</p>
<p><b>RM20-9932-K</b></p> 	<p>Provides the following connections:</p> <ul style="list-style-type: none"> <li>• Four 3G/HD/SD-SDI video inputs (<b>SDI IN A</b> thru <b>SDI IN D</b>; IN D-to-OUT 1 as passive RLY bypass)</li> <li>• Six AES audio inputs (<b>AES IN 1</b> thru <b>AES IN 6</b>)</li> <li>• Two analog balanced audio inputs (<b>AN-AUD IN 1</b> and <b>AN-AUD IN 2</b>)</li> <li>• Four 3G/HD/SD-SDI video outputs (<b>SDI OUT 1</b> thru <b>SDI OUT 4</b>)</li> <li>• Four AES audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 4</b>)</li> <li>• <b>COMM/GPIO</b> RJ-45 connector</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Refer to GPIO, Serial (COMM), and Analog Audio Connections (p. 2-9) for connector pinouts and important information regarding GPO electrical limits.</li> <li>• Available equipped with High-Density BNC (HDBNC) or DIN1.0/2.3 connectors as: RM20-9932-FS-K-HDBNC or RM20-9932-FS-K-DIN, respectively.</li> </ul>

Table 2-1 9932-EMDE Rear I/O Modules — continued

9932-EMDE Rear I/O Module	Description
<p><b>RM20-9932-N</b></p> 	<p>Double-width rear modules provides the following connections:</p> <ul style="list-style-type: none"> <li>• Four 3G/HD/SD-SDI video inputs (<b>SDI IN A</b> thru <b>SDI IN D</b>)</li> <li>• CVBS video input (<b>CVBS IN</b>)</li> <li>• Four analog balanced audio inputs (<b>AN-AUD IN 1</b> thru <b>AN-AUD IN 4</b>)</li> <li>• Eight AES audio inputs (<b>AES IN 1</b> thru <b>AES IN 8</b>)</li> <li>• Four 3G/HD/SD-SDI video outputs (<b>SDI OUT 1B</b> thru <b>SDI OUT 4B</b> (OUT 1B with relay bypass protect))</li> <li>• CVBS video output (<b>CVBS OUT</b>)</li> <li>• Four analog balanced audio outputs (<b>AN-AUD OUT 1</b> thru <b>AN-AUD OUT 4</b>)</li> <li>• Eight AES audio outputs (<b>AES OUT 1</b> thru <b>AES OUT 8</b>)</li> <li>• <b>COMM/GPIO</b> RJ-45 connector</li> <li>• <b>ETHERNET</b> 100/1000 BaseT Ethernet connector</li> </ul> <p><b>Note:</b> Available equipped with High-Density BNC (HDBNC) or DIN1.0/2.3 connectors as: RM20-9932-N-HDBNC or RM20-9932-N-DIN, respectively.</p>
<div style="border: 1px solid black; padding: 10px; width: fit-content;">  <p style="text-align: center;"><b>COBALT</b> RM20-9001-B/S-DIN</p> <p style="text-align: center;">**SAMPLE-NOT FOR USE**</p> </div>	<p>Due to the density of connector placement on Rear Modules using high-density connectors (e.g., RM20-9001-B/S-DIN), these modules use a QR barcode label instead a regular label. Simply scan the image with a smart phone and a link to the rear module label (as shown in our catalog) will appear. (Smart phone must have a QR reader app such as QuickMark QR Code Reader or equivalent.)</p> <p>Not all devices may be able to acquire the image. If this occurs, use the device to access the web page for card/rear module to view the diagram.</p>

---

## GPIO and Analog Audio Connections

Figure 2-2 shows connections to the card multi-pin terminal block connectors. These connectors are used for card serial comm, GPIO, and balanced analog audio connections.

**Note:** It is preferable to wire connections to plugs oriented as shown in Figure 2-2 rather than assessing orientation on rear module connectors. Note that the orientation of rear module 3-wire audio connectors is not necessarily consistent within a rear module, or between different rear modules. If wiring is first connected to plug oriented as shown here, the electrical orientation will be correct regardless of rear module connector orientation.

## Setting Up 9932-EMDE Network Remote Control

Perform remote control setup in accordance with Cobalt® reference guide “Remote Control User Guide” (PN 9000RCS-RM).

**Note:** • If network remote control is to be used for the frame and the frame has not yet been set up for remote control, Cobalt® reference guide **Remote Control User Guide (PN 9000RCS-RM)** provides thorough information and step-by-step instructions for setting up network remote control of Cobalt® cards using DashBoard™. (Cobalt® OGCP-9000 and OGCP-9000/CC Remote Control Panel product manuals have complete instructions for setting up remote control using a Remote Control Panel.)

Download a copy of this guide by clicking on the **Support>Reference Documents** link at [www.cobaltdigital.com](http://www.cobaltdigital.com) and then select DashBoard Remote Control Setup Guide as a download, or contact Cobalt® as listed in Contact Cobalt Digital Inc. (p. 1-25).

• If installing a card in a frame already equipped for, and connected to DashBoard™, no network setup is required for the card. The card will be discovered by DashBoard™ and be ready for use.




Figure 2-2 GPIO, and Analog Audio Connector Pinouts



---

# Operating Instructions

## Overview

If you are already familiar with using DashBoard or a Cobalt Remote Control Panel to control Cobalt cards, please skip to 9932-EMDE Function Menu List and Descriptions (p. 3-10).

This chapter contains the following information:

- Control and Display Descriptions (p. 3-1)
- Accessing the 9932-EMDE Card via Remote Control (p. 3-6)
- Checking 9932-EMDE Card Information (p. 3-8)
- Ancillary Data Line Number Locations and Ranges (p. 3-9)
- 9932-EMDE Function Menu List and Descriptions (p. 3-10)
- Troubleshooting (p. 3-56)

## Control and Display Descriptions

This section describes the user interface controls, indicators, and displays for using the 9932-EMDE card. The 9932-EMDE functions can be accessed and controlled using any of the user interfaces described here.


The format in which the 9932-EMDE functional controls, indicators, and displays appear and are used varies depending on the user interface being used. Regardless of the user interface being used, access to the 9932-EMDE functions (and the controls, indicators, and displays related to a particular function) follows a general arrangement of Function Menus under which related controls can be accessed (as described in Function Menu/Parameter Overview below).

**Note:** When a setting is changed, settings displayed on DashBoard™ (or a Remote Control Panel) are the settings as effected by the card itself and reported back to the remote control; the value displayed at any time is the actual value as set on the card.

## Function Menu/Parameter Overview

The functions and related parameters available on the 9932-EMDE card are organized into function **menus**, which consist of parameter groups as shown below.

Figure 3-1 shows how the 9932-EMDE card and its menus are organized, and also provides an overview of how navigation is performed between cards, function menus, and parameters.



**Figure 3-1 Function Menu/Parameter Overview**

DashBoard™ User Interface

(See Figure 3-2.) The card function menus are organized in DashBoard™ using tabs. When a tab is selected, each parametric control or selection list item associated with the function is displayed. Scalar (numeric) parametric values can then be adjusted as desired using the GUI slider controls. Items in a list can then be selected using GUI drop-down lists.




Figure 3-2 Typical DashBoard Tabs and Controls


**Cobalt® Remote Control Panel User Interfaces**

(See Figure 3-3.) Similar to the function menu tabs using DashBoard™, the Remote Control Panels have a Select Submenu key that is used to display a list of function submenus. From this list, a control knob on the Control Panel is used to select a function from the list of displayed function submenu items.

When the desired function submenu is selected, each parametric control or selection list item associated with the function is displayed. Scalar (numeric) parametric values can then be adjusted as desired using the control knobs, which act like a potentiometer. Items in a list can then be selected using the control knobs which correspondingly act like a rotary switch. (In this manner, the setting effected using controls and selection lists displayed on the Control Panel are comparable to the submenu items accessed and committed using the 9932-EMDE card edge controls.)

Figure 3-3 shows accessing a function submenu and its parameters (in this example, “Video Proc”) using the Control Panel as compared to using the card edge controls.

**Note:** Refer to “OGCP-9000 Remote Control Panel User Manual” (PN OGCP-9000-OM) or “OGCP-9000/CC Remote Control Panel User Manual” (PN OGCP-9000/CC-OM) for complete instructions on using the Control Panels.



**Figure 3-3 Remote Control Panel Setup of Example Video Proc Function Setup**

Web HTML5 User Interface

(See Figure 3-4.) When equipped with a rear I/O module having an Ethernet port, the 9932-EMDE controls can be accessed via a web network connection with no additional remote control software needed. The web GUI shows the same tabs, controls and status displays as those accessed using DashBoard™. This allows very convenient control access to the card, even if using a computer without DashBoard remote control or in case the frame network connection is down.

The card can be accessed in a web browser by entering the card IP address as set in the card **Admin** tab. (See Admin (Log Status/Firmware Update - Card IP Address) (p. 3-49) for more information.)

**Note:** Card must be equipped with a rear I/O module with an Ethernet port to use html access. The card address is entirely independent of, and requires no association with, the frame openGear IP address.





Figure 3-4 Typical Web GUI Tabs and Controls

## Accessing the 9932-EMDE Card via Remote Control


Access the 9932-EMDE card using DashBoard™ or Cobalt® Remote Control Panel as described below.

### Accessing the 9932-EMDE Card Using DashBoard™

1. On the computer connected to the frame LAN, open DashBoard™.
2. As shown below, in the left side Basic View Tree locate the Network Controller Card associated with the frame containing the 9932-EMDE card to be accessed (in this example, “MFC-8320-N SN: 00108053”).



3. As shown below, expand the tree to access the cards within the frame. Click on the card to be accessed (in this example, “Slot 6: 9932-EMDE”).




As shown on the next page, when the card is accessed in DashBoard™ its function menu screen showing tabs for each function is displayed. (The particular menu screen displayed is the previously displayed screen from the last time the card was accessed by DashBoard™).



## Accessing the 9932-EMDE Card Using a Cobalt® Remote Control Panel

Press the **Select Device** key and select a card as shown in the example below.



## Checking 9932-EMDE Card Information

The operating status and software version the 9932-EMDE card can be checked using DashBoard™ or the card edge control user interface. Figure 3-5 shows and describes the 9932-EMDE card information screen using DashBoard™ and accessing card information using the card edge control user interface.

**Note:** Proper operating status in DashBoard™ is denoted by green icons for the status indicators shown in Figure 3-5. Yellow or red icons respectively indicate an alert or failure condition. Refer to Troubleshooting (p. 3-56) for corrective action.

The **Tree View** shows the cards seen by DashBoard™. In this example, Network Controller Card is hosting a 9932-EMDE card in slot 18.

**Status Display**  
This displays shows the status and format of the signals being received by the 9932-EMDE, as well as card status.

Status	Product Info
Product	9932-EMDE
Product Options	+COLOR +KEYER +ANC +LTC +QC
Supplier	Cobalt Digital Inc.
Revision	1.109.6982-dev
Build Date	Apr 1 2015 11:43:05
FPGA Revision	1.04.0000
FPGA Build Date	Mar 31 2015 10:27:05
Kernel Revision	3.2.0-Local-1.1 #60 Fri May 30 16:28:26
Filesystem Revision	1.0 Oct 20 2014 15:56:55
Flash Storage	40.0 MB free
RAM Usage	17.0 %
CPU Usage	93.0 %
Serial Number	371604
Rear Module	1919

**Card Info Display**  
This displays (alternately selected in the Card Info pane) shows the card hardware and software version info, as well as a Cobalt code number for the currently installed rear module.

Figure 3-5 9932-EMDE Card Info/Status Utility



## Ancillary Data Line Number Locations and Ranges

Table 3-1 lists typical default output video VANC line number locations for various ancillary data items that may be passed or handled by the card.

**Table 3-1 Typical Ancillary Data Line Number Locations/Ranges**


Item	Default Line No. / Range	
	SD	HD
AFD	12 (Note 2)	9 (Note 2)
ATC_VITC	13 (Note 2)	9/8 (Note 2)
ATC_LTC	—	10 (Note 2)
Dolby® Metadata	13 (Note 2)	13 (Note 2)
SDI VITC Waveform	14/16 (Note 2)	—
Closed Captioning	21 (locked)	10 (Note 2)

Notes:

- The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.
- While range indicated by drop-down list on GUI may allow a particular range of choices, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. Limiting ranges for various output formats are as follows:

Format	Line No. Limiting	Format	Line No. Limiting	Format	Line No. Limiting
525i	12-19	720p	9-25	1080p	9-41
625i	9-22	1080i	9-20		

Because line number allocation is not standardized for all ancillary items, consideration should be given to all items when performing set-ups. Figure 3-6 shows an example of improper and corrected VANC allocation within an HD-SDI stream.




**Figure 3-6 Example VANC Line Number Allocation Example**

## 9932-EMDE Function Menu List and Descriptions

Table 3-2 individually lists and describes each 9932-EMDE function menu and its related list selections, controls, and parameters. Where helpful, examples showing usage of a function are also provided. Table 3-2 is primarily based upon using DashBoard™ to access each function and its corresponding menus and parameters.

- Note:**
- **Option** ➡ For any DashBoard tabs on card not appearing in this manual, this indicates the function is an option and covered in a separate Manual Supplement. Please refer to card web page Product Downloads for pdf Manual Supplements covering these options.

On DashBoard™ itself and in Table 3-2, the function menu items are organized using tabs as shown below.



The table below provides a quick-reference to the page numbers where each function menu item can be found.

Function Menu Item	Page	Function Menu Item	Page
Input Video Controls	3-11	Timecode	3-32
Output Video Mode Controls	3-12	Wings Insertion	3-37
Framesync	3-13	Keyer	3-38
Input Audio Status	3-16	Ancillary Data Proc Controls	3-41
Input Audio Routing/Controls	3-17	Presets	3-43
Video Quality Events	3-22	GPO Setup Controls	3-44
Audio Detect Events Setup Controls	3-23	Event Setup Controls	3-45
Video Proc/Color Correction	3-24	Admin (Log Status/Firmware Update - Card IP Address)	3-49
Output Audio Routing/Controls	3-27	User Log	3-51
Text-To-Speech Setup Controls	3-27	Alarms Setup Controls	3-52

Table 3-2 9932-EMDE Function Menu List






	<p>Allows manual or failover selection of card SDI program video inputs and displays status and raster format of received SDI video.</p>
<p><b>• Input Video Source</b></p> 	<p>Selects the input video source to be applied to the card's program video input.</p> <ul style="list-style-type: none"> <li>• <b>SDI A</b> and <b>SDI B</b> choices allow forced manual selection of correspondingly <b>SDI IN A</b> or <b>SDI IN B</b>.</li> <li>• <b>Failover A to B</b> sets main path preference of <b>SDI IN A</b>.             <ul style="list-style-type: none"> <li>- If <b>SDI IN A</b> goes invalid, then <b>SDI IN B</b> is selected.</li> <li>- If <b>SDI IN A</b> goes valid again, failover automatically reverts to <b>SDI IN A</b>.</li> </ul> </li> <li>• <b>Failover B to A</b> sets main path preference of <b>SDI IN B</b>.             <ul style="list-style-type: none"> <li>- If <b>SDI IN B</b> goes invalid, then <b>SDI IN A</b> is selected.</li> <li>- If <b>SDI IN B</b> goes valid again, failover automatically reverts to <b>SDI IN B</b>.</li> </ul> </li> <li>• <b>SDI C</b> and <b>SDI D</b> choices allow forced manual selection of correspondingly <b>SDI IN C</b> or <b>SDI IN D</b> without failover choices.</li> <li>• <b>CVBS</b> – select CVBS input as the program video input.</li> </ul> <p><b>Note:</b> Failover criteria via this control is simple signal presence.</p>
<p><b>• Input Video Status</b></p> 	<p>Displays input status of each video input, along with elapsed time of signal acquire.</p> <p><b>SDI A</b> thru <b>SDI D</b> and <b>CVBS Status</b> show raster/format for all card inputs. If signal is not present or is invalid, <b>Unlocked</b> is displayed. (These status indications are also propagated to the Card Info pane.)</p> <p><b>Note:</b> Status display shows maximum card input complement. Input complement is determined by rear I/O module used.</p>
<p><b>Input SDI Raster Size / Frame Rate Filtering</b></p>	
<p>The controls shown below allow user filtering to exclude selected raster or rate formats from being received by a card input.</p>	
<p>Default settings have all raster sizes and frame rates "checked", thereby providing no filtering (exclusion.)</p>  <p>In the example below, only 720p and 29.97 are checked, filtering allowed input to only be 720p 29.97 ("720p half-rate").</p>  <p><b>Note:</b> Rates shown in selector are frame rates and not field rates.</p>	

Table 3-2 9932-EMDE Function Menu List — continued






	<p>Allows selection of each of the four video output coaxial connectors as processed SDI out or reclocked SDI out. Also provides CVBS parameter controls and test pattern output controls for card CVBS output.</p>
<p>• <b>Output Video Crosspoint</b></p> 	<p>For each SDI output port supported by the card, provides a crosspoint for routing program processed video or selected-input reclocked to an SDI output.</p> <p>In this example, <b>SDI OUT 1</b> and <b>SDI OUT 3</b> are receiving Program (processed) video out, with <b>SDI OUT 2</b> providing SDI IN A reclocked input video.</p> <p><b>Note:</b> Choices shown here are examples only. Key preview available only when equipped with +KEYER option.</p>
	<p>Provides CVBS output parameter controls and test pattern output controls</p>
<p>• <b>CVBS Oversampling and Color Controls</b></p> 	<ul style="list-style-type: none"> <li>• <b>Oversampling</b> enables or disables video DAC oversampling. Oversampling can improve rendering of motion for down-conversions to the CVBS SD analog output.</li> <li>• <b>Color</b> enables or disables chroma content in the CVBS output.</li> </ul>
<p>• <b>CVBS Test Pattern Generator Control</b></p> 	<p>Enables manual insertion (replacement) of CVBS output video to instead output 75% color bars.</p>

Table 3-2 9932-EMDE Function Menu List — continued










	<p>(Option <b>+FS</b> only) Provides video frame sync/delay offset control and output control/loss of program video failover selection controls.</p>
<p>• <b>Framesync Enable/Disable Control</b></p> 	<p>Provides master enable/disable of all card framesync functions/controls.</p>
<p>• <b>Lock Mode Select</b></p> 	<p>Selects Frame Sync functions from the choices shown to the left and described below.</p> <ul style="list-style-type: none"> <li>• <b>Lock to Reference:</b> Output video is locked to selected external reference received on the frame reference bus. (External reference signal Ref 1 / Ref 2 are distributed to the card and other cards via the Ref 1 / Ref 2 buses on the frame.)             <p><b>Note:</b> If valid reference is not received, the <b>Card state:</b> <span style="color: yellow;">●</span> <b>Reference Invalid</b> indication appears in the Card Info status portion of DashBoard™, indicating invalid frame sync reference error.</p> </li> <li>• <b>Lock to Input:</b> Uses the program video input video signal as the reference standard.             <p><b>Note:</b> If <b>Lock to Input</b> is used for framesync, any timing instability on the input video will result in corresponding instability on the output video.</p> </li> <li>• <b>Free Run:</b> Output video is locked to the card's internal clock. Output video is <b>not</b> locked to external reference.</li> </ul>
<p>• <b>Output Rate Select</b></p> 	<p>Allows frame rate to be outputted same as input video, or converted to from the choices shown to the left and described below.</p> <ul style="list-style-type: none"> <li>• <b>Auto</b> – output video frame rate tracks with input video.</li> <li>• <b>23.98/29.97/59.94</b> – forces standard North American frame rates. Can be used to convert 24/30/60 Hz camera frame rates to corresponding 23.98/29.97/59.94 standard North American frame rates.</li> <li>• <b>24/30/60</b> – forces 24/30/60 frame rates. Can be used to convert 23.98/29.97/59.94 Hz frame rates to corresponding 24/30/60 Hz frame rates.</li> </ul>
<p>• <b>Initial Startup Format Select</b></p> 	<p>Selects a synthesized frame sync format/rate to be invoked (from the choices shown to the left) in the time preceding stable lock to external reference.</p> <p>Set this control to that of the intended external reference to help ensure smoothest frame sync locking. This control also sets the card test pattern format where the card's initial output at power-up is the internal pattern instead of program video.</p>

Table 3-2 9932-EMDE Function Menu List — continued

<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Framesync</div>	<p style="text-align: center; font-weight: bold;">(continued)</p>
<p>• <b>Program Video Output Mode Select</b></p> 	<p>Provides a convenient location to select between card program video output and other technical outputs from the choices shown to the left and described below.</p> <ul style="list-style-type: none"> <li>• <b>Input Video</b> – card outputs input program video (or loss of signal choices described below).</li> <li>• <b>Flat Field (Black)</b> – card outputs black flat field.</li> <li>• <b>Freeze</b> – card outputs last frame having valid SAV and EAV codes.</li> <li>• <b>Test Pattern</b> – card outputs standard technical test pattern (pattern is selected using the Pattern drop-down described below).</li> <li>• <b>Snow</b> – card outputs synthesized snow multi-color pattern.</li> </ul>
<p>• <b>Loss of Input Signal Selection</b></p> 	<p>In the event of program input video Loss of Signal (LOS), determines action to be taken as follows:</p> <ul style="list-style-type: none"> <li>• <b>Disable Outputs:</b> Disable program video SDI outputs.</li> <li>• <b>Flat Field</b> – go to flat field on program video output.</li> <li>• <b>Freeze</b> – go to last frame having valid SAV and EAV codes on program video output.</li> <li>• <b>Test Pattern</b> – go to standard technical test pattern on program video output (pattern is selected using the Pattern drop-down described below).</li> <li>• <b>Snow</b> – output synthesized snow multi-color pattern.</li> </ul>
<p>• <b>Test Pattern Select</b></p> 	<p>Provides a choice of standard technical patterns when <b>Test Pattern</b> is invoked (either by LOS failover or directly by selecting Test Pattern on the Program Video Output Mode Select control).</p>
<p>• <b>Flat Field Color Select</b></p> 	<p>Provides a choice of flat field colors when <b>Flat Field</b> is invoked (either by LOS failover or directly by selecting Flat Field on the Program Video Output Mode Select control).</p>

**Table 3-2 9932-EMDE Function Menu List — continued**






	(continued)
<p>• <b>Output Video Reference Offset Controls</b></p> 	<p>With framesync enabled, provides the following controls for offsetting the output video from the reference:</p> <ul style="list-style-type: none"> <li>• <b>Vertical (Lines)</b> – sets vertical delay (in number of lines of <b>output video</b>) between the output video and the frame sync reference. (Positive values provide delay; negative values provide advance)</li> <li>(Range is -1124 thru 1124 lines; null = 0 lines.)</li> <li>• <b>Horizontal (µs)</b> – sets horizontal delay (in µs of <b>output video</b>) between the output video and the frame sync reference. (Positive values provide delay; negative values provide advance)</li> <li>(Range is -64 thru 64 µsec; null = 0.000 µsec.)</li> </ul> <p><b>Note:</b> Offset <b>advance</b> is accomplished by hold-off of the reference-directed release of the frame, thereby effectively advancing the program video relative to the reference.</p>
<p>• <b>Frame Delay Control</b></p> 	<p>When Framesync is enabled, specifies the smallest amount of latency delay (frames held in buffer) allowed by the frame sync. The frame sync will not output a frame unless the specified number of frames are captured in the buffer. <b>The operational latency of the frame sync is always between the specified minimum latency and minimum latency plus one frame (not one field).</b></p> <p><b>Note:</b> Due to card memory limits, the maximum available Minimum Latency Frames is related to the output video format selected. When using this control, be sure to check the <b>Report Delay</b> display to make certain desired amount of frames are delayed.</p>
<p>• <b>Video Delay Display</b></p> 	<p>Displays the current input-to-output video delay (in msec units) as well as in terms of Frames/fractional frame (in number of lines).</p> <p>Status display shows total input-to-output video delay, along with any framesync delay.</p>
<p>• <b>Framesync Lock Status Display</b></p> 	<p>Displays the current framesync status and reference source.</p>
<p><b>Note:</b> Audio timing offset from video is performed using the delay controls on the Input Audio Routing/Controls tab. Refer to Input Audio Routing/Controls (p. 3-17) for these controls.</p>	



Table 3-2 9932-EMDE Function Menu List — continued

<div style="background-color: #444; color: white; padding: 5px; display: inline-block;"><b>Input Audio Status</b></div>	Displays signal status and payload for embedded and discrete audio received by the card.																																								
Individual signal status and peak level displays for embedded audio input pairs, and AES/analog input pairs as described below. <ul style="list-style-type: none"> <li>• <b>Absent:</b> Indicates embedded channel or AES pair does not contain recognized audio PCM data.</li> <li>• <b>Present - PCM:</b> Indicates AES pair or embedded channel contains recognized audio PCM data.</li> <li>• <b>Dolby E:</b> Indicates embedded channel or AES pair contains Dolby® E encoded data.</li> <li>• <b>Dolby Digital:</b> Indicates embedded channel or AES pair contains Dolby® Digital encoded data.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Dolby status displays occur only for valid Dolby® signals meeting SMPTE 337M standard.</li> <li>• AES Dolby-encoded inputs that are routed directly to card are directed via a special path that automatically bypasses SRC. However, AES inputs to other destinations (e.g., AES embedding) are first applied through SRC. These paths disable SRC if Dolby-encoded data is detected. To avoid a possible “Dolby noise burst” if an input on these paths changes from PCM to Dolby, it is recommended to set the AES <b>SRC</b> control for the pair to <b>SCR Off</b> for an AES input that is expected to carry a Dolby signal.</li> </ul>																																									
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;"></th> <th style="width: 45%;">Status</th> <th style="width: 40%;">Peak</th> </tr> </thead> <tbody> <tr> <td>Emb 1-2</td> <td>Dolby Digital</td> <td>Data</td> </tr> <tr> <td>Emb 3-4</td> <td>Present - PCM</td> <td>-80 dBFS/-80 dBFS</td> </tr> <tr> <td>Emb 5-6</td> <td>Present - PCM</td> <td>-80 dBFS/-80 dBFS</td> </tr> <tr> <td>Emb 7-8</td> <td>Present - PCM</td> <td>-20 dBFS/-20 dBFS</td> </tr> <tr> <td>Emb 9-10</td> <td>Present - PCM</td> <td>0 dBFS/-20 dBFS</td> </tr> <tr> <td>Emb 11-12</td> <td>Present - PCM</td> <td>-14 dBFS/-10 dBFS</td> </tr> <tr> <td>Emb 13-14</td> <td>Present - PCM</td> <td>-9 dBFS/-5 dBFS</td> </tr> <tr> <td>Emb 15-16</td> <td>Present - PCM</td> <td>-3 dBFS/0 dBFS</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;"></th> <th style="width: 45%;">Status</th> <th style="width: 20%;">Peak</th> <th style="width: 20%;">SRC</th> </tr> </thead> <tbody> <tr> <td>AES 1-2</td> <td>Dolby E, Line 449</td> <td>---/---</td> <td style="text-align: center;"> <input type="button" value="SRC On"/> </td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;"></th> <th style="width: 85%;">Peak</th> </tr> </thead> <tbody> <tr> <td>Analog 1-2</td> <td>-80 dBFS/-80 dBFS</td> </tr> </tbody> </table>				Status	Peak	Emb 1-2	Dolby Digital	Data	Emb 3-4	Present - PCM	-80 dBFS/-80 dBFS	Emb 5-6	Present - PCM	-80 dBFS/-80 dBFS	Emb 7-8	Present - PCM	-20 dBFS/-20 dBFS	Emb 9-10	Present - PCM	0 dBFS/-20 dBFS	Emb 11-12	Present - PCM	-14 dBFS/-10 dBFS	Emb 13-14	Present - PCM	-9 dBFS/-5 dBFS	Emb 15-16	Present - PCM	-3 dBFS/0 dBFS		Status	Peak	SRC	AES 1-2	Dolby E, Line 449	---/---	<input type="button" value="SRC On"/>		Peak	Analog 1-2	-80 dBFS/-80 dBFS
	Status	Peak																																							
Emb 1-2	Dolby Digital	Data																																							
Emb 3-4	Present - PCM	-80 dBFS/-80 dBFS																																							
Emb 5-6	Present - PCM	-80 dBFS/-80 dBFS																																							
Emb 7-8	Present - PCM	-20 dBFS/-20 dBFS																																							
Emb 9-10	Present - PCM	0 dBFS/-20 dBFS																																							
Emb 11-12	Present - PCM	-14 dBFS/-10 dBFS																																							
Emb 13-14	Present - PCM	-9 dBFS/-5 dBFS																																							
Emb 15-16	Present - PCM	-3 dBFS/0 dBFS																																							
	Status	Peak	SRC																																						
AES 1-2	Dolby E, Line 449	---/---	<input type="button" value="SRC On"/>																																						
	Peak																																								
Analog 1-2	-80 dBFS/-80 dBFS																																								



Table 3-2 9932-EMDE Function Menu List — continued

<b>Input Audio Routing/Controls</b>	Provides audio routing, gain, per-channel/bulk audio delay controls, and audio meters. These controls route selected audio sources onto the card 16-channel internal bus (which is used for all audio processing).
Input Bus    Audio Delay    Dolby E Alignment	



All audio inputs are transferred through the card via the 16-channel Internal Bus (**Bus Ch 1** thru **Bus Ch 16**).

The example above shows various Source selections that direct Emb Ch 1 thru Ch 6 and AES Ch 1 and Ch 2 onto the card internal bus (unused bus channels can be set to Silence or Mute).

Each bus channel provides Gain, Mute, and Invert controls.

The source-to-destination correlation shown here is only an example; **any** of the sources described on the following pages can route to **any** of the internal bus channels.

Table 3-2 9932-EMDE Function Menu List — continued




<div style="background-color: #333; color: white; padding: 5px; border: 1px solid black;"> <b>Input Audio Routing/Controls</b> </div>		<p>(continued)</p>
<div style="background-color: #ccc; border: 1px solid black; padding: 2px; display: flex; justify-content: space-between;"> <span>Input Bus</span> <span>Audio Delay</span> <span>Dolby E Alignment</span> </div>		
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Default factory preset routing routes embedded Ch 1 thru Ch 16 to bus channels Audio Bus Ch 1 thru Ch 16.</li> <li>• <b>Bus Ch 2</b> thru <b>Bus Ch 16</b> have controls identical to the controls described here for <b>Bus Ch 1</b>. Therefore, only the <b>Bus Ch 1</b> controls are shown here.</li> </ul>		
<p>• <b>Bus Channel Source</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <div style="background-color: #333; color: white; padding: 2px; border: 1px solid black; text-align: center;">Audio Bus Ch 1</div> <div style="border: 1px solid #ccc; padding: 2px; display: flex; align-items: center;"> <span>Emb Ch 1</span> <span style="font-size: 0.8em;">▼</span> </div> </div>	<p>Using the <b>Source</b> drop-down list, selects the audio input source to be routed to the card bus channel from the following choices:</p> <ul style="list-style-type: none"> <li>• Embedded input channel 1 thru 16 (<b>Emb Ch 1</b> thru <b>Emb Ch 16</b>)</li> <li>• AES input channel 1 thru 16 (<b>AES Ch 1</b> thru <b>AES Ch 16</b>)</li> <li>• Analog input channel 1 thru 16 (<b>Analog Ch 1</b> thru <b>Analog Ch 4</b>)</li> <li>• Input flex mix summed mix output nodes <b>Flex Bus A</b> thru <b>P</b></li> </ul> <p><b>Note:</b> AES pair and analog channel count are dependent on rear I/O module used.</p>	
<p>• <b>Channel Mute/Phase Invert/Gain Controls and Peak Level Display</b></p> 	<p>Provides <b>Mute</b> and phase <b>Invert</b> channel controls, as well as peak level meter for each output channel. (Meter shows level as affected by Level control.)</p> <p><b>Gain</b> controls allow relative gain (in dB) control for the corresponding destination Embedded Audio Group channel.</p> <p>(-80 to +20 dB range in 1.0 dB steps; unity = 0 dB)</p> <p><b>Note:</b> Although the card can pass non-PCM data such as Dolby® E or AC-3, setting the gain control to any setting other than default 0 will corrupt Dolby data.</p>	
<div style="background-color: #333; color: white; padding: 5px; border: 1px solid black;"> <b>Audio Bus Input Routing/Controls</b> </div>		
<div style="background-color: #ccc; border: 1px solid black; padding: 2px; display: flex; justify-content: space-between;"> <span>Input Bus</span> <span>Audio Delay</span> <span>Dolby E Alignment</span> </div>		
<p>• <b>Bulk (Master) Audio/Video Delay Control</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <div style="display: flex; align-items: center;"> <div style="text-align: center;"> <span style="font-size: 0.8em;">Audio Bulk Delay (msec)</span>  </div> <div style="margin: 0 10px;">...</div> <div style="text-align: center;">  </div> </div> </div>	<p><b>Audio Delay</b> – Provides bulk (all four groups/master) and individual card audio bus channel delay offset controls and delay parametric displays.</p> <p><b>Bulk Delay</b> control adds bulk (all four groups) audio delay from any video delay (net audio delay offset setting adds delay in addition to any delay included by other actions). This control is useful for correcting lip sync problems when video and audio paths in the chain experience differing overall delays. (-33 to +3000 msec range in 0.01-msec steps; null = 0 msec).</p>	

Table 3-2 9932-EMDE Function Menu List — continued



<div style="background-color: #336699; color: white; padding: 5px; text-align: center; font-weight: bold;">Audio Bus Input Routing/Controls</div> <div style="display: flex; justify-content: space-between; border-top: 1px solid black; border-bottom: 1px solid black;"> <span style="background-color: #cccccc; padding: 2px;">Input Bus</span> <span style="background-color: #336699; color: white; padding: 2px;">Audio Delay</span> <span style="background-color: #cccccc; padding: 2px;">Dolby E Alignment</span> </div>	<p>(continued)</p>
<p>• <b>Per-Channel Audio/Video Delay Offset Controls</b></p> <p><b>Offset</b> control adds or reduces (offsets) channel audio delay from the matching video delay (audio delay offset setting adds or removes delay in addition to any delay included by other actions). This control is useful for correcting lip sync problems when video and audio paths in the chain experience differing overall delays.</p> <p>(-800.0 to +800.0 msec range in 0.02 msec steps; null = 0.0 msec)</p> <p><b>Delay Status</b> shows current delay from video for the corresponding audio channel.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Maximum advance/delay offset is dependent on video format.</li> <li>• Where a Dolby pair is present, adjustment of either channel control results in a matching delay setting for the other channel in the pair.</li> </ul> 	
<div style="background-color: #336699; color: white; padding: 5px; text-align: center; font-weight: bold;">Audio Bus Input Routing/Controls</div> <div style="display: flex; justify-content: space-between; border-top: 1px solid black; border-bottom: 1px solid black;"> <span style="background-color: #cccccc; padding: 2px;">Input Bus</span> <span style="background-color: #cccccc; padding: 2px;">Audio Delay</span> <span style="background-color: #336699; color: white; padding: 2px;">Dolby E Alignment</span> </div>	<p><b>Dolby E Alignment</b> – Provides selectable Dolby E alignment for embedded Dolby E to position the bitstream utilizing the Dolby E “guard band”. This helps prevent frame errors that may occur in a bitstream upon switching or editing.</p>
<p>• <b>Dolby E Embedding Alignment Control</b></p> 	<p>For incoming Dolby E data routed to the audio bus (either over embedded channels or via AES embedding to the bus), aligns the embedded Dolby E data corresponding to selection. Alignment line as a result of selection is shown in <b>E Alignment</b> status display.</p> <p><b>Note:</b> Where a frame reference is available, it is recommended to use the <b>Align to Reference</b> selection. This helps ensure that the correct alignment is achieved even if the video is user delayed or output format is changed.</p> <p>Refer to “Preferred Alignment for Dolby E in HD Systems” (<a href="http://www.dolby.com/about/news-events/newsletters-dtvaudio-dolby-e-alignment.html">http://www.dolby.com/about/news-events/newsletters-dtvaudio-dolby-e-alignment.html</a>) for more information regarding Dolby E alignment.</p>

Table 3-2 9932-EMDE Function Menu List — continued

Audio Bus Input Routing/Controls

**Input Flex Mix** – Provides a 16-channel mixer in which each of the inputs can be mixed onto up to 16 independent output summing nodes. Each input channel has independent gain and mute controls.

Flex Mix

	Source	Flex Bus
Flex Mix 1	Embed Ch 1	Flex Mix A
Flex Mix 2	Embed Ch 2	Flex Mix A
Flex Mix 3	Embed Ch 3	Flex Mix A
Flex Mix 4	Embed Ch 4	Flex Mix A
Flex Mix 5	Embed Ch 5	Flex Mix B
Flex Mix 6	Embed Ch 6	Flex Mix B
Flex Mix 7	Embed Ch 11	Flex Mix B
Flex Mix 8	Embed Ch 12	Flex Mix B
Flex Mix 9	Embed Ch 13	Flex Mix C
Flex Mix 10	Embed Ch 14	Flex Mix C
Flex Mix 11	Embed Ch 15	Flex Mix C
Flex Mix 12	Embed Ch 16	Flex Mix C
Flex Mix 13	Analog Input 1	Flex Mix D
Flex Mix 14	Analog Input 2	Flex Mix D
Flex Mix 15	Analog Input 3	Flex Mix D
Flex Mix 16	Analog Input 4	Flex Mix D

In this example four, 4-input mono mixers are provided by selecting **Flex Mixer Bus A** for the Flex Mix 1 thru Flex Mix 4 inputs, and **Flex Mixer Bus B** for the next four inputs, and so on as shown.

	Source	Flex Bus
Flex Mix 1	Embed Ch 1	Flex Mix A
Flex Mix 2	Embed Ch 2	Flex Mix A
Flex Mix 3	AES Ch 1	Flex Mix B
Flex Mix 4	AES Ch 2	Flex Mix B
Flex Mix 5	Analog Input 1	Flex Mix C
Flex Mix 6	Analog Input 2	Flex Mix C
Flex Mix 7	Silence	Flex Mix D
⋮		
Flex Mix 16	Silence	Flex Mix D

In this example three, 2-input mono mixers are provided by selecting **Flex Mixer Bus A** for the Flex Mix 1 and Flex Mix 2 inputs, and **Flex Mixer Bus B** for the next two inputs, and so on as shown.

3-20

9932-EMDE PRODUCT MANUAL

9932EMDE-OM (V1.6)

**Table 3-2 9932-EMDE Function Menu List — continued**









<div style="background-color: #444; color: white; padding: 5px; text-align: center; font-weight: bold;">Audio Bus Input Routing/Controls</div> <div style="background-color: #ccc; padding: 5px; text-align: center; font-weight: bold; margin-top: 10px;">Flex Mix</div>	<p>(continued)</p>
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Flex Mix input channels <b>Flex Mix 2</b> thru <b>Flex Mix 16</b> have controls identical to that described here for Flex Mix 1. Therefore, only the <b>Flex Mix 1</b> controls are shown here.</li> <li>For each Flex Mix input channel, its source should be considered and appropriately set. Unused input channels should be set to the <b>Silence</b> selection.</li> </ul>	
<p>• <b>Flex Mix Input Channel Source/Bus Assignment</b></p> 	<p>Using the <b>Source</b> drop-down list, selects the audio input source to be directed to the corresponding bus channel from the choices listed below.</p> <ul style="list-style-type: none"> <li><b>Silence</b></li> <li><b>Embed Ch 1</b> thru <b>Embed Ch 16</b></li> <li><b>AES Ch 1</b> thru <b>AES Ch 16</b></li> <li><b>Analog Ch 1</b> thru <b>Analog Ch 4</b></li> </ul> <p>The <b>Flex Bus</b> drop-down selects the bus (A thru P) to which the input is assigned to.</p> <p><b>Note:</b> See the examples on the previous page showing various types of mixers using multiple flex buses.</p>
<p>• <b>Gain / Mute Control</b></p> 	<p>Provides relative gain (in dB) control and a channel <b>Mute</b> checkbox.</p> <p>(-80 to +20 dB range in 0.1 dB steps; unity = 0.0 dB)</p>

Table 3-2 9932-EMDE Function Menu List — continued

	<p>(Option <b>+QC</b> only) Sets quality check screening and thresholds for video quality event alerts. When a quality events occur, the event(s) can be used by the Presets function to invoke input routing or other changes.</p>
<p><b>Note:</b> <b>Input B</b> thru <b>Input D</b> have controls identical to the controls described here for <b>Input A</b> sub-tab. Therefore, only the <b>Input A</b> controls are shown here. Set controls for other inputs using the respective sub-tab.</p>	
<p><b>• Event Status Indicator</b></p> 	<p>Displays event status (based on criteria set below) for signal condition to be considered OK (green), or signal condition considered to be a quality alert event (red) due the condition exceeding the criteria threshold(s) set below.</p>
<p><b>• Position and Width Controls</b></p> 	<p>Position and Width controls set the area of concern to be screened by the Quality Event function.</p> <p><b>X and Y Position</b> controls set the origin point for the area of concern</p>  <hr/> <p><b>X and Y Width</b> controls set the size for the area of concern</p> 
<p><b>• Threshold and Event Type Controls</b></p> 	<p>Sets the thresholds for black frame and event type to be considered. Also provides holdoff controls for event trigger engagement and disengagement.</p> <ul style="list-style-type: none"> <li>• <b>Noise Immunity</b> sets the relative noise levels that are rejected in the course of black event assessment (Low, Medium, or High).</li> <li>• <b>Engagement Holdoff</b> sets the time (in msec) where, when time is exceeded, an event is to be considered a valid alert event.</li> <li>• <b>Disengagement Holdoff</b> sets the time (in msec) where, when event time is has ceased, an alert event is cleared.</li> <li>• <b>Event Type</b> sets the type of event(s) to be considered by the event screening (Disabled, Frozen frame, Black frame, or either Black or Frozen frame).</li> </ul>

**Table 3-2 9932-EMDE Function Menu List — continued**

Audio Detect Events

Option

(Option **+QC** only) Sets audio level screening and thresholds for audio silence/presence event alerts on embedded and/or AES discrete audio in. When an audio events occur, the event(s) can be used by the Presets function to invoke input routing or other changes.

Any combination of embedded and AES input channels can be selected to be screened for silence or presence. In the example here, **Audio Detect Event 1** is set to trigger if audio on **any** of channels Emb Ch 1 thru Ch 6 fall below the selected threshold for an interval exceeding the selected threshold. Status indicators for each channel show silence (S) / presence (P) status based on the configured thresholds.

Up to eight independent audio silence/presence events can be set to be screened (with descending priority of consideration from Event 1 down to Event 8). This status here can be propagated to the **Presets > Event Triggers** sub-tab controls to issue a GPO, preset engage, or other command when audio silence events are detected.

	Emb Chan 1	Emb Chan 2	Emb Chan 3	Emb Chan 4	Emb Chan 5	Emb Chan 6	Emb Chan 7	Emb Chan 8	AES Chan 16
Status: S=Silent P=Present	S	P	P	P	P	P	P	P	S
Audio Detect Event 1	Silence	Silence	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care
Audio Detect Event 2	Presence	Presence	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care
⋮									
Audio Detect Event 8	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care
Audio Failover Threshold (dBFS)	-60								
Trigger Holdoff (minutes)	0								
Trigger Holdoff (ms)	5000								
Trigger Release (minutes)	0								
Trigger Release (ms)	0								

- **Audio Failover Threshold** sets the dBFS level at which channel content is considered to be silent, and correspondingly also a transition back to an untriggered condition with resumption of audio for the selected embedded channels. If the selected channels maintain levels above the selected **Audio Failover Threshold**, no triggering is invoked.
- **Trigger Holdoff** sets the period of time in which selected channel silence must occur before an Audio Silence Event trigger goes true.
- **Release Holdoff** control sets the time in which the trigger is revoked upon an event false condition.

**Note:** • Default threshold and holdoff settings shown here are recommended for typical use.










- “Don't Care” setting may be labeled as **Don't Care**, **DC**, or **DSBL** (disabled). All notations mean ignoring the channel from event triggering.
- Selections other than Don't Care work as an AND function. Where multiple selections are set, a true (trigger) condition is not propagated unless **all** selected channels experience the configured criteria.  
(In the example shown above, **both** channels Emb Ch 1 and Emb Ch 2 need to experience a Silence event for a trigger to be propagated.)

9932EMDE-OM (V1.6)

9932-EMDE PRODUCT MANUAL

3-23

Table 3-2 9932-EMDE Function Menu List — continued

 <p>The image shows a menu with 'Video Proc' selected and 'Color Correction' as an option.</p>	<p><b>Option</b> </p> <p>Provides the following Video Proc and Color Correction parametric controls.</p>
<p>• <b>Video Proc</b></p>  <p>The image shows a control labeled 'Video Proc' with a button set to 'Enabled'.</p>	<p><b>Video Proc (Enable/Disable)</b> provides master on/off control of all Video Proc functions.</p> <ul style="list-style-type: none"> <li>• When set to <b>Disable</b>, Video Proc is bypassed.</li> <li>• When set to <b>Enable</b>, currently displayed parameter settings take effect.</li> </ul>
<p>• <b>Reset to Unity</b></p>  <p>The image shows a control labeled 'Reset to Unity' with a 'Confirm' button.</p>	<p><b>Reset to Unity</b> provides unity reset control of all Video Proc functions. When Confirm is clicked, a <b>Confirm?</b> pop-up appears, requesting confirmation.</p> <ul style="list-style-type: none"> <li>• Click <b>Yes</b> to proceed with the unity reset.</li> <li>• Click <b>No</b> to reject unity reset.</li> </ul>
<p>• <b>Luma Gain</b></p>  <p>The image shows a slider control labeled 'Luma Gain' with a value of 0.0.</p>	<p>Adjusts gain percentage applied to Luma (Y channel). (0% to 200% range in 0.1% steps; unity = 100%)</p>
<p>• <b>Luma Lift</b></p>  <p>The image shows a slider control labeled 'Luma Lift' with a value of -100.0.</p>	<p>Adjusts lift applied to Luma (Y-channel). (-100% to 100% range in 0.1% steps; null = 0.0%)</p>
<p>• <b>Color Gain</b></p>  <p>The image shows a slider control labeled 'Color Gain' with a value of 0.0.</p>	<p>Adjusts gain percentage (saturation) applied to Chroma (C-channel). (0% to 200% range in 0.1% steps; unity = 100%)</p>
<p>• <b>Color Phase</b></p>  <p>The image shows a slider control labeled 'Color Phase' with a value of -360.0.</p>	<p>Adjusts phase angle applied to Chroma. (-360° to 360° range in 0.1° steps; null = 0°)</p>
<p>• <b>Gang Luma/Color Gain</b></p>  <p>The image shows a control labeled 'Gang Luma/Color Gain' with a button set to 'On'.</p>	<p>When set to <b>On</b>, changing either the <b>Luma Gain</b> or <b>Color Gain</b> controls increases or decreases both the Luma and Color gain levels by equal amounts.</p>



**Table 3-2 9932-EMDE Function Menu List — continued**












	<p>Provides color corrector functions for the individual RGB channels for the card program video path (option <b>+COLOR</b>).</p>
<p>• <b>Color Corrector</b></p> 	<p><b>Color Corrector (On/Off)</b> provides master on/off control of all Color Corrector functions.</p> <ul style="list-style-type: none"> <li>• When set to <b>Off</b>, all processing is bypassed.</li> <li>• When set to <b>On</b>, currently displayed parameters settings take effect.</li> </ul>
<p>• <b>Reset to Unity</b></p> 	<p><b>Reset to Unity</b> provides unity reset control of all Color Corrector functions.</p> <p>When Confirm is clicked, a <b>Confirm?</b> pop-up appears, requesting confirmation.</p> <ul style="list-style-type: none"> <li>• Click <b>Yes</b> to proceed with the unity reset.</li> <li>• Click <b>No</b> to reject unity reset.</li> </ul>
<p>• <b>Luma Gain R-G-B controls</b></p>  <p>• <b>Black Gain R-G-B controls</b></p>  <p>• <b>Gamma Factor R-G-B controls</b></p> 	<p>Separate red, green, and blue channels controls for Luma Gain, Black Gain, and Gamma curve adjustment.</p> <p>Gain controls provide gain adjustment from 0.0 to 200.0% range in 0.1% steps (unity = 100.0)</p> <p>Gamma controls apply gamma curve adjustment in 0.125 to 8.000 range in thousandths steps (unity = 1.000)</p> <p>Each of the three control groups (Luma, Black, and Gamma have a <b>Gang Column</b> button which allows settings to be proportionally changed across a control group by changing any of the group's controls.</p>

Table 3-2 9932-EMDE Function Menu List — continued

	(continued)
<ul style="list-style-type: none"> <li>• <b>Black Hard Clip</b></li> </ul> 	<p>Applies black hard clip (limiting) at specified percentage. (-6.8% to 50.0%; null = -6.8%)</p>
<ul style="list-style-type: none"> <li>• <b>White Hard Clip</b></li> </ul> 	<p>Applies white hard clip (limiting) at specified percentage. (50.0% to 109.1%; null = 109.1%)</p>
<ul style="list-style-type: none"> <li>• <b>White Soft Clip</b></li> </ul> 	<p>Applies white soft clip (limiting) at specified percentage. (50.0% to 109.1%; null = 109.1%)</p>
<ul style="list-style-type: none"> <li>• <b>Chroma Saturation Clip</b></li> </ul> 	<p>Applies chroma saturation clip (limiting) chroma saturation at specified percentage. (50.0% to 160.0%; null = 160.0%)</p>

**Table 3-2 9932-EMDE Function Menu List — continued**











	<p>Provides an audio crosspoint allowing the audio source selection for each embedded audio output channel. Also provides Gain, Phase Invert, and Muting controls and peak level meters for each output channel.</p>
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• <b>Embedded Ch 2</b> thru <b>Embedded Ch 16</b> have controls identical to the <b>Source</b>, <b>Gain</b>, <b>Mute</b>, and <b>Invert</b> controls described here for <b>Embedded Ch 1</b>. Therefore, only the <b>Embedded Ch 1</b> controls are shown here.</li> <li>• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the <b>Silence</b> selection.</li> </ul>	
<p>• <b>Group Enable/Disable Controls</b></p> 	<p>Allows enable/disable of embedded audio groups 1 thru 4 on card program video output to accommodate some legacy downstream systems that may not support all four embedded audio groups.</p> <p><b>Note:</b> Changing the setting of this control will result in a noise burst in all groups. This control should not be manipulated when carrying on-air content.</p>
<p>• <b>Embedded Output Channel Source</b></p> 	<p>Using the drop-down list, selects the audio input source to be embedded in the corresponding embedded output channel from the following choices:</p> <ul style="list-style-type: none"> <li>• Card <b>Audio Bus Ch 1</b> thru <b>Ch 16</b></li> <li>• Built-in Tone generators <b>Tone n</b> (-20 dBFS level tone generators with <i>n</i> being frequencies of 100, 200, 300, 400, 500, 600, 700, 800, 900, 1k, 2k, 4k, 6k, 8k, 12k, and 16k)</li> <li>• <b>Flex Bus A</b> thru <b>P</b> mixer sum node outputs</li> <li>• <b>Option</b>  <b>Audio LTC</b></li> <li>• <b>Downmixer L</b></li> <li>• <b>Downmixer R</b></li> <li>• <b>Option</b>  <b>Embedded Data L</b> and <b>R</b> (SMPTE 337 non-PCM data embedding with option <b>+ANC</b>)</li> </ul>
<p>• <b>Channel Mute/Phase Invert/Gain Controls and Peak Level Display</b></p> 	<p>Provides <b>Mute</b> and phase <b>Invert</b> channel controls, as well as peak level meter for each output channel. (Meter shows level as affected by Level control.)</p> <p><b>Gain</b> controls allow relative gain (in dB) control for the corresponding destination Embedded Audio Group channel.</p> <p>(-80 to +20 dB range in 1.0 dB steps; unity = 0 dB)</p> <p><b>Note:</b> Although the 9932-EMDE can pass non-PCM data such as Dolby<sup>®</sup> E or AC-3, setting the gain control to any setting other than default 0 will corrupt Dolby data.</p>





Table 3-2 9932-EMDE Function Menu List — continued

<p><b>Output Audio Routing/Controls</b></p> <p>AES Audio Out    Analog Audio Out</p>	<p>Provides an audio crosspoint allowing the audio source selection for each AES audio output channel. Also provides Gain, Phase Invert, and Muting controls and peak level meters for each output channel.</p>
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• AES Out Ch 2 has controls identical to the <b>Source</b>, <b>Gain</b>, <b>Mute</b>, and <b>Invert</b> controls described here for <b>AES Out Ch 1</b>. Therefore, only the <b>AES Out Ch 1</b> controls are shown here.</li> <li>• For each channel, its source and destination should be considered and appropriately set. Unused destination channels should be set to the <b>Silence</b> selection.</li> </ul>	
<p>• <b>AES Output Channel Source</b></p> 	<p>Using the <b>Source</b> drop-down list, selects the audio input source to be routed to the corresponding AES output channel from the following choices:</p> <ul style="list-style-type: none"> <li>• Card <b>Audio Bus Ch 1</b> thru <b>Ch 16</b></li> <li>• Built-in Tone generators <b>Tone n</b> (-20 dBFS level tone generators with <i>n</i> being frequencies of 100, 200, 300, 400, 500, 600, 700, 800, 900, 1k, 2k, 4k, 6k, 8k, 12k, and 16k)</li> <li>• <b>Flex Bus A</b> thru <b>P</b> mixer sum node outputs</li> <li>• <b>Option</b>  <b>Audio LTC</b></li> <li>• <b>Downmixer L</b></li> <li>• <b>Downmixer R</b></li> <li>• <b>Option</b>  <b>Embedded Data L</b> and <b>R</b> (SMPTE 337 non-PCM data embedding with option <b>+ANC</b>)</li> </ul>
<p>• <b>Channel Mute/Phase Invert/Gain Controls and Peak Level Display</b></p> 	<p>Provides <b>Mute</b> and phase <b>Invert</b> channel controls, as well as peak level meter for each output channel. (Meter shows level as affected by Level control.)</p> <p><b>Gain</b> controls allow relative gain (in dB) control for the corresponding destination AES output channel.</p> <p>(-80 to +20 dB range in 1.0 dB steps; unity = 0 dB)</p> <p><b>Note:</b> Although the 9932-EMDE can pass non-PCM data such as Dolby® E or AC-3, setting the gain control to any setting other than default 0 will corrupt Dolby data.</p>

**Table 3-2 9932-EMDE Function Menu List — continued**

<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Output Audio Routing/Controls</div> <div style="display: flex; justify-content: space-around; margin-top: 5px;"> <span style="background-color: #ccc; padding: 2px 5px;">Analog Audio Out</span> <span style="background-color: #ccc; padding: 2px 5px;">Downmixer</span> </div>	<p>Provides an audio crosspoint allowing the audio source selection for each analog audio output channel. Also provides Gain, Phase Invert, and Muting controls and peak level meters for each output channel.</p>
<p>• <b>Analog Output Channel Source</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin: 5px 0;"> <div style="background-color: #333; color: white; padding: 2px; text-align: center; font-weight: bold;">AN Out Ch 1</div> <div style="border: 1px solid #ccc; padding: 2px;">Audio Bus Ch 1 <span style="float: right;">▼</span></div> </div>	<p>Using the <b>Source</b> drop-down list, selects the audio input source to be routed to the corresponding analog audio output channel from the following choices:</p> <ul style="list-style-type: none"> <li>• Card <b>Audio Bus Ch 1</b> thru <b>Ch 16</b></li> <li>• Built-in Tone generators <b>Tone <i>n</i></b> (-20 dBFS level tone generators with <i>n</i> being frequencies of 100, 200, 300, 400, 500, 600, 700, 800, 900, 1k, 2k, 4k, 6k, 8k, 12k, and 16k)</li> <li>• <b>Flex Bus A</b> thru <b>P</b> mixer sum node outputs</li> <li>• <b>Option</b> <b>Audio LTC</b></li> <li>• <b>Downmixer L</b></li> <li>• <b>Downmixer R</b></li> </ul>
<p>• <b>Channel Mute/Phase Invert/Gain Controls and Peak Level Display</b></p>	<p>Provides <b>Mute</b> and phase <b>Invert</b> channel controls, as well as peak level meter for each output channel. (Meter shows level as affected by Level control.)</p> <p><b>Gain</b> controls allow relative gain (in dB) control for each corresponding destination analog audio out channel.</p> <p>(-80 to +20 dB range in 1.0 dB steps; unity = 0 dB)</p>

Table 3-2 9932-EMDE Function Menu List — continued

	<p>Provides audio down-mix audio routing selections that multiplexes any five audio channel sources into a stereo pair.</p>
<p>• <b>Downmixer Source Controls</b></p> 	<p><b>Left Channel Input</b> thru <b>Right Surround Channel Input</b> select the five audio bus source channels to be used for the downmix.</p> <p>Downmix channels <b>Downmixer L</b> and <b>Downmixer R</b> are available as sources for embedded, AES, or analog audio outputs using the Channel Source controls described above.</p>
<p>• <b>Center Mix Ratio Control</b></p> 	<p>Adjusts the attenuation ratio of center-channel content from 5-channel source that is re-applied as Lt and Rt content to the DM-L and DM-R stereo mix.</p> <ul style="list-style-type: none"> <li>• 0 dB setting applies no ratiometric reduction. Center channel content is restored as in-phase center-channel content with no attenuation, making center-channel content more predominate in the overall mix.</li> <li>• Maximum attenuation setting (-80 dB) applies a -80 dB ratiometric reduction of center-channel content. Center-channel content is restored as in-phase center-channel content at a -80 dB ratio relative to overall level, making center-channel content less predominate in the overall mix.</li> </ul> <p>(20 dB to -80 dB range in 0 dB steps; default = 0 dB)</p> <p><b>Note:</b> Default setting is recommended to maintain center-channel predominance in downmix representative to that of the original source 5-channel mix.</p>
<p>• <b>Surround Mix Ratio Control</b></p> 	<p>Adjusts the attenuation ratio of surround-channel content from 5-channel source that is re-applied as Lo and Ro content to the DM-L and DM-R stereo mix.</p> <ul style="list-style-type: none"> <li>• 0 dB setting applies no ratiometric reduction. Surround-channel content is restored with no attenuation, making Lo and Ro content more predominate in the overall mix.</li> <li>• Maximum attenuation setting (-80 dB) applies a -80 dB ratiometric reduction of surround-channel content. Surround-channel content is restored at a -80 dB ratio relative to overall level, making surround-channel content less predominate in the overall mix.</li> </ul> <p>(20 dB to -80 dB range in 0 dB steps; default = 0 dB)</p> <p><b>Note:</b> Default setting is recommended to maintain surround-channel predominance in downmix representative to that of the original source 5-channel mix.</p>

**Table 3-2 9932-EMDE Function Menu List — continued**



<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Output Audio Routing/Controls</div> <div style="background-color: #ccc; padding: 5px; margin-top: 5px; font-weight: bold;">Flex Mix</div>	<p><b>Output Flex Mix</b> – Provides a 16-channel mixer in which each of the inputs can be mixed onto up to 16 independent output summing nodes. The input sources are the card processed audio bus channels. Each input channel has independent gain and mute controls.</p>
<p><b>Note:</b> For each Flex Mix input channel, its source should be considered and appropriately set. Unused input channels should be set to the <b>Silence</b> selection.</p>	
<p>• <b>Flex Bus Input Channel Source/Bus Assignment</b></p> 	<p>Using the <b>Source</b> drop-down list, selects the audio input source to be directed to the corresponding bus channel from the choices listed below.</p> <ul style="list-style-type: none"> <li>• <b>Silence</b></li> <li>• <b>Audio Bus Ch 1 thru Ch 16</b></li> <li>• <b>Tones</b> (100 Hz thru 16 kHz)</li> <li>• <b>Downmix L or Downmix R</b></li> </ul> <p>The <b>Flex Bus</b> drop-down selects the bus (A thru P) to which the input is assigned to.</p>
<p>• <b>Gain / Mute Control</b></p> 	<p>Provides relative gain (in dB) control and a channel <b>Mute</b> checkbox. (-80 to +20 dB range in 0.1 dB steps; unity = 0.0 dB)</p>
<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Text to Speech</div> <div style="background-color: #0070c0; color: white; padding: 5px; margin-top: 5px; font-weight: bold;">Option </div>	<p>Refer to Text-To-Speech option supplement <b>OPT-TTS-MS</b> supplied with this option.</p>

Table 3-2 9932-EMDE Function Menu List — continued

<div style="background-color: #333; color: white; padding: 5px; display: inline-block; border-radius: 5px;">Timecode</div>	<p>Provides timecode data extraction from various sources, and provides formatting and re-insertion controls for inserting the timecode into the output video.</p>																
<p>Shown below is an example in which received 525i 5994 SDI video with VITC waveform timecode is being processed to output ATC_VITC timecode. To re-format and insert the timecode data, the following can be performed using the Timecode function. Each Timecode control is fully described on the pages that follow.</p>																	
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p style="text-align: center;">525i 5994 w/ VITC Waveform</p> <p style="text-align: center;">→ 9932-EMDE →</p> <p style="text-align: center;">525i 5994 w/ ATC_VITC</p> </div> <p><b>A</b> Noting that the incoming video contains VITC waveform timecode data (as shown in the status display), set the Source Priority drop-down lists to include VITC Waveform timecode data (<b>SDI VITC</b>) as a choice. This extracts VITC Waveform timecode data from the incoming video.</p>	<table border="1" style="width: 100%; border-collapse: collapse; background-color: #f0f0f0;"> <tr><td>Reference VITC Status</td><td>05:49:08:20.1</td></tr> <tr><td>Input VITC Status</td><td>05:49:08:19.1</td></tr> <tr><td>Input ATC_LTC Status</td><td>Not Present</td></tr> <tr><td>Input ATC_VITC Status</td><td>Not Present</td></tr> </table> <table border="1" style="width: 100%; border-collapse: collapse; background-color: #f0f0f0;"> <tr><td>Source Priority 1</td><td>Input VITC</td></tr> <tr><td>Source Priority 2</td><td>Input ATC_VITC</td></tr> <tr><td>Source Priority 3</td><td>Reference VITC</td></tr> <tr><td>Source Priority 4</td><td>Free Run</td></tr> </table>	Reference VITC Status	05:49:08:20.1	Input VITC Status	05:49:08:19.1	Input ATC_LTC Status	Not Present	Input ATC_VITC Status	Not Present	Source Priority 1	Input VITC	Source Priority 2	Input ATC_VITC	Source Priority 3	Reference VITC	Source Priority 4	Free Run
Reference VITC Status	05:49:08:20.1																
Input VITC Status	05:49:08:19.1																
Input ATC_LTC Status	Not Present																
Input ATC_VITC Status	Not Present																
Source Priority 1	Input VITC																
Source Priority 2	Input ATC_VITC																
Source Priority 3	Reference VITC																
Source Priority 4	Free Run																
<p><b>B</b> In this example, it is desired to provide SDI ATC_VITC timecode data in the processed output video. As such, set <b>SD ATC VITC Insertion</b> to <b>Enabled</b>.</p> <p>In the example here, the line numbers are set to the default SMPTE 12M-2-2008 recommended values.</p>	<table border="1" style="width: 100%; border-collapse: collapse; background-color: #f0f0f0;"> <tr><td>SD ATC_VITC Insertion</td><td>Enabled</td></tr> <tr><td>SD ATC Insertion Line</td><td>13 - SMPTE 12M-2-2008 Recommended</td></tr> </table>	SD ATC_VITC Insertion	Enabled	SD ATC Insertion Line	13 - SMPTE 12M-2-2008 Recommended												
SD ATC_VITC Insertion	Enabled																
SD ATC Insertion Line	13 - SMPTE 12M-2-2008 Recommended																
<p style="text-align: center;"> <span style="border: 1px solid black; padding: 2px;">Option</span> </p>																	



**Table 3-2 9932-EMDE Function Menu List — continued**







	(continued)
<p><b>Option</b>  <b>Audio LTC</b> controls described below only appear on cards with <b>+LTC</b> licensed optional feature. This feature allows audio LTC from an audio channel to be used as a timecode source, with conversion to a selected SMPTE 12M format on the output video.</p>	
<p>• <b>Timecode Source Status Displays</b></p> 	<p>Displays the current status and contents of the four supported external timecode formats shown to the left.</p> <ul style="list-style-type: none"> <li>• If a format is receiving timecode data, the current content (timecode running count and line number) is displayed.</li> <li>• If a format is not receiving timecode data, Not Present is displayed.</li> </ul>
<p>• <b>LTC Input Control</b></p> 	<p>Selects source to be used by card to <b>receive</b> LTC as listed below.</p> <ul style="list-style-type: none"> <li>• Audio LTC over Emb Ch 1 thru Ch 16</li> <li>• Audio LTC over AES Ch 1 thru Ch 16</li> <li>• Audio LTC over Analog audio Ch 1 thru Ch 4</li> </ul> <p><b>Note:</b> • <b>Audio LTC Source</b> must be appropriately set for card to receive and process received LTC.</p> <ul style="list-style-type: none"> <li>• COM 1 and COM 2 are not available on this model.</li> <li>• Card audio inputs will not center inputs with DC offset. If input has DC offset, the source may need to be capacitively coupled to remove the offset.</li> </ul>
<p>• <b>Mute LTC Control</b></p> 	<p>Allows LTC audio or RS-485 output to mute upon loss of selected timecode inputs.</p> <ul style="list-style-type: none"> <li>• When set to <b>Enabled</b> and input timecode is lost: <ul style="list-style-type: none"> <li>• RS-485 LTC output goes to frozen state.</li> <li>• Audio LTC output mutes.</li> </ul> </li> <li>• When set to <b>Disabled</b> and input timecode is lost: <ul style="list-style-type: none"> <li>• RS-485 LTC output keeps counting, with count value being free-run count.</li> <li>• Audio LTC output is not muted, with count value being free-run count.</li> </ul> </li> </ul> <p><b>Note:</b> If muting upon loss of a particular input format is desired, set all <b>Source Priority 1</b> thru <b>4</b> to that particular input format. If this is not done, the card failover timecode selection may substitute another format choice for the format not being received.</p>
<p>• <b>Incoming ATC Packet Removal Control</b></p> 	<p>Enables or disables removal of existing input video ATC timecode packets from the output. This allows removal of undesired existing timecodes from the output, resulting in a “clean slate” where only desired timecodes are then re-inserted into the output. (For example, if both SDI ATC_VITC and ATC_LTC are present on the input video, and only ATC_LTC is desired, using the Removal control will remove both timecodes from the output. The ATC_LTC timecode by itself can then be re-inserted on the output using the other controls discussed here.)</p> <p><b>Note:</b> Set this control to <b>Enabled</b> if Free-Run timecode is to be used. If incoming packets are not removed, output embedded SMPTE timecode may alternate between free-run and embedded SMPTE timecode values.</p>






Table 3-2 9932-EMDE Function Menu List — continued

<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Timecode</div>	<div style="text-align: center; font-weight: bold;">(continued)</div>												
<p><b>• Source Priority</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <p>Source Priority 1 <span style="float: right;">▼</span></p> <div style="border: 1px solid #ccc; padding: 2px; margin-top: 2px;"> <p>Free Run</p> <p>Reference VITC</p> <p>Input VITC</p> <p>Input ATC_LTC</p> <p>Input ATC_VITC</p> <p>Disable Output</p> </div> <p style="text-align: center;">⋮</p> </div> <div style="border: 1px solid #ccc; padding: 5px;"> <p>Source Priority 4 <span style="float: right;">▼</span></p> <p>Reference VITC</p> </div>	<p>Selects the priority assigned to each of the four supported external formats, and internal Free Run in the event the preferred source is unavailable.</p> <p><b>Source Priority 1</b> thru <b>Source Priority 4</b> select the preferred format to be used in descending order (i.e., Source Priority 2 selects the second-most preferred format, and so on. See example below.)</p> <div style="text-align: center; margin: 10px 0;"> </div> <p>In this example, <b>Input VITC</b> 1st priority selection selects SDI VITC (received on SDI input) over reference VITC (received on frame reference) regardless of video input material source to be processed by the card.</p> <p>The selected timecode source is embedded on the SDI video output (in this example, 720p) using the selected line number. In this example, if the SDI VITC on the SDI input becomes unavailable, the card then uses the reference VITC data received on the frame reference.</p> <p><b>Note:</b> Set Incoming ATC Packet Removal Control to <b>Enabled</b> if Free-Run timecode is to be used. If incoming packets are not removed, output embedded SMPTE timecode may alternate between free-run and embedded SMPTE timecode values.</p>												
<div style="margin-bottom: 10px;"> <p>Disable Output setting should be used with care. If Disable Output is selected with alternate intended format(s) set as a lower priority, the card will indeed disable <b>all</b> timecode output should the ordinate preferred format(s) become unavailable. Typically, choices other than Disable should be used if a timecode output is always desired, with Disable only being used to remove all timecode data.</p> </div> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>In this example, even though and ATC_LTC could be available to substitute for ATC_VITC not being present, the card will revert to no timecode output since the choice of Disable Output “out-prioritizes” ATC_LTC with these settings.</p> </div> <div style="flex: 2; border: 1px solid #ccc; padding: 5px; margin: 5px;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;"><b>Source Priority 1</b></td> <td style="width: 30%;">Input VITC ▼</td> <td style="width: 30%;">Input VITC ▼</td> </tr> <tr> <td><b>Source Priority 2</b></td> <td>Input ATC_VITC ▼</td> <td>Input ATC_VITC ▼</td> </tr> <tr> <td><b>Source Priority 3</b></td> <td>Disable Output ▼</td> <td>Input ATC_LTC ▼</td> </tr> <tr> <td><b>Source Priority 4</b></td> <td>Input ATC_LTC ▼</td> <td>Disable Output ▼</td> </tr> </table> </div> <div style="flex: 1; padding-left: 10px;"> <p>The choices shown here will allow ATC_LTC to “out-prioritize” Disable Output if ATC_VITC is not available.</p> </div> </div>	<b>Source Priority 1</b>	Input VITC ▼	Input VITC ▼	<b>Source Priority 2</b>	Input ATC_VITC ▼	Input ATC_VITC ▼	<b>Source Priority 3</b>	Disable Output ▼	Input ATC_LTC ▼	<b>Source Priority 4</b>	Input ATC_LTC ▼	Disable Output ▼	<p><b>• Offset Controls</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <p>Offset <span style="float: right;">▼</span></p> <div style="border: 1px solid #ccc; padding: 2px; margin-top: 2px;"> <p>Advanced</p> <p>Delayed</p> <p>Advanced</p> </div> </div> <hr/> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Offset Field <span style="float: right;">0 ▼</span></p> <p>Offset Frame <span style="float: right;">0</span></p> </div> </div> <p>Allows the current timecode count to be advanced or delayed on the output video.</p> <ul style="list-style-type: none"> <li>• <b>Offset Advance</b> or <b>Delay</b> selects offset advance or delay.</li> <li>• <b>Offset Field</b> delays or advances or delays timecode by one field.</li> <li>• <b>Offset Frame</b> delays or advances or delays timecode by up to 5 frames.</li> </ul> <p><b>Note:</b> Default settings are null, with both controls set at zero as shown.</p>
<b>Source Priority 1</b>	Input VITC ▼	Input VITC ▼											
<b>Source Priority 2</b>	Input ATC_VITC ▼	Input ATC_VITC ▼											
<b>Source Priority 3</b>	Disable Output ▼	Input ATC_LTC ▼											
<b>Source Priority 4</b>	Input ATC_LTC ▼	Disable Output ▼											

**Table 3-2 9932-EMDE Function Menu List — continued**

<div style="background-color: #333; color: white; padding: 5px; text-align: center; font-weight: bold;">Timecode</div>	(continued)
<p>• <b>Output Status Display</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <p><b>Output Status</b> 00:04:46:06.1 (Source: SDI VITC)</p> </div>	<p>Displays the current content and source being used for the timecode data as follows:</p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <p><b>Output Status</b> 00:04:46:06.1 (Source: SDI VITC)</p> </div> <ul style="list-style-type: none"> <li>• Output status OK (in this example, SDI VITC timecode received and outputted).</li> </ul> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <p><b>Output Status</b> Insertion Disabled</p> </div> <ul style="list-style-type: none"> <li>• <b>Timecode Insertion</b> button set to <b>Disabled</b>; output insertion disabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• If timecode is not available from Source Priority selections performed, timecode on output reverts to Free Run (internal count) mode.</li> <li>• Because the 1's digit of the display Frames counter goes from 0 to 29, the fractional digit (along with the 1's digit) indicates frame count as follows:           <ul style="list-style-type: none"> <li>0.0 Frame 0</li> <li>0.1 Frame 1</li> <li>1.0 Frame 2</li> <li>1.1 Frame 3</li> <li>•</li> <li>•</li> <li>•</li> <li>29.1 Frame 59</li> </ul> </li> </ul>
<p>• <b>Audio LTC Output</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <p><b>Option</b> </p> </div>	<p>Audio LTC output is routed to desired embedded, AES, or analog audio outputs using the Output Audio Routing/Controls (p. 3-27). Whatever timecode is displayed on the Output Status is converted to audio LTC and available as an LTC audio output.</p>
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Although the output line drop-down on the controls described below will allow a particular range of choices, the actual range is automatically clamped (limited) to certain ranges to prevent inadvertent conflict with active picture area depending on video format. See Ancillary Data Line Number Locations and Ranges (p. 3-9) for more information.</li> <li>• The card does not check for conflicts on a given line number. Make certain the selected line is available and carrying no other data.</li> </ul>	
<p>• <b>SD VITC Waveform Insertion Controls</b></p> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> <p>SD VITC Waveform Output 1 Line Number <input style="width: 80px;" type="text" value="14"/></p> <p>SD VITC Waveform Output 2 Line Number <input style="width: 80px;" type="text" value="16"/></p> <p>SD VITC Waveform Insertion <input checked="" type="checkbox"/> Enabled</p> </div>	<p>For SD output, enables or disables SD VITC waveform timecode insertion into the output video, and selects the VITC1 and VITC2 line numbers (6 thru 22) where the VITC waveform is inserted.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• If only one output line is to be used, set both controls for the same line number.</li> <li>• <b>SD VITC Waveform Insertion</b> control only affects VITC waveforms inserted (or copied to a new line number) by this function. An existing VITC waveform on an unscaled SD SDI stream is not affected by this control and is passed on an SDI output.</li> </ul>
<p>• <b>SD ATC Insertion Control</b></p> <div style="border: 1px solid #ccc; padding: 5px;"> <p>SD ATC_VITC Insertion <input checked="" type="checkbox"/> Enabled</p> <p>SD ATC Insertion Line <input type="text" value="13 - SMPTE 12M-2-2008 Recommended"/></p> </div>	<p>For SD output, enables or disables SD ATC_VITC timecode insertion into the output video, and selects the line number for ATC_VITC.</p>

Table 3-2 9932-EMDE Function Menu List — continued

	(continued)
<p>• <b>HD ATC_LTC Insertion Control</b></p> 	<p>For HD output, enables or disables ATC_LTC timecode insertion into the output video, and selects the line number for ATC_LTC timecode data.</p>
<p>• <b>HD ATC_VITC Insertion Control</b></p> 	<p>For HD output, enables or disables ATC_VITC timecode insertion into the output video, and selects the line number for ATC_VITC1 and ATC_VITC2.</p>
<p>• <b>ATC_VITC Legacy Support Control</b></p> 	<p>When enabled, accommodates equipment requiring ATC_VITC packet in both fields as a "field 1" packet (non-toggling).</p> <p><b>Note:</b> Non-toggling VITC1 and VITC2 packets do not conform to SMPTE 12M-2-2008 preferences. As such, ATC_VITC Legacy Support should be enabled only if required by downstream equipment.</p>
<p>• <b>Free Run Timecode Controls</b></p> 	<p>Allows an initial (starting) count to be applied to output video timecode when Free Run insertion is enabled.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Initialization can only be applied when card is outputting Free Run timecode (as shown by Output Status displaying "Free Run").</li> <li>If failover to Free Run occurs due to loss of external timecode(s), the Free Run count assumes its initial count from the last valid externally supplied count.</li> </ul>

**Table 3-2 9932-EMDE Function Menu List — continued**










	<p>Provides wings insertion/width controls and displays insertion status.</p>
<p>• <b>Wings Source Control</b></p> 	<p>Selects the card SDI input video port to serve as the card's wings source.</p> <p><b>Note:</b> SDI inputs selected must be used with Rear I/O Module correspondingly equipped with intended input ports.</p>
<p>• <b>Wings Insertion Enable Control</b></p> 	<p>Enables or disables wings insertion into the output video.</p> <p><b>Note:</b> For conditions where wings is not intended to be inserted, make certain this control is set to Disabled.</p>
<p>• <b>Wings Width Control</b></p> 	<p>Allows symmetrical L/R wings insertion width, from none to widths extending into active image area if desired.</p> <p>(0 to 300 pixel range; null = 0)</p>
<p>• <b>Wings Status Displays</b></p>	<p>Displays wings timing status (on both Wings tab and Card Status displays) as described below.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Wings timing is a function of the wings frame sync card/device. Ideal wings timing is <b>within 0 to 200 samples early</b> of output video timing. Wings timing cannot be controlled on host card wings inserter.</li> <li>• Error in wings timing will result in loss of wings (however, program video image will not be corrupted).</li> </ul>
	

Table 3-2 9932-EMDE Function Menu List — continued

	<p>Provides key/fill insertion controls and displays insertion status.</p>
<p><b>Option</b> ➡ Key/fill controls described below only appear on cards with <b>+KEYER</b> licensed optional feature. This feature requires a Rear Module that accommodates separate key/fill video inputs. Note that on cards also licensed with <b>+KEYER</b>, Wings and Keyer controls appear on the same tab.</p>	
<p>• <b>Key/Fill Source Controls</b></p> 	<p>Selects the card SDI input video ports to serve as the card's key and fill sources.</p> <p><b>Note:</b> SDI inputs selected must be used on Rear I/O Module correspondingly equipped with intended input ports.</p>
<p>• <b>Key Mode Control</b></p> 	<p>Selects key mode as follows:</p> <ul style="list-style-type: none"> <li>• <b>Alpha Ramp</b> setting is used when typical key/fill is provided by key/fill generator with separate key and fill outputs.</li> <li>• <b>Alpha Threshold</b> or <b>Reverse Alpha Threshold</b> setting is used to provide keying using a combined key/fill signal derived from a simple graphic source.</li> </ul>
<p>• <b>Key/Fill Insertion Enable Control</b></p> 	<p><b>Key Enable</b> control sets up key/fill for insertion. When enabled, key preview is available on Key Preview output.</p> <p>When key preview shows desired results, <b>Apply Key To Program</b> can be enabled to apply the key/fill to the program video output.</p>

**Table 3-2 9932-EMDE Function Menu List — continued**




	(continued)
<p>• <b>Key/Fill Status Displays</b></p>	<p>Displays keyer timing status (on both Keyer tab and Card Status displays) as described below.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Key/fill timing is a function of the respective key and fill signal frame sync card/device(s). Ideal timing is within 0 to 200 samples early of output video timing. Key/fill timing cannot be controlled on +KEYER host card.</li> <li>• Error in key/fill timing will result in loss of keying (however, program video image will not be corrupted).</li> </ul>
	
<p>• <b>Key Alpha/Threshold Controls</b></p>	<p>When keying is set to Alpha Threshold or Reverse Alpha Threshold mode sets luma thresholds, when crossed, allow key/fill onto program video image.</p> <p><b>Key Alpha</b> setting, when increased, increases the opacity of the key/fill.</p> <p><b>Key Threshold</b> setting, when reduced, more readily allows the key/fill input to assert itself over more variations of program video luma levels.</p>


Table 3-2 9932-EMDE Function Menu List — continued




**Alpha Threshold** keying allows cost-effective luminance keying from low-cost generic file-based graphic sources. With the graphic source applied to both the card **Key** and **Fill** inputs, the card **Key Alpha** and **Key Threshold** controls can be set to easily optimize the key/fill as shown below.




**Key Threshold** setting, when reduced, more readily allows the key/fill input to assert itself over more variations of program video luma levels. In the example to the right, progressively reducing the threshold setting allows more of the key/fill to assert itself over the program video.



**Key Alpha** setting, when increased, increases the opacity of the key/fill. In the example to the right, progressively increasing the alpha setting increases the key/fill opacity.



When both settings are optimized, the key/fill appears consistent in opacity and free from edge distortions or graphic bleed lines appearing in the image.



**Alpha Threshold** mode setting is suited for graphic sources using black backgrounds.



**Reverse Alpha**

**Threshold** mode setting is suited for graphic sources using white backgrounds.

When using either alpha threshold modes, set the **Key Source** and **Fill Source** to use the same source (in this example, SDI input D).





**Table 3-2 9932-EMDE Function Menu List — continued**

Ancillary Data Processing

ADP Routing
IP Port Setup

Option

Provides controls for VANC/HANC ancillary data de-embedding and embedding to and from program video stream. Data can be extracted and inserted within the card (Bridge mode), or inserted and/or extracted to and from external interfaces via serial or IP interfaces.

Eight individual Ancillary Data Processors (ADPs) provide for insertion, extraction, or bridging ancillary data to and from the card program video SDI stream.

**Mode** controls select the type of ANC processing:

- **Bridge** extracts ANC from the deserialized input video and re-inserts in the output video, thereby allowing full control of specialized ANC packets
- **Insert** and **Extract** modes respectively allow insertion to the output stream or extraction from the input stream between external interfaces

**Interface** controls select either card IP or serial data (COM 1) interface where Mode is set to insertion or extraction  
**Note:** COM1s not available on all models.

**Insertion** controls allow special insertions in HANC or the C-channel, as well as removal of incoming packets

**DID and SDID** controls select the desired packet to be handled by the corresponding ANC Data Processor

**Line Number** controls select the VANC location of packet insertion/extraction

In the example above, **ADP Proc 1** is set to extract ATC timecode at DID60<sub>h</sub> / SDID 60<sub>h</sub>. Depending on the interface used to carry the extraction (COM or IP), status is displayed as shown below.

Extracting 15.0 Kbit/s, dropped 0.0 Kbit

When set to extract to **COM** interface, displays rate and dropped data (if any)

---

Extracting 18.75 Kbit/s, total 125.78 Kbit

When set to extract to **IP** interface, displays rate and total amount transferred

**Note:** DashBoard versions 4.1 and earlier display DID and SDID numbers in decimal; newer DashBoard versions display DID and SDID numbers in hexadecimal. Hexadecimal notation is denoted by the "0x" preceding the value.

Table 3-2 9932-EMDE Function Menu List — continued




	<p><b>IP Port Setup</b> sub-tab provides IP setup for card UDP IP communications.</p>																																																												
<ul style="list-style-type: none"> <li>• <b>Card IP Receive Setup/Status</b></li> </ul> 	<p>Shows card receiving IP address/status and sets port as follows:</p> <ul style="list-style-type: none"> <li>• <b>Card Active IP:</b> Shows the card IP address. (IP address is set using <b>Admin</b> tab Networking settings; see Admin (Log Status/ Firmware Update - Card IP Address) on page 3-49).</li> <li>• <b>Card Port:</b> Sets card IP receive port.</li> <li>• <b>Insertion / Rx Status:</b> Shows card IP receive/Rx insertion status.             <ul style="list-style-type: none"> <li>- Stopped (with yellow indicator) means no data is being received.</li> <li>- Green indicator means data is being received and inserted. Data rate is also shown.</li> </ul> </li> </ul>																																																												
<ul style="list-style-type: none"> <li>• <b>Card IP Transmit Setup/Status</b></li> </ul> 	<p>Provides setup for destination IP address and shows card transmit status as follows:</p> <ul style="list-style-type: none"> <li>• <b>Extraction / Tx Status:</b> Shows card extraction from stream to Tx status.             <ul style="list-style-type: none"> <li>- Stopped (with yellow indicator) means no data is being sent.</li> <li>- Green indicator means data is being extracted and sent. Data rate is also shown.</li> </ul> </li> <li>• <b>Destination IP/Port:</b> Allows setting destination IP address and port.</li> <li>• <b>Extraction Mode:</b> Sets the IP data sent to consist of only payload, or send as formatted packets.</li> </ul>																																																												
<p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>• Packets received must be sized to fit in a native ancillary data packet (i.e., payloads that span multiple ancillary packets need to be broken down by the sending controller before they are sent to the device).</li> <li>• Device can be configured to send back ACK packets each time data is inserted. The ACK packet is sent immediately after the data is actually inserted. Packets need to be broken down by the sending controller before they are sent to the device. Device can also be configured to send out "heartbeat" packets every two seconds as an additional safeguard.</li> <li>• Packet formatting for insertion/extraction, ACK, and heartbeat is as follows:</li> </ul> <table border="1" data-bbox="201 1308 1398 1644"> <thead> <tr> <th colspan="2">Packet formatting used for insertion/extraction:</th> <th colspan="2">ACK Packet Format</th> <th colspan="2">Heartbeat Packets</th> </tr> <tr> <th>Bytes</th> <th>Field</th> <th>Bytes</th> <th>Field</th> <th>Bytes</th> <th>Field</th> </tr> </thead> <tbody> <tr> <td>3:0</td> <td>Packet Type (0xF5AB02ED)</td> <td>3:0</td> <td>Packet Type (0xAC73B938)</td> <td>3:0</td> <td>Packet Type (0x20120831)</td> </tr> <tr> <td>5:4</td> <td>Packet size</td> <td>5:4</td> <td>Received packet size</td> <td>31:4</td> <td>Reserved</td> </tr> <tr> <td>6</td> <td>DID</td> <td>6</td> <td>Received DID</td> <td></td> <td></td> </tr> <tr> <td>7</td> <td>SDID</td> <td>7</td> <td>Received SDID</td> <td></td> <td></td> </tr> <tr> <td>9:8</td> <td>Line number for Insertion. If set to 0, use the line number set by software.</td> <td>9:8</td> <td>Line number on which the received packet was inserted</td> <td></td> <td></td> </tr> <tr> <td>11:10</td> <td>Payload size</td> <td>11:10</td> <td>Received payload size</td> <td></td> <td></td> </tr> <tr> <td>15:12</td> <td>User packet ID</td> <td>15:12</td> <td>Received user packet ID</td> <td></td> <td></td> </tr> <tr> <td>N:16</td> <td>Payload</td> <td>31:16</td> <td>Reserved</td> <td></td> <td></td> </tr> </tbody> </table>		Packet formatting used for insertion/extraction:		ACK Packet Format		Heartbeat Packets		Bytes	Field	Bytes	Field	Bytes	Field	3:0	Packet Type (0xF5AB02ED)	3:0	Packet Type (0xAC73B938)	3:0	Packet Type (0x20120831)	5:4	Packet size	5:4	Received packet size	31:4	Reserved	6	DID	6	Received DID			7	SDID	7	Received SDID			9:8	Line number for Insertion. If set to 0, use the line number set by software.	9:8	Line number on which the received packet was inserted			11:10	Payload size	11:10	Received payload size			15:12	User packet ID	15:12	Received user packet ID			N:16	Payload	31:16	Reserved		
Packet formatting used for insertion/extraction:		ACK Packet Format		Heartbeat Packets																																																									
Bytes	Field	Bytes	Field	Bytes	Field																																																								
3:0	Packet Type (0xF5AB02ED)	3:0	Packet Type (0xAC73B938)	3:0	Packet Type (0x20120831)																																																								
5:4	Packet size	5:4	Received packet size	31:4	Reserved																																																								
6	DID	6	Received DID																																																										
7	SDID	7	Received SDID																																																										
9:8	Line number for Insertion. If set to 0, use the line number set by software.	9:8	Line number on which the received packet was inserted																																																										
11:10	Payload size	11:10	Received payload size																																																										
15:12	User packet ID	15:12	Received user packet ID																																																										
N:16	Payload	31:16	Reserved																																																										

Table 3-2 9932-EMDE Function Menu List — continued





	<p>Allows user control settings to be saved in a Preset and then loaded (recalled) as desired, and provides a one-button restore of factory default settings.</p>
<p><b>• Preset Layer Select</b></p> <p>Allows selecting a functional layer (or “area of concern”) that the preset is concerned with. Limiting presets to a layer or area of concern allows for highly specific presets, and masks changing card settings in areas outside of the layer or area of concern.</p> <p>Default <b>All</b> setting will “look” at all card settings and save all settings to the defined preset with no masking.</p>  <p>Selecting a layer (in the example, “In Audio Routing”) will set the preset to <b>only</b> “look at” and “touch” audio routing settings and save these settings under the preset. When the preset is loaded (recalled), the card will only “touch” the audio routing layer.</p> <p><b>Example:</b> Since EAS audio routing can be considered independent of video proc settings, if normal audio routing was set up with a particular video proc setting in effect, and at a later time EAS audio routing is desired to be saved and invoked as a preset, selecting <b>In Audio Routing</b> here tells the preset save and load to not concern itself with video proc settings. In this manner, any video proc settings in effect when the EAS preset is invoked will not affect any video proc settings that might be currently in effect.</p>	
<p><b>• Preset Enter/Save/Delete</b></p>  <p><b>Protected</b> state – changes locked out</p> <p><b>Ready (open)</b> state – changes can be applied</p>	<p>Locks and unlocks editing of presets to prevent accidental overwrite as follows:</p> <ul style="list-style-type: none"> <li><b>Protect (ready):</b> This state awaits Protected and allows preset Save/Delete button to save or delete current card settings to the selected preset. <b>Use this setting when writing or editing a preset.</b></li> <li><b>Protected:</b> Toggle to this setting to lock down all presets from being inadvertently re-saved or deleted. <b>Use this setting when all presets are as intended.</b></li> <li><b>Create New Preset:</b> Field for entering user-defined name for the preset being saved (in this example, “IRD Rcv122”).</li> <li><b>Save:</b> Saves the current card settings under the preset name defined above.</li> </ul>
<p><b>• Preset Save/Load Controls</b></p>  <ul style="list-style-type: none"> <li><b>Select Preset:</b> drop-down allows a preset saved above to be selected to be loaded or deleted (in this example, custom preset “IRD Rcv122”).</li> <li><b>Load Selected Preset</b> button allows loading (recalling) the selected preset. When this button is pressed, the changes called out in the preset are immediately applied.</li> <li><b>Delete Selected Preset</b> button deletes the currently selected preset.</li> <li><b>Load Factory Defaults</b> button allows loading (recalling) the factory default preset. When this button is pressed, the changes called out in the preset are immediately applied.</li> </ul> <p><b>Note:</b> Load Factory Defaults functions with no masking. The Preset Layer Select controls have no effect on this control and will reset <b>all</b> layers to factory default.</p> <ul style="list-style-type: none"> <li><b>Download Presets</b> saving the preset files to a folder on the connected computer.</li> </ul>	

Table 3-2 9932-EMDE Function Menu List — continued






<p style="text-align: center;"><b>Presets</b></p>	<p style="text-align: center;">(continued)</p>
<p><b>Download (save)</b> card presets to a network computer by clicking <b>Download Presets – Save</b> at the bottom of the Presets page.</p>  <p style="text-align: center;">▼</p> <p>Browse to a desired save location (in this example, <i>My Documents\Cobalt Presets</i>).</p> <p>The file can then be renamed if desired (<i>RCVR21 Presets</i> in this example) before committing the save.</p> 	<p><b>Upload (open)</b> card presets from a network computer by clicking <b>Upload</b> at the bottom of DashBoard.</p>  <p style="text-align: center;">▼</p> <p>Browse to the location where the file was saved on the computer or drive (in this example, <i>My Documents\Cobalt Presets</i>).</p> <p>Select the desired file and click <b>Open</b> to load the file to the card.</p>  <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Preset transfer between card download and file upload is on a <b>group</b> basis (i.e., individual presets cannot be downloaded or uploaded separately).</li> <li>• After uploading a presets file, engagement of a desired preset is only assured by selecting and loading a desired preset as described on the previous page.</li> </ul>
<p style="text-align: center;"><b>GPO Setup</b></p>	<p>Provides controls for setting up the two GPO's power-up states as well as forced manual or event action triggered.</p>
<p><b>Note:</b> This tab has identical independent controls for <b>GPO 1</b> and <b>2</b>. Therefore, only the <b>GPO 1</b> controls are described here.</p>	
	<ul style="list-style-type: none"> <li>• <b>Current State</b> indicates GPO status regardless of any pre-setup.</li> <li>• <b>Power-on State</b> allows the power-up GPO state to be set (initialized) upon power-up</li> <li>• <b>Control Mode</b> allows GPO manual asserted open or closed states, or hands over control to Event Action triggering.</li> </ul>

Table 3-2 9932-EMDE Function Menu List — continued

<div style="background-color: #444; color: white; padding: 5px; font-weight: bold; font-size: 1.2em;">Event Setup</div> <hr style="border: 1px solid black;"/> <div style="display: flex; justify-content: space-around; background-color: #eee; padding: 2px;"> <span>Event Triggers</span> <span>Email Alerts</span> </div>	<p>Provides event-based loading allowing a defined action to be automatically engaged upon various received signal status. Actions can be “canned” control commands or user-defined by going to a user preset.</p>
---	--



- Event based preset loading is not passive and can result in very significant and unexpected card control and signal processing changes if not properly used. If event based presets are not to be used, make certain the **Event Based Loading** button is set to **Disabled**.
- Because event based preset loading can apply card control changes by invoking presets, loading conditions cannot be nested within a called preset (event-based loading settings performed here cannot be saved to presets, although the settings are persistent across power cycles).

Event triggers allow a variety of event screening criteria, and in turn provide an Event Action “go to” in response to the detected event(s). For each screened criteria, categories can be set as “Don’t Care” or set to specific criteria to broaden or concentrate on various areas of concern.

- The **Event based loading** button serves as a master enable/disable for the function.
- Go-to **Event Actions** can be user-defined presets, “canned” (hard-coded) selections (such as GPO triggers or routing changes), or automated E-mail alert to a respondent (see Email Alerts (p. 3-48) for setting up e-mail alerts).
- Each Event (**Event 1** thru **Event 32**) can be set to screen for any or several Definer criteria as shown in the example below. Up to 32 separate events can be defined.
- Event 1 thru Event 32 are arranged with Event 1 having the highest priority, descending down to Event 32. Where multiple event screening is enabled, lower-priority events are serviced first, with the highest-priority event being the final event serviced and last action taken as well as last item logged in the Event History (see below). This helps ensure that a lower-priority event does not mask detection of higher-priority event(s).
- The **Status** indicator and message shows the activation status of each Event. Green indicator means event is currently engaged.

**Event Definers**

Each event can be uniquely set up for any of the condition types in these columns. Unless set to Don’t Care, all defined conditions will need to be true in order for the Event to be considered active

	Status	Acquired Video Format	GPI	Video Quality	Audio Events	ANC Data	User States	Event Action:
Event 1	<span style="color: green;">●</span> Last Active Event	Don't Care	Don't Care	Input A Event Engaged	Don't Care	Don't Care	Don't Care	go to B
Event 2	<span style="color: red;">●</span> Condition Not Met	Don't Care	Don't Care	Input A Event Disengaged	Don't Care	Don't Care	Don't Care	normal path A
...								
Event 32	<span style="color: red;">●</span> Condition Not Met	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	Don't Care	no-cc-msg

**Note:** Event criteria settings in any row comprise an AND function. Where multiple criteria are selected, a true (trigger) condition is not propagated unless **all** specified criteria are true. To independently screen for multiple criteria, rows should be set up where each criteria is screened in its own Event row. Examples of this are shown on the following pages.

Event History	Time	Event Number	Event Action
	19:22:39 02/05/15	2	GPO 1 Close
	19:22:39 02/05/15	4	GPO 2 Close
	19:22:17 02/05/15	2	GPO 1 Close
	19:22:17 02/05/15	4	GPO 2 Close
<b>Card Time</b>	19:25:43 02/05/15		
	Force Event Refresh		

The **Event History** log shows any triggered events in groups of five most recent events (newest at the top).

In the example here, log shows Event 2 as the most recent event, and its user-selected action of GPO 1 Close.

Pressing the **Force Event Refresh** button updates the list.

Table 3-2 9932-EMDE Function Menu List — continued

Event Setup

(continued)

Event Triggers

Email Alerts

In the example here for Event 1, the **Video Quality Events** tab is set to screen for frozen video on Input A. When detected, this status can be used here (Video Quality set to "Input A Event Engaged" indicating black or frozen video detected). Using the Event Action selector, go-to action of "go to B" can be invoked (which in this example is a user preset that changes card routing to use an alternate input source).

Conversely, to go back to the original source, an event could be set up with Video Quality here looking for "Input A Event Disengaged" and in turn invoke an event action returning routing to the original video source (in this example, user preset "normal path A").

Video Quality Events

Event Status ● Frozen video det

Event Type Black or Frozen

Input A
Input B

Video Quality	Audio Events	ANC Data	Event Action:
Input A Event Engaged	Don't Care	Don't Care	go to B
Input A Event Disengaged	Don't Care	Don't Care	normal path A

In the example here, **Event 1** and **Event 3** are respectively set for frozen video and closed captioning absence detection. Using separate Event rows for Video Quality and ANC Data (closed-captioning absence) screening allows these conditions to be independently detected and acted upon with user actions tailored to the event (when either of the conditions are detected, different actions can be taken as selected).

In this example, frozen video calls a preset using an input video routing change, while loss of closed captioning calls a preset to burn a "no CC" message on the raster. Both Events 1 and 3 have corresponding go-to actions to resume normal operation when the event ceases (in this example, a preset "normal path A").

	Status
Event 1	● Last Active Event
Event 2	● Condition Not Met
Event 3	● Condition Met
Event 4	● Condition Not Met

Video Quality	Audio Events	ANC Data	Event Action:
Input A Event Engaged	Don't Care	Don't Care	go to B
Input A Event Disengaged	Don't Care	Don't Care	normal path A
Don't Care	Don't Care	Closed Caption Absence Event	no-cc-msg
Don't Care	Don't Care	Closed Caption Presence Event	normal path A

**Note:**

- Screened conditions are triggered upon start of event. Any event-based setup must be done in advance of the triggering event in order for event to be detected.
- If a desired user preset does not appear in the Event Action drop-down, press the Dashboard **Refresh** button at the bottom of the page to update the list in the drop-down.
- Loss of true conditions does not disengage an event-based triggering. A new set of true conditions must be defined and then occur to transition from one event-based trigger to another.
- Time required to engage an event-based trigger depends upon complexity of the called preset. (For example, a preset that invokes a video change will take longer to engage than a preset involving only an audio routing change.)
- Make certain all definable event conditions that the card might be expected to "see" are defined in any of the Event 1 thru Event 32 rows. This makes certain that the card will always have a defined "go-to" action if a particular event occurs. For example, if the card is expected to "see" a 720p5994 stream or as an alternate, a 525i5994 stream, make certain both of these conditions are defined (with your desired go-to presets) in any two of the Event 1 thru Event 32 condition definition rows.
- Event Actions defined using user presets must be used with care to prevent conditions that could cause looping or the removal or "override" of desired expected settings. When using presets, the Preset Layer selection should be used such that only required aspects are touched (for the example above, the preset "no-cc-msg" should be set to only touch the character burner layer to invoke a character burn).
- Where multiple event screening is set up, the event you consider to be the highest priority should be set as higher priority than lesser events (as shown in the example above where Video Quality screening trumps CC absence). Also, this prioritization helps ensure that all desired events are screened for before a significant change (such as input video source change) is effected.

Table 3-2 9932-EMDE Function Menu List — continued

Event Setup

(continued)

Event Triggers






Email Alerts

**User States** is a special column which allows a logic state to be set (similar to a register or latch) whenever a defined condition is first triggered. A user state (which is latched until cleared by some other definable action) can be successively used with other user states, thereby allowing a final action to be invoked only when subordinate user states have been sequentially satisfied as true.

In the example here, two independent units are used for an EAS alert input (one box supplies alert key video, and the other supplies automated alert audio). Both communicate their ready signal each using edge-trigger GPO's which are fed to the respective GPI 1 and GPI 2 on the card. Because these two boxes are independent and cannot be relied upon to provide coinciding triggers, a chain of user state definers are used here to engage a preset routing key video and EAS audio routing when both states from both boxes are true in the order of GPI 1 first and then GPI 2 second for this example.

Event Setup	Status	GPI	User States	Event Action:	
Event 1	<span style="color: yellow;">●</span> Condition Met	GPI 1 Open->Closed	Don't Care	Set User State 1	GPI 1 (key) cue falling-edge sets user state 1
Event 2	<span style="color: yellow;">●</span> Condition Met	GPI 2 Open->Closed	User State 1 Set	Set User State 2	GPI 2 (audio) cue falling-edge sets user state 2
Event 3	<span style="color: yellow;">●</span> Condition Met	Don't Care	User State 2 Set	Set User State 3	User state 2 (which requires user state 1 being true first) sets state 3, which then invokes a preset to load settings to route EAS key and audio
Event 4	<span style="color: green;">●</span> Last Active Event	Don't Care	User State 3 Set	Preset Load: EAS Key+Audio	
Event 5	<span style="color: red;">●</span> Condition Not Met	Don't Care	User State 1 Cleared	Preset Load: Revert to Normal	When either GPI 1 or GPI 2 has a rising-edge trigger (cease EAS), user states 1 or 2 are cleared, thereby clearing user state 3. Either state change calls a preset to revert to normal operation.
Event 6	<span style="color: red;">●</span> Condition Not Met	Don't Care	User State 2 Cleared	Preset Load: Revert to Normal	
Event 7	<span style="color: red;">●</span> Condition Not Met	GPI 1 Closed->Open	Don't Care	Clear User State 1	
Event 8	<span style="color: red;">●</span> Condition Not Met	GPI 2 Closed->Open	Don't Care	Clear User State 2	

Table 3-2 9932-EMDE Function Menu List — continued

	<p>Provides three general-purpose timers that can be triggered to start, pause, reset, or stop upon event actions. The state of each timer, in turn, can also be used to invoke other actions.</p>																
	<p><b>Event Timers 1 thru 3</b> (Timer 1 shown) can be set with count-down values. The Pause/Reset/Start control here are manual controls. The timers are typically used with automated cues to start and stop the timer(s), as shown below.</p>																
<p>in the example here, <b>Event Timer 1</b> is used to set a logo insertion disable after a specific amount of elapsed time. A GPI inserts the logo, along with a time started at that time. Upon the timer timeout, a separate action sets logo insertion to Disabled.</p>																	
 <table border="1" data-bbox="178 829 1421 1081"> <thead> <tr> <th>Event Setup</th> <th>GPI</th> <th>Event Timers</th> <th>Event Action:</th> </tr> </thead> <tbody> <tr> <td>Event 1</td> <td>GPI 1 Open-&gt;Closed</td> <td>Don't Care</td> <td>Start Timer 1</td> </tr> <tr> <td>Event 2</td> <td>GPI 1 Open-&gt;Closed</td> <td>Don't Care</td> <td>Logo Enable</td> </tr> <tr> <td>Event 3</td> <td>Don't Care</td> <td>Timer 1 Timeout</td> <td>Logo Disable</td> </tr> </tbody> </table>		Event Setup	GPI	Event Timers	Event Action:	Event 1	GPI 1 Open->Closed	Don't Care	Start Timer 1	Event 2	GPI 1 Open->Closed	Don't Care	Logo Enable	Event 3	Don't Care	Timer 1 Timeout	Logo Disable
Event Setup	GPI	Event Timers	Event Action:														
Event 1	GPI 1 Open->Closed	Don't Care	Start Timer 1														
Event 2	GPI 1 Open->Closed	Don't Care	Logo Enable														
Event 3	Don't Care	Timer 1 Timeout	Logo Disable														
	<p>Provides setup for automated Email alerts when an event has occurred.</p>																
<p>As an Event Action choice on the Events Triggers sub-tab, an Email alert can be sent as a response. Set up email fields as shown in the example below.</p> <p><b>Note:</b> Frame hosting the card must be accessible to email recipient's network. It is recommended to set up and generate a test event to test the email send.</p>																	
	<p>When fields are filled-in to specify recipient and sender, and email alert is selected for Event Action on Event Triggers sub-tab page, recipient receives an email alert upon event, with the triggering event shown (in this example, "frozen video detected").</p>																



**Table 3-2 9932-EMDE Function Menu List — continued**




	<p>Provides a global card operating status and allows a log download for factory engineering support. Also provides controls for selecting and loading card firmware upgrade files, and for setting the card comm IP address.</p>
<p>• <b>Card DashBoard Name Control</b></p> 	<p>Allows card name In Dashboard to be changed as desired. Click return to engage change.</p> <ul style="list-style-type: none"> <li>• <b>Append to Product Name</b> appends (or adds to) existing OEM name (for example, "9932-EMDE Processing 1A").</li> <li>• <b>Replace Product Name</b> completely replaces the OEM name OEM name (for example, "Processing 1A").</li> </ul> <p><b>Note:</b> Dashboard instance(s) may have to be refreshed before name change appears.</p>
<p>• <b>Log Status and Download Controls</b></p> 	<ul style="list-style-type: none"> <li>• <b>Log Status</b> indicates overall card internal operating status.</li> <li>• <b>Download Log File</b> allows a card operational log file to be saved to a host computer. This log file can be useful in case of a card error or in the case of an operational error or condition. The file can be submitted to Cobalt engineering for further analysis.</li> <li>• <b>Delete Log File</b> deletes the currently displayed log file. A second confirmation dialog is displayed to back out of the delete if desired.</li> <li>• <b>Thermal Shutdown</b> enable/disable allows the built-in thermal failover to be defeated. (Thermal shutdown is enabled by default).</li> </ul> <p><b>CAUTION</b></p> <p>The 9932-EMDE FPGA is designed for a normal-range operating temperature around 85° C core temperature. Operation in severe conditions exceeding this limit for non-sustained usage are within device operating safe parameters, and can be allowed by setting this control to Disable. However, the disable (override) setting should be avoided under normal conditions to ensure maximum card protection.</p>

Table 3-2 9932-EMDE Function Menu List — continued







	(continued)
<ul style="list-style-type: none"> <li><b>Firmware Upgrade Controls</b></li> </ul>	<p>Firmware upgrade controls allow a selected firmware version (where multiple versions can be uploaded to the card's internal memory) to invoke an upgrade to a selected version either instantly, or set to install on the next card reboot (thereby allowing card upgrade downtime to be controlled at a scheduled point in time).</p>
<p><b>Note:</b> The page/tab here allows managing multiple firmware versions saved on the card. New upgrade firmware from our web site can always be directly uploaded to the card without using this page. Instructions for firmware downloading to your computer and uploading to the card can be found at the <b>Support&gt;Firmware Downloads</b> link at <a href="http://www.cobaltdigital.com">www.cobaltdigital.com</a>.</p>	
<ol style="list-style-type: none"> <li>1. Access a firmware upgrade file from a network computer by clicking <b>Upload</b> at the bottom of DashBoard.</li> <li>2. Browse to the location of the firmware upgrade file (in this example, <i>My Documents\lv1.0.0019.bin</i>).</li> <li>3. Select the desired file and click <b>Open</b> to upload the file to the card.</li> </ol>	 
<ul style="list-style-type: none"> <li><b>Immediate firmware upload.</b> The card default setting of <b>Automatically Reboot After Upgrade</b> checked allow a selected firmware version to be immediately uploaded as follows:</li> </ul> <ol style="list-style-type: none"> <li>1. Click <b>Firmware To Load</b> and select the desired upgrade file to be loaded (in this example, "v1.0.0019").</li> <li>2. Click <b>Load Selected Firmware</b>. The card now reboots and the selected firmware is loaded.</li> </ol>	
<ul style="list-style-type: none"> <li><b>Deferred firmware upload.</b> With <b>Automatically Reboot After Upgrade</b> unchecked, firmware upgrade loading is held off until the card is manually rebooted. This allows scheduling a firmware upgrade downtime event until when it is convenient to experience to downtime (uploads typically take about 60 seconds).</li> </ul> <ol style="list-style-type: none"> <li>1. Click <b>Firmware To Load</b> and select the desired upgrade file to be loaded (in this example, "v1.0.0019"). Note now how the display shows "Installs on Next Reboot".</li> <li>2. Click <b>Load Selected Firmware</b>. The card holds directions to proceed with the upload, and performs the upload only when the card is manually rebooted (by pressing the <b>Reboot</b> button).</li> <li>3. To cancel a deferred upload, press <b>Cancel Pending Upgrade</b>. The card reverts to the default settings that allow an immediate upload/upgrade.</li> </ol>	
<ul style="list-style-type: none"> <li><b>Card IP Physical Port Select Control</b></li> </ul> 	<p>Allows card dedicated IP interface (as set below) to use frame communications or dedicated rear I/O module Ethernet RJ-45 port.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Frame net connection allows cards with per-card Ethernet connection to connect with network via a shared frame Ethernet port instead of per-card dedicated Ethernet connectors on the card's rear module. Frame net connection is available only on certain frame models.</li> <li>• Card slot must be fitted with a rear I/O module equipped with an Ethernet connector in order to use <b>Rear I/O</b> selection.</li> </ul>

Table 3-2 9932-EMDE Function Menu List — continued







<div style="text-align: center; background-color: #333; color: white; padding: 5px; border-radius: 5px;">Admin</div>	<p>(continued)</p>
<p><b>• Card Network Setup Controls</b></p>  <p>The screenshot shows the 'Networking' section with the following fields: 'Card Active IP' (10.99.16.100), 'Addressing Mode' (DHCP), 'Static IP Address' (10.99.16.100), 'Static Subnet Mask' (255.255.255.0), and 'Static Default Gateway' (0.0.0.0).</p>	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The IP address setting here is independent of a frame IP typically used for DashBoard or other frame/card remote control.</li> <li>The IP address setting here is required if the card Ancillary Data Proc Controls function is to send or receive data via IP. If IP comm with Ancillary Data Proc Controls is not required, setting these fields can be ignored. See Ancillary Data Proc Controls (p. 3-41) for more information.</li> </ul> <p><b>• Addressing Mode</b> allows setting address to static (user) address or via DHCP (where a DHCP server is available for the connection).</p> <p><b>• Static IP Address, Static Subnet Mask, and Static Default Gateway</b> fields allow setting IP parameters when Static mode is selected.</p> <p><b>• Card Active IP</b> shows the currently configured IP address (whether static or DHCP).</p>
<p><b>• Card Check and Restore Utilities</b></p>  <p>The screenshot shows the 'Memory Test' section with an 'FPGA Memory Test' button and a 'Test' button. Below it, the 'Memory Test Status' shows 'Running Memory Test: 8.99%'. Another status shows 'Memory test completed successfully, please reboot the card'. The 'Restore From SD Card' section has a 'Confirm' button and a message 'Please contact support'.</p>	<p><b>Memory Test</b> allows all cells of the card FPGA memory to be tested.</p> <p> This control should <b>only</b> be activated under direction of product support. Exercising the memory test is <b>not</b> part of normal card maintenance.</p> <p><b>Restore from SD Card</b> allows card rendered inoperable to be restored using an SD memory card fitted to the card internal SD slot.</p> <p> Product support must be contacted prior to performing this operation. Use of any SD card not supplied by support can corrupt the card.</p>
<p><b>• NTP Clock Setup</b></p>  <p>The screenshot shows the 'Clock Setup' section with the following fields: 'NTP IP (use 0.0.0.0 for pool NTP)' (0.0.0.0), 'Local Timezone (NTP Only)' (US-Central), and 'NTP Status' (Synchronized with NTP).</p>	<p>Allows device NTP clock IP source and localization. This is the clock/time device will use for logs and other recorded actions.</p> <ul style="list-style-type: none"> <li><b>NTP IP</b> sets the IP address where NTP is to be obtained.</li> <li><b>Local Timezone</b> sets the recorded time to the localized time.</li> <li><b>NTP Status</b> shows if time is synced with NTP or if an error exists.</li> </ul>
<div style="text-align: center; background-color: #333; color: white; padding: 5px; border-radius: 5px;">User Log</div>	<p>Automatically maintains a log of user actions and input lock status.</p>
<p><b>User Log</b> shows input lock and other user conditions (with most recent event at top of list).</p> <p><b>Clear User Log</b> clears all entries.</p> <p><b>Download Log File</b> opens a browser allowing the log file to be saved on the host machine.</p>	 <p>The screenshot shows a table with columns 'Time', 'Type', and 'Event'. The table contains four entries: '22:40:36 12/02/15 Info SDI Input sdi_in_c Locked to 720p 59.94', '22:40:34 12/02/15 Info SDI Input sdi_in_d Locked to 1080i 59.94', '21:17:36 12/02/15 Info SDI Input sdi_in_b Locked to 1080i 59.94', and '21:17:18 12/02/15 Info Log file cleared'. Below the table are buttons for 'Clear User Log' (with a 'Confirm' sub-button) and 'Download Log File' (with '9922-FS.tar.gz' and a 'Save' sub-button).</p>

Table 3-2 9932-EMDE Function Menu List — continued

Alarms

Provides controls for setting up controls which screen for and propagate input program video alarms for video, audio, and ancillary data defect conditions.

Conditions and alarm status can be propagated as DashBoard tree-view frame alarms, downloadable .txt files and/or Syslog IP-based alarms.

The **Alarms** tab has several sub-tabs which allow setting up detection and alarm severity/propagation for input program video alarms for video, audio, and ancillary data defect conditions (as described and shown below)

Video Alarm Setup  
Video

Audio Alarm Setup  
Audio

Ancillary Data Alarm Setup  
Ancillary Data

Logging

---

Video Alarm Setup

**Video Alarm Setup** sub-tab allows setting up screening engagement and disengagement holdoff for frozen and/or black video detection on the card's four SDI inputs (independent for each SDI input). In the default example settings shown here, engagement and disengagement of alarm generation occurs 3000 msec after event detect.

Factory default holdoff settings shown here are recommended for at least initial settings. If holdoff periods are too brief, nuisance alarms may be generated during transitions to and from programs and interstitials.

Frozen Video Detection Setup				
	Engagement Holdoff (minutes)	Engagement Holdoff (ms)	Disengagement Holdoff (minutes)	Disengagement Holdoff (ms)
SDI Input A	0	3000	0	3000
SDI Input B	0	3000	0	3000
SDI Input C	0	3000	0	3000
SDI Input D	0	3000	0	3000

Black Video Detection Setup				
	Engagement Holdoff (minutes)	Engagement Holdoff (ms)	Disengagement Holdoff (minutes)	Disengagement Holdoff (ms)
SDI Input A	0	3000	0	3000
SDI Input B	0	3000	0	3000
SDI Input C	0	3000	0	3000
SDI Input D	0	3000	0	3000

Audio Alarm Setup

**Audio Alarm Setup** sub-tab allows setting up screening trigger threshold, engagement and disengagement holdoff for low or missing audio levels on the card's embedded audio input channels.

- Levels **above** the Failover Threshold are considered normal.
- Levels **below** the Failover Threshold (and exceeding the holdoff) are considered below normal.

**Note:** Audio channels screened are from the card SDI that is selected for the program video/audio path (for example, if SDI A is selected as the input source on the **Input Video** tab, the 16 embedded channels comprising this video/audio input are screened).

Factory default holdoff and threshold settings shown here are recommended for at least initial settings. If holdoff periods are too brief (or threshold set too high), nuisance alarms may be generated during transitions to and from programs and interstitials, as well as during certain content.

Audio Failover Threshold (dBFS)	-60
Trigger Holdoff (minutes)	0
Trigger Holdoff (ms)	5000
Release Holdoff (minutes)	0
Release Holdoff (ms)	0

3-52

9932-EMDE PRODUCT MANUAL

9932EMDE-OM (V1.6)

Table 3-2 9932-EMDE Function Menu List — continued



Alarms	(continued)
<div style="background-color: #333; color: white; padding: 5px; margin-bottom: 10px;">Ancillary Data Alarm Setup</div> <p><b>Ancillary Data Alarm Setup</b> sub-tab allows setting up screening engagement and disengagement holdoff for absence of closed captioning packets.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Video screened is the card SDI that is selected for the program video/audio path.</li> <li>• Ancillary data condition detection is functional only for CEA608/708 packet-based closed captioning. This feature does not function for SD line 21 “waveform-based” closed captioning.</li> </ul> 	<p><b>Alarm Propagation Tabs</b>  <b>Video, Audio, and Ancillary Data</b> sub-tabs set alarm propagation attributes, including:</p> <ul style="list-style-type: none"> <li>• Logging of alarms and conditions</li> <li>• Propagation of alarms to the card general Card State/DashBoard frame-based tree-view pane</li> <li>• Ignore alarm, or set severity as <b>Warning</b> (yellow “LED”) or <b>Error</b> (red “LED”)</li> </ul> <p>Each of these sub-tabs is described below.</p> <hr/> <div style="background-color: #333; color: white; padding: 5px; margin-bottom: 10px;">Video</div> <p><b>Video</b> sub-tab independently shows for all four SDI inputs any LOS (loss of signal), frozen, or black conditions triggered for any of the SDI IN A thru SDI IN D inputs.</p> <p><b>Condition/Status</b> has LOS, Frozen, and Black status fields for all 4 SDI inputs. Illuminated “LED” indicates that condition is presently occurring. Color of LED is determined by user-set Severity level.</p> <ul style="list-style-type: none"> <li>• <b>Log</b> (when checked) propagates the alarm to a log file.</li> <li>• <b>Alarm</b> (when checked) propagates the alarm to the Card State and frame-level DashBoard tree-view “LEDs”.</li> <li>• <b>Severity</b> selects from Ignore/OK (green “LED”), Warning (yellow “LED”), and Error (red “LED”) alarm escalation states.</li> <li>• <b>Duration</b> and <b>Last Occurrence</b> shows details for each triggered alarm event.</li> </ul> 
<p><b>Note:</b> The Log, Alarm, Severity, and Duration/Last Occurrence columns appear on the other alarm sub-tabs and function identically as described here.</p>	

Table 3-2 9932-EMDE Function Menu List — continued

Alarms

(continued)

Audio

**Audio** sub-tabs independently show for all 16 embedded channels any missing audio (whether absent due to low level, mute or unlocked status).

**Note:** Audio screened is the audio associated with the selected card SDI program inputs.

Unused audio channels should, at the minimum, have Severity set to Ignore/OK. If this is not done, nuisance alarms may occur.

Condition Status	Log	Alarm	Severity	Duration	Last Occurrence
<span style="color: yellow;">●</span> Missing Audio Ch 1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Warning	00h 15m 49s	07:28:13
<span style="color: yellow;">●</span> Missing Audio Ch 2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Warning	00h 15m 49s	07:28:13
⋮					
<span style="color: green;">●</span> Missing Audio Ch 16	<input type="checkbox"/>	<input type="checkbox"/>	Ignore/OK	00h 15m 49s	07:28:13

Independent rows are present for each of the program path 16 embedded audio channels. Log, Alarm, Severity and Duration/Last Occurrence controls and status function as described in Video (p. 3-53).

---

Ancillary Data

**Ancillary Data** sub-tab shows loss of closed captioning packet presence for program video path.

**Note:**

- Closed captioning screened are the CC packet presence associated with the selected card SDI program inputs.
- Ancillary data condition detection is functional only for CEA608/708 packet-based closed captioning. This feature does not function for SD line 21 “waveform-based” closed captioning.

Condition Status	Log	Alarm	Severity	Duration	Last Occurrence
<span style="color: red;">●</span> Loss Of Closed Captioning	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Error	00h 00m 04s	07:34:23

Row showing program path ANC status. Log, Alarm, Severity and Duration/Last Occurrence controls and status function as described in Video (p. 3-53).

Table 3-2 9932-EMDE Function Menu List — continued

<div style="background-color: #444; color: white; padding: 5px; display: inline-block; border-radius: 3px;">Alarms</div>	<p>(continued)</p>										
<p><b>Alarm Event History</b> shows the eight most-recent alarm events that have been detected (with most-recent at top of list). The alarm severity (as set using the Severity drop-down for each alarm type) sets the “LED” color shown here. In addition to alarms directly affecting performance, status such as cleared alarms are also displayed, as well as any actions related to enabling alarm propagation (such as “Logging Enabled” and “Logging Disabled”). All display rows shown here are retained in the overall log and can be downloaded as a .txt file (see Logging below).</p> <p><b>Cleared</b> alarms appear as an “open” LED</p> <p>Alarms configured as <b>Error</b> or <b>Warning</b> correspondingly appear here as a red “LED” or yellow “LED”</p> <p>Detected alarms event configured as <b>Ignore/OK</b> appear here as a green “LED”</p> <div style="border: 1px solid #ccc; padding: 10px; margin: 10px 0;"> <p style="background-color: #444; color: white; padding: 2px; margin: -10px -10px 10px -10px;">Alarm Event History</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20px; text-align: center;"><input type="radio"/></td> <td>2016-10-12 07:51:19 Loss Of Signal SDI Input A Cleared after 00h 00m 02s</td> </tr> <tr> <td style="text-align: center;"><input checked="" type="radio"/></td> <td>2016-10-12 07:51:16 Loss Of Signal SDI Input A Triggered</td> </tr> <tr> <td style="text-align: center;">•</td> <td></td> </tr> <tr> <td style="text-align: center;">•</td> <td></td> </tr> <tr> <td style="text-align: center;"><input checked="" type="radio"/></td> <td>2016-10-12 07:51:05 Missing Audio Ch 4 Triggered</td> </tr> </table> </div>		<input type="radio"/>	2016-10-12 07:51:19 Loss Of Signal SDI Input A Cleared after 00h 00m 02s	<input checked="" type="radio"/>	2016-10-12 07:51:16 Loss Of Signal SDI Input A Triggered	•		•		<input checked="" type="radio"/>	2016-10-12 07:51:05 Missing Audio Ch 4 Triggered
<input type="radio"/>	2016-10-12 07:51:19 Loss Of Signal SDI Input A Cleared after 00h 00m 02s										
<input checked="" type="radio"/>	2016-10-12 07:51:16 Loss Of Signal SDI Input A Triggered										
•											
•											
<input checked="" type="radio"/>	2016-10-12 07:51:05 Missing Audio Ch 4 Triggered										
<div style="display: flex; align-items: center;"> <div style="background-color: #444; color: white; padding: 5px; display: inline-block; border-radius: 3px; margin-right: 10px;">Logging</div> <div> <p><b>Logging</b> sub-tab allows downloading of an overall running <b>AlarmLog.txt</b> file via DashBoard to a host computer. This sub-tab also has setup controls for using Syslog IP connection of alarm log data (Linux and Unix).</p> <p style="text-align: center;">Clicking <b>Save</b> opens a dialog to save the AlarmLog.txt file to a host computer.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">Setup controls and fields for Syslog</div> <div style="border: 1px solid #ccc; padding: 10px; background-color: #f9f9f9;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <span>Download Log File</span> <span>AlarmLog.txt</span> <span>Save</span> </div> <div style="background-color: #444; color: white; padding: 2px; margin: -10px -10px 10px -10px;">Remote Syslog Setup</div> <p><b>Syslog Enable</b> <input type="checkbox"/></p> <p><b>IP Address</b> <input style="width: 100%;" type="text" value="192.168.2.1"/></p> <p><b>Port</b> <input style="width: 100%;" type="text" value="514"/></p> <p><b>Syslog Host Name</b> <input style="width: 100%;" type="text" value="9922-2FS"/></p> <p><b>Syslog Application Name</b> <input style="width: 100%;" type="text" value="Alarm System"/></p> </div> </div> </div></div>											
<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• Download Log File is performed via DashBoard connection; no external connection is required.</li> <li>• For Syslog usage, default 514 port assignment is recommended.</li> <li>• Syslog usage , is available only on certain frame models offering per-card dedicated Ethernet connection. If this frame type is not being used, card slot must be fitted with a rear I/O module equipped with an Ethernet connector (such as RM20-9932-N) in order to use Syslog.</li> </ul>											

## Troubleshooting

This section provides general troubleshooting information and specific symptom/corrective action for the 9932-EMDE card and its remote control interface. The 9932-EMDE card requires no periodic maintenance in its normal operation; if any error indication (as described in this section) occurs, use this section to correct the condition.

### Error and Failure Indicator Overview

The 9932-EMDE card itself and its remote control systems all (to varying degrees) provide error and failure indications. Depending on how the 9932-EMDE card is being used (i.e., standalone or network controlled through DashBoard™ or a Remote Control Panel), check all available indications in the event of an error or failure condition.

The various 9932-EMDE card and remote control error and failure indicators are individually described below.

**Note:** The descriptions below provide general information for the various status and error indicators. For specific failures, also use the appropriate subsection listed below.

- Basic Troubleshooting Checks (p. 3-60)
- 9932-EMDE Processing Error Troubleshooting (p. 3-61)
- Troubleshooting Network/Remote Control Errors (p. 3-62)



### 9932-EMDE Card Edge Status/Error Indicators and Display

Figure 3-7 shows and describes the 9932-EMDE card edge status indicators and display. These indicators and the display show status and error conditions relating to the card itself and remote (network) communications (where applicable). Because these indicators are part of the card itself and require no external interface, the indicators are particularly useful in the event of communications problems with external devices such as network remote control devices.







Figure 3-7 9932-EMDE Card Edge Status Indicators and Display

## DashBoard™ Status/Error Indicators and Displays

Figure 3-8 shows and describes the DashBoard™ status indicators and displays. These indicator icons and displays show status and error conditions relating to the 9932-EMDE card itself and remote (network) communications.

Indicator Icon or Display	Error Description
	<p>Red indicator icon in Card Access/Navigation Tree pane shows card with Error condition (in this example, the Card Access/Navigation Tree pane shows a general error issued by the 9932-EMDE card in slot 6).</p> <p>Specific errors are displayed in the Card Info pane (in this example “No connection to device” indicating 9932-EMDE card is not connecting to frame/LAN).</p> <p>If the 9932-EMDE card is not connecting to the frame or LAN, all controls are grayed-out (as shown in the example here).</p>
	<p>Gray indicator icon in Card Access/Navigation Tree pane shows card(s) are not being seen by DashBoard™ due to lack of connection to frame LAN (in this example, both a 9932-EMDE card in slot 6 and the MFC-8320-N Network Controller Card for its frame in slot 0 are not being seen).</p>
	<p>Yellow indicator icon in Card Access/Navigation Tree pane shows card with Alert condition (in this example, the Card Access/Navigation Tree pane shows a general alert issued by the MFC-8320-N Network Controller Card).</p> <p>Clicking the card slot position in the Card Access/Navigation Tree (in this example Network Controller Card “Slot 0: MFC-8320-N”) opens the Card Info pane for the selected card. In this example, a “Fan Door Open” specific error is displayed.</p>

**Figure 3-8 DashBoard™ Status Indicator Icons and Displays**

Access Card Info panes for specific cards by clicking the card slot position in the Card Access/Navigation Tree pane (as shown in the example in Figure 3-9).




Figure 3-9 Selecting Specific Cards for Card Info Status Display

## Basic Troubleshooting Checks

Failures of a general nature (affecting many cards and/or functions simultaneously), or gross inoperability errors are best addressed first by performing basic checks before proceeding further. Table 3-3 provides basic system checks that typically locate the source of most general problems. If required and applicable, perform further troubleshooting in accordance with the other troubleshooting tables in this section.

**Table 3-3 Basic Troubleshooting Checks**

Item	Checks
<b>Verify power presence and characteristics</b>	<ul style="list-style-type: none"> <li>• On both the frame Network Controller Card and the 9932-EMDE, in all cases when power is being properly supplied there is always at least one indicator illuminated. Any card showing no illuminated indicators should be cause for concern.</li> <li>• Check the Power Consumed indication for the 9932-EMDE card. This can be observed using the DashBoard™ Card Info pane.               <ul style="list-style-type: none"> <li>• If display shows <b>no</b> power being consumed, either the frame power supply, connections, or the 9932-EMDE card itself is defective.</li> <li>• If display shows <b>excessive</b> power being consumed (see Technical Specifications (p. 1-21) in Chapter 1, “Introduction”), the 9932-EMDE card may be defective.</li> </ul> </li> </ul>
<b>Check Cable connection secureness and connecting points</b>	Make certain all cable connections are fully secure (including coaxial cable attachment to cable ferrules on BNC connectors). Also, make certain all connecting points are as intended. Make certain the selected connecting points correlate to the intended card inputs and/or outputs. Cabling mistakes are especially easy to make when working with large I/O modules.
<b>Card seating within slots</b>	Make certain all cards are properly seated within its frame slot. (It is best to assure proper seating by ejecting the card and reseating it again.)
<b>Check status indicators and displays</b>	On both DashBoard™ and the 9932-EMDE card edge indicators, red indications signify an error condition. If a status indicator signifies an error, proceed to the following tables in this section for further action.
<b>Troubleshoot by substitution</b>	All cards within the frame can be hot-swapped, replacing a suspect card or module with a known-good item.

## 9932-EMDE Processing Error Troubleshooting


Table 3-4 provides 9932-EMDE processing troubleshooting information. If the 9932-EMDE card exhibits any of the symptoms listed in Table 3-4, follow the troubleshooting instructions provided.

In the majority of cases, most errors are caused by simple errors where the 9932-EMDE is not appropriately set for the type of signal being received by the card.

**Note:** The error indications shown below are typical for the corresponding error conditions listed. Other error indications not specified here may also be displayed on DashBoard™ and/or the 9932-EMDE card edge status indicators.

**Note:** Where errors are displayed on both the 9932-EMDE card and network remote controls, the respective indicators and displays are individually described in this section.

**Table 3-4 Troubleshooting Processing Errors by Symptom**

Symptom	Error/Condition	Corrective Action
<ul style="list-style-type: none"> <li>DashBoard™ shows <b>Unlocked</b> message in 9932-EMDE Card Info pane</li> </ul>  <ul style="list-style-type: none"> <li>Card edge <b>Input LED</b> corresponding to input is not illuminated</li> </ul>	No video input present	Make certain intended video source is connected to appropriate 9932-EMDE card video input. Make certain BNC cable connections between frame Rear I/O Module for the card and signal source are OK.
Ancillary data (timecode) not transferred through 9932-EMDE	<ul style="list-style-type: none"> <li>Control(s) not enabled</li> <li>VANC line number conflict between two or more ancillary data items</li> </ul>	<ul style="list-style-type: none"> <li>Make certain respective control is set to <b>On</b> or <b>Enabled</b> (as appropriate).</li> <li>Make certain each ancillary data item to be passed is assigned a unique line number (see Ancillary Data Line Number Locations and Ranges on page 3-9).</li> </ul>
Audio not processed or passed through card	Enable control not turned on	On <b>Output Audio Routing/Controls</b> tab, <b>Audio Group Enable</b> control for group 1 thru 4 must be turned on for sources to be embedded into respective embedded channel groups.
Excessive or nuisance input signal quality events in log or Card State status display	Holdoff periods are too brief (or threshold set too high)	If holdoff periods are too brief (or threshold set too high), nuisance alarms may be generated during transitions to and from programs and interstitials, as well as during certain content.
(Option +QC only) Audio silence event not detected or triggered on	Holdoff set too long to detect condition	The <b>Trigger Holdoff</b> controls on the <b>Audio Detect Events</b> tab allow ignoring silence events unless the event duration exceeds the holdoff setting. Make certain holdoff is set sufficiently low to detect events as desired.

**Table 3-4 Troubleshooting Processing Errors by Symptom — continued**

Symptom	Error/Condition	Corrective Action
Selected upgrade firmware will not upload	Automatic reboot after upgrade turned off	Card <b>Presets &gt; Automatically Reboot After Upgrade</b> box unchecked. Either reboot the card manually, or leave this box checked to allow automatic reboot to engage an upgrade upon selecting the upgrade.
Card does not pass video or audio as expected. Control settings spontaneously changed from expected settings.	Event-based preset inadvertently invoked	Event-based preset loading ( <b>Presets</b> tab > <b>Event Triggers</b> sub-tab) should be set to <b>Disabled</b> if this function is not to be used. Read and understand this control description before using these controls to make sure engagement for all expected conditions is considered. See Presets (p. 3-43) for more information.
Card will not retain user settings, or setting changes or presets spontaneously invoke.	<b>Event Based Loading</b> sub-tab inadvertently set to trigger on event	If event based loading is not to be used, make certain <b>Event Based Presets</b> is disabled (either using master <b>Enable/Disable</b> control or through events settings. See Presets (p. 3-43) for more information.

## Troubleshooting Network/Remote Control Errors

Refer to Cobalt® reference guide “Remote Control User Guide” (PN 9000RCS-RM) for network/remote control troubleshooting information.

## In Case of Problems

### Recovering Card From SD Memory Card

New production cards come equipped with an SD card installed in a slot receptacle on the underside of the card. The data on this SD card can be used to restore a card should the card become unresponsive (can’t communicate with DashBoard or other remote control). Recovering a card using the procedure here will restore the card to any installed option licenses and the most recent firmware installed.

1. (See Figure 3-10.) Make certain the card has the proper SD card installed in the under-card slot. If SD card is **not** installed, contact Product Support to obtain an SD card.

- Note:**
- (Option +TTS only) Cards shipped with option +TTS use an SD card for the TTS library in addition to recovery files. If your +TTS-equipped device was received **earlier than December 2015**, your SD may not contain the recovery files. Contact Product Support to obtain the updated SD card containing both TTS library and SD recovery files.
  - If unit is a BBG-1000 Series device, remove the top cover before proceeding.




Figure 3-10 SD Card Installation

- (See Figure 3-11.) With card powered-down, locate the **MMC BOOT** button on the card. Proceed as shown in picture.




Figure 3-11 MMC Boot Button

- With button now released, the card will begin reprogramming:
  - COM LED** illuminates and remains illuminated.
  - When reprogram is complete, **COM LED** turns off, on, and then off again (entire process takes about 1-1/2 minute).

4. Remove power from the card (remove card from slot or power-down BBG-1000 Series unit).
5. Re-apply power to the card. The card/device will display as “*UNLICENSED*” in DashBoard/remote control.
6. In Dashboard or web remote control, go to **Admin** tab and click **Restore from SD Card**. After about 1/2-minute, the card license(s) will be restored and card will be using its most recently installed firmware.
7. Card/device can now be used as normal. On BBG-1000 Series unit, re-install top cover.

### **Contact and Return Authorization**

Should any problem arise with this product that was not solved by the information in this section, please contact the Cobalt Digital Inc. Technical Support Department.

If required, a Return Material Authorization number (RMA) will be issued to you, as well as specific shipping instructions. If required, a temporary replacement item will be made available at a nominal charge. Any shipping costs incurred are the customer’s responsibility. All products shipped to you from Cobalt Digital Inc. will be shipped collect.

The Cobalt Digital Inc. Technical Support Department will continue to provide advice on any product manufactured by Cobalt Digital Inc., beyond the warranty period without charge, for the life of the product.

See Contact Cobalt Digital Inc. (p. 1-26) in Chapter 1, “Introduction“ for contact information.







**Cobalt Digital Inc.**

2506 Galen Drive  
Champaign, IL 61821  
Voice 217.344.1243 • Fax 217.344.1245  
[www.cobaltdigital.com](http://www.cobaltdigital.com)